

Dear Customer,

We are pleased that you have chosen a motorhome from **HYMER** and would like to thank you for the trust you have shown in our company.

This instruction manual is intended to help you get to know and use your new motorhome. It is essential that you read and comply with the safety instructions in chapter 2.

Don't hesitate to contact our **HYMER** service centres if you have any questions. Their staffs are fully conversant with your vehicle and will be pleased to help in any way they can. Our list of **HYMER** service centres in Europe is updated regularly. You can obtain a copy of the latest edition from our customer service department or from your **HYMER** dealer.

In addition to this instruction manual, you are also receiving from us

- the service folder containing all information about the inspection intervals and the water ingress tests.
- the separate instruction manuals for the base vehicle and the various appliances.

We are sure that you will get a lot of enjoyment from your motorhome. Have a good trip! You will also find **HYMER GmbH & Co. KG** on the Internet at: http://www.hymer.com Yours, **HYMER GmbH & Co. KG**

Please also observe the chassis manufacturer's operating instructions at all times.

The terms used in these operating instructions with regard to weight specifications are explained again in detail at the end of the operating instructions (legal information on weight-related specifications). For further details on weight specifications, please also refer to the "Weight information" section of our homepage at www.hymer.com/en/en/weight-information





Checkl	list before first	4.6	Seat belts	
journe	y of the vehicle7	4.6.1	General	
•	,	4.6.2	Fastening the seat belts correctly	
1	Introduction9	4.6.3	Seat belt cover	
1.1	General10	4.7	Child restraint systems	
1.2	Environmental tips10	4.7.1	Isofix fastening system for child seat	55
		4.8	Driver's seat and front	
2	Safety 13		passenger's seat	56
2.1	Fire prevention13		Seat heater	57
2.1.1	Avoidance of fire risks13		Headrests (bench)	58
2.1.2	Fire-fighting13	4 4 4	Attachable seat	59
2.1.3	In case of fire13		Additional seat	61
2.2	General14	4 4 0	Seating arrangement	62
2.3	Road safety15		Electrical window winder	
2.4	Towing16		Electrically adjustable and heatable	
2.5	Gas system16		external mirrors	63
2.5.1	General instructions16		Roman shades for driver's window	
2.5.1			and front passenger's window	63
	Gas bottles	4 4 7	Curtain shades for driver's window,	00
2.6	Electrical system		windscreen, and front	
2.7	Water system19		passenger's window	64
2	Defere the journey 21	4.18	Reversing camera	
3	Before the journey21	4.19	Bonnet	
3.1	Initial start-up21	4.19	Filling with windscreen washer fluid	
3.2	Vehicle load capacity21		Checking the oil level	
3.2.1	Terms22	4.21		
3.2.2	Calculating the vehicle	4.00	Refuelling	
	load capacity26		Ad-Blue [®]	
3.2.3	Load securing and load distribution27		Towing	ხ8
3.2.4	Roof loads32	E	Ditabing the Meterogravan	60
3.2.5	Rear garage / rear storage space 33	- 4	Pitching the Motorcaravan	
\sim	Bike rack36	5.1	Handbrake	
3.3	DINC TACK	5 0	C - (
3.4	Towing37	5.2	Entrance step	
	Towing	5.2 5.3	Ramps	69
3.4	Towing37	5.2 5.3 5.4	RampsWheel chock	69 69
3.4 3.5	Towing	5.2 5.3 5.4 5.5	Ramps	69 69 70
3.4 3.5 3.6	Towing	5.2 5.3 5.4 5.5 5.6	Ramps	69 69 70
3.4 3.5 3.6 3.6.1	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38	5.2 5.3 5.4 5.5 5.6 5.6.1	Ramps	69 69 70 70
3.4 3.5 3.6 3.6.1 3.6.2	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2	Ramps	69 70 70 70
3.4 3.5 3.6 3.6.1 3.6.2 3.7	Towing	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs	69 70 70 70 70
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection	69 70 70 70 70
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs	69 70 70 70 70
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection	69 70 70 70 72 76
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning	69 70 70 70 72 76 76
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator	69 70 70 70 72 76 76
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning	69 70 70 70 76 76
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning	69 70 70 70 76 76 76
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Living Doors	69 70 70 70 76 76 76 79
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.1 6.1.2	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Living Doors Central locking system	69 70 70 76 76 76 79 79
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43 During the journey 47	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.1 6.1.2 6.1.3	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Living Doors Central locking system Living area door, outside	69 70 70 76 76 79 79 79 80 80
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14 3.15 4	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43 During the journey 47 Driving 47	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.1 6.1.2 6.1.3	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Living Doors Central locking system Living area door, outside Living area door, outside Driver's door, outside	69 70 70 76 76 79 79 79 80 81
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43 During the journey 47 Driving 47 Breakdown assistance in the	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.1 6.1.2 6.1.3 6.1.4	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Living Doors Central locking system Living area door, outside Living area door, inside Driver's door, inside	69 70 70 76 76 79 79 79 80 81
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14 3.15 4	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43 During the journey 47 Driving 47 Breakdown assistance in the event of vehicle-related	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Living Doors Central locking system Living area door, outside Living area door, inside Driver's door, inside Garage door with central	69 70 70 76 76 79 79 79 80 81
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14 3.15 4 4.1 4.2	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43 During the journey 47 Driving 47 Breakdown assistance in the event of vehicle-related technical problems 48	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Living Doors Central locking system Living area door, outside Living area door, inside Driver's door, inside Garage door with central locking system	69 70 70 76 76 79 79 79 80 81
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14 3.15 4 4.1 4.2	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43 During the journey 47 Breakdown assistance in the event of vehicle-related technical problems 48 Driving speed 49	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Living Doors Central locking system Living area door, outside Living area door, inside Driver's door, outside Driver's door, inside Garage door with central locking system Insect screen on the living	69 70 70 72 76 79 79 80 81
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14 3.15 4 4.1 4.2	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43 During the journey 47 Breakdown assistance in the event of vehicle-related technical problems 48 Driving speed 49 Air suspension 49	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Doors Central locking system Living area door, outside Living area door, inside Driver's door, outside Driver's door, inside Garage door with central locking system Insect screen on the living area door, extendable	69 70 70 76 76 79 80 81 81
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14 3.15 4 4.1 4.2	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43 During the journey 47 Breakdown assistance in the event of vehicle-related technical problems 48 Driving speed 49	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Living Doors Central locking system Living area door, outside Living area door, inside Driver's door, outside Driver's door, inside Garage door with central locking system Insect screen on the living area door, extendable External flaps	69 70 70 76 76 79 79 79 80 81 81
3.4 3.5 3.6 3.6.1 3.6.2 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14 3.15 4 4.1 4.2	Towing 37 Caravan coupling 37 Entrance steps 38 Entrance step 38 Driver's door step 39 Electrically heated windscreen 39 Multimedia system (Mercedes) 40 TV unit 40 Thitronik WiPro III alarm system 40 Sink cover 42 Gas regulator 42 Snow chains 43 Manufacturer service for original appliances and original built-in parts 43 Road safety 43 During the journey 47 Breakdown assistance in the event of vehicle-related technical problems 48 Driving speed 49 Air suspension 49	5.2 5.3 5.4 5.5 5.6 5.6.1 5.6.2 5.7 5.8 5.9 5.10 6 6.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6	Ramps Wheel chock Rear area lighting Supports General instructions Steady legs Hydraulic steady legs 230 V connection Refrigerator Awning Doors Central locking system Living area door, outside Living area door, inside Driver's door, outside Driver's door, inside Garage door with central locking system Insect screen on the living area door, extendable	69 70 70 76 76 79 79 79 80 81 81

Contents



6.4	Windows85	7.4	External gas connection	126
6.4.1	Front passenger's window86	7.5	Gas bottle compartment pull-out	
6.4.2	Hinged window with	7.6	Gas bottle compartment	128
	automatic hinges86	7.7	Gas pressure regulating system	
6.4.3	Hinged roof window with rotary		DuoControl CS	129
	window supports89	7.8	Gas filter	132
6.4.4	Roman shade and insect screen90	7.9	Changing gas bottles	133
6.4.5	Roman shades for driver's window	_		
	and front passenger's window91	8	Electrical system	
6.4.6	Roman shade for windscreen,	8.1	General safety instructions	
	driver's window and front	8.2	Terms	
	passenger's window91	8.3	Bluetooth connection	
6.5	Skylights92	8.4	12 V power supply	
6.5.1	Skylight with crank handle (KLAKU)93	8.4.1	USB socket	
6.5.2	Hinged skylight94	8.4.2	Starter battery	138
6.5.3	Wind-up skylight95	8.4.3	Living area battery	400
6.5.4	Skylight with fan96	0.4.4	(HYMER Smart Battery System)	139
6.6	Rotating seats98	8.4.4	Energy balance of the living	4.40
6.7	Storage spaces98	0.45	area battery	
6.7.1	Floor storage compartment99	8.4.5	Retrofitting an AC converter	
6.8	Multifunctional sideboard100	8.5	Transformer/rectifier (EBL 402)	
6.9	Seat belt cover101	8.6	Panel (LT 94)	147
6.10	Tables	8.6.1	Switching the 12 V power supply	4.40
6.10.1	Lift-off table with release button 102	0.00	on/off	
6.10.2	Table with extendable table top102	8.6.2	Battery voltage display	
6.10.3	Table with pillar table leg104	8.6.3	Displaying the tank level	
6.10.4	Suspension table with separable	8.6.4	Alarms	
0.40.5	support leg	8.7	7" panel	
6.10.5	Folding worktop	8.8 8.9	HYMER Connect App	
6.11	TV unit	8.10	System Control Unit (SCU)	
6.11.1	Satellite unit with automatic antenna	8.11	AC converter (MSI 1812T)230 V power supply	
6.12	alignment (Oyster)	8.11.1	230 V connection	131
6.12.1	Lighting109 Lamps in driver's cabin109	0.11.1	(CEE socket outlet)	157
6.12.1	Lamps with two operating levels 110	8.11.2	Connecting the 230 V power supply	
6.13	Beds110	8.12	Solar installation	
6.13.1	Pull-down bed, mechanically	8.13	Fuses	
0.15.1	operated110	8.13.1	12 V fuses	
6.13.2	Rear bed (if a flat screen is fitted	8.13.2	Positions of fuses	
0.10.2	(optional equipment))112	8.13.3	230 V fuse	
6.13.3	Pull-down bed,	0.10.0	200 V 1000	
0.10.0	electrically operated113	9	Appliances	165
6.13.4	Queen size bed in the rear,	9.1	General	
00	mechanically height-adjustable 115	9.2	Heater and boiler	
6.13.5	Protective panel / fall out protection 117	9.2.1	Heating properly	
6.13.6	Width extension of rear bed	9.2.2	Gas hot-air heater and boiler with	
6.13.7	Lying surface extension of rear		CP plus digital operating unit	168
	single bed (XXL bed)120	9.2.3	Hot-air heater and boiler Truma	
6.13.8	Conversion of L-seating group and		Combi D with digital CP plus	
	individual seat into additional bed 120		digital control unit	174
6.13.9	Conversion of divan and individual	9.2.4	Alde hot-water heater and boiler	
	seat into additional bed121	9.2.5	Rear garage hot-water heater	
		9.2.6	Wall flue	
7	Gas system123	9.3	Truma Aventa air conditioning unit	
7.1	General instructions123	9.3.1	Operation and display on the unit	
7.2	Gas bottles124		• •	
7.3	Gas isolator taps			



9.4	Cooker	192	11.8	Water system	229
9.4.1	Gas cooker	192	11.8.1	Cleaning the water tank	229
9.4.2	Cooker with gas grill and gas oven		11.8.2	Cleaning the water pipes	229
	(optional equipment)	194	11.8.3	Disinfecting the water system	230
9.5	Refrigerator	198	11.8.4	Cleaning the waste water tank	230
9.5.1	Refrigerator ventilation grill		11.9	Skylight with fan	231
	(optional equipment)	198	11.10	Care for vehicle operation in winter.	231
9.5.2	Thetford model range N3000 E/A		11.11	Lay-up	
9.5.3	Refrigerator door locking		11.11.1	Temporary lay-up	
	mechanism	202	11.11.2	Recommendation for long periods	
				of inactivity of motorhomes	
10	Sanitary fittings	203		(Mercedes-Benz)	232
10.1	Water supply, general	203	11.11.3	General/over winter lay-up	
10.2	Water system		11.11.4	Activating the vehicle's	
10.2.1	Water tank			hibernation mode	236
10.2.2	Filling the water system	205	11.11.5	Starting up the vehicle after a	
10.2.3	Topping up the water			temporary lay-up or after lay-up	
10.2.4	Reducing the water quantity for			over winter	236
	mobile operation	207	11.12	Setting up the vehicle	
10.2.5	Draining water			2 9 - F	
	(safety drainage rotary handle)	207	12	Customer service and	
10.2.6	Emptying the water system			maintenance	. 239
10.3	Water filter (optional)		12.1	Service and sales partners	
10.4	Waste water tank		12.2	Official inspections	
10.5	Bathroom		12.3	Inspection work	
10.6	Toilet		12.4	Maintenance work	
10.6.1	Swivel toilet		12.5	Lubricating the rear axle	
10.6.2	Toilet with fixed seat		12.6	Changing the filter pad of the	241
10.6.3	Emptying the sewage container		12.0	gas filter	2/1
10.6.4	Electrical ventilation system		12.7	Alde hot-water heater	
10.6.5	Winter operation		12.7.1		
10.6.6	Temporary lay-up		12.7.1	Changing the heating fluid	
10.7	Installation positions		12.7.2	Checking the fluid level Topping up heating fluid	
10.7	motanation positions	2 . 7	12.7.3	Bleeding the heating system	
11	Care	219	12.7.4	Cooker/oven/refrigerator	
11.1	General		12.8.1	<u> </u>	
11.2	External care			Refrigerator	
11.2.1	Washing with a high-pressure	210	12.9	Changing windscreen blade	
	cleaner	219	12.10	Replacing bulbs, external	
11.2.2	Washing the vehicle		12.10.1	Front lights	
11.2.3	Windows of acrylic glass		12.10.2	Rear lights	
11.2.4	Add-on parts made of glass-fibre	220	12.10.3	Side lights	
	reinforced plastic (GRP)	221	12.10.4	Types of bulbs for exterior lighting	
11.2.5	Underbody		12.11	Lighting for living area	
11.2.6	Engine compartment		12.12	Air suspension	
11.2.7	Windscreen washer system and	22 1	12.13	Electrical ventilation system	
11.2.7	windscreen wipers	222	12.14	Spare parts	
11.2.8	Air conditioning unit		12.15	Vehicle identification plate	253
11.2.9	Entrance step		12.16	Vehicle identification plate on	054
11.3	Interior care		40.47	the chassis	
11.4	Wall covering, inside (Renolit)		12.17	Warning and information stickers	
11.5	Kitchen installation		12.18	Replacement keys	254
11.5.1	General notes on care		10	Whoole and tures)EE
11.5.1	Refrigerator		13	Wheels and tyres	
11.5.2	Stainless steel surfaces		13.1	General	
11.7			13.2	Tyre selection	
11.7	Cushions	∠∠1	13.3	Tyre specifications	
			13.4	Handling of tyres	25/

Contents



B-MC I/T - 04/24-1 - EHG-0016-04EN

13.5	Spare wheel	257	14.10	Refrigerator	270
13.6	Repair kit		14.10.1	General	
13.7	Changing wheels		14.11	Water supply	
13.7.1	General instructions		14.12	Body	
13.7.2	Tightening torque		2	20dy	270
13.7.3	Changing a wheel		15	Optional equipment	275
13.7.4	Changing a wheel with alloy	200	15.1	Weight details for optional	
13.7.4	wheel rims	260	10.1	equipment	275
13.8	Tyre pressure			oquipinont	270
13.0	Tyre pressure	201	16	Technical data	277
14	Troubleshooting	263	16.1	Technical data	
14.1	Braking system		16.2	Dimensions and permissible	211
14.1	Air suspension		10.2	number of persons	277
	•			number of persons	∠11
14.3	Skylight		17	Instructions for the	
14.4	Electrical system		17		
14.5	AC converter	266		service partner	279
14.6	Gas system	266		•	
14.7	Cooker		18	Legal notes on weight-	
14.8	Heater/boiler	267		related information	281
14.8.1	Heater/boiler with CP plus digital				
	operating unit	267	Index		285
14.8.2	Alde heater/boiler		IIIGOA		200
14.9	Air conditioning unit				

6



Observe the following instructions before first journey of the vehicle:



- ▶ Re-tighten the wheel nuts/wheel bolts after 50 km (30 miles).
- Read the instruction manual to avoid personal and material damage.

Observe the following instructions before each journey of the vehicle:



- Check the tyre pressures.
 - See Tyre pressure section.
- ► Load the vehicle correctly. Observe the technically permissible maximum laden mass.

See Payload section.

- ► Fully charge batteries before each journey. See Starter battery and Living area battery sections.
- ► In case of external temperatures below 0 °C first heat vehicle, then fill water system.

See Water supply/Filling the water tank section.

- ► Gas bottles are only to be transported within the designated gas bottle compartment.
- ► Keep forced ventilations clear.
 See Skylights and Ventilation sections.
- Before filling the vehicle with fuel switch off gas-operated appliances.

If there is any risk of frost, observe the following instructions:



- ► If there is any risk of frost, always heat the vehicle. See Heater section.
- ▶ If the vehicle is not being used when there is risk of frost, empty the entire water system. Make sure that the 12 V power supply on the panel is switched off. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave all drain cocks open. This will avoid frost damage to appliances and to the vehicle.

See Emptying the water system section.





Please read this instruction manual completely before using the vehicle for the first time!

Always keep this instruction manual in the vehicle. Also inform all other users of the safety regulations.



▶ The non-observance of this symbol can lead to personal injury.



The non-observance of this symbol can lead to damage being caused to, or inside the vehicle.



This symbol indicates recommendations or special aspects.



> This symbol indicates actions which lead to environmental awareness.

This instruction manual contains sections which describe model-specific equipment or optional equipment. These sections are not specially marked. It may be that your vehicle has not been fitted with this optional equipment. In some cases, the actual equipment of your vehicle may therefore be different from that shown in some illustrations and descriptions.

However, your vehicle may be fitted with other optional equipment not described in this instruction manual.

Optional equipment is described when an explanation is required.

Adhere to the instruction manuals which are separately enclosed.



- The details "right", "left", "front" and "rear" always refer to the vehicle in direction of travel.
- > All dimensions and weight details are "approximate".

Should the vehicle be subjected to damage due to a failure to follow the instructions in this instruction manual, then the warranty claim is deemed invalid.

Our vehicles are subjected to continuous development. Please understand that we reserve the right to alter the form, equipment and technology. Therefore, no claims can be made against the manufacturer as a result of the contents of this instruction manual. The equipment which was known and included at the time of going to press is described.

The reprinting, translation and copying, including extracts is not permitted without prior written authorisation from the manufacturer.



1.1 General

The vehicle is constructed in accordance with the latest technology and the recognised safety regulations. Nevertheless, personal injury may result and the vehicle may be damaged if the safety instructions in this instruction manual are not followed.

Before using the vehicle for the first time, equip it with the legally prescribed equipment (e.g. first aid kit, warning vest, hazard warning triangle etc.). Observe the relevant equipment regulations when travelling abroad.

Only use the vehicle in a technically impeccable condition. Follow the instructions in the instruction manual.

Malfunctions which impair the safety of persons or the vehicle should be immediately remedied by qualified personnel. To avoid further damages, observe the duty to avert, minimise or mitigate loss for the user during faults.

Have the vehicle's braking and gas systems inspected and repaired by an authorised specialist workshop only.

Alterations to the body are only to be carried out with the authorisation of the manufacturer.

The vehicle is designed for the exclusive transport of persons. Luggage and accessories may only be transported up to the maximum permissible gross weight.

Observe the test and inspection periods stipulated by the manufacturer.

1.2 Environmental tips



- Be considerate of the environment.
- Remember that: All kinds of waste water and household waste are not to be disposed of in drains or in the open countryside.
- On board, collect waste water only in the waste water tank or if necessary in other containers designed for that purpose.
- Only empty the waste water tank and sewage container at disposal stations, camping sites or caravan sites provided especially for this purpose. When stopping in towns and communities, observe the instructions at caravan sites or ask where there are disposal stations.
- Empty waste water tank as often as possible, even when it is not completely full (hygiene).
 - If possible, flush out waste water tank and, if necessary, drainage pipe with fresh water every time it is emptied.
- Never allow the sewage container to become too full. Empty the sewage container frequently, at the latest as soon as the filling level indicator lights up.
- Separate household waste according to glass, tin cans, plastic and wet waste also when on a journey. Enquire at the town or community authority about disposal points. Household waste is not to be disposed of in waste paper baskets which are situated at car parks.
- ▷ Empty waste bins as often as possible into the containers provided for this purpose. This helps to avoid unpleasant smells and an accumulation of rubbish on board.





- When parked, do not allow the engine to run more than necessary. When running idle, a cold engine releases more contaminants than usual. The running temperature of the engine is achieved more quickly whilst the vehicle is in motion.
- Use an environmentally-friendly WC chemical agent for the WC which can also be biologically degraded and only use small doses.
- When staying in towns and communities for long periods, search for parking areas which are specially reserved for motorhomes. Enquire at the town or community authority about parking spaces.
- Always leave the parking places in a clean condition.



12



Chapter overview

This chapter contains important safety instructions. The safety instructions are for the protection of persons and property.

2.1 Fire prevention

2.1.1 Avoidance of fire risks



- ▶ Never leave children in the vehicle unattended.
- ▶ Keep flammable materials clear of heating and cooking appliances.
- ▶ Never use portable heating or cooking appliances.
- ▶ Only authorised qualified personnel may make changes to the electrical system, gas system or appliances.

2.1.2 Fire-fighting



▶ Please inform yourself about the country- and location-specific requirements for firefighting in the place where you are staying and keep the required tools on hand.

2.1.3 In case of fire



- Evacuate all passengers.
- Cut off the electrical power supply and disconnect from the mains.
- Close the regulator tap on the gas bottle.
- Sound the alarm and call the fire brigade.
- Fight the fire if this is possible without risk.



- Acquaint yourself with the position and operation of the emergency exits.
- ▷ Observe the fire extinguisher instructions for use.



2.2 General



- Do not fix any objects to the double floor of the vehicle. Do not drill any holes into the double floor nor perform any other interventions. Such activities change the statics of the vehicle and may endanger its safety. All warranty obligations will lapse in the event of an infringement.
- ▶ The oxygen in the vehicle interior is used up by breathing and the use of gas operated appliances. That is why the used air must be replaced permanently. For this purpose, forced ventilation options (e.g. skylights with forced ventilation, mushroom-shaped vents or floor vents) are fitted to the vehicle. Never cover or block forced ventilations from the inside or outside with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves. There is a danger of suffocation due to increased CO₂ levels.
- Do not use storage spaces or rear garages as places for people or animals to stay or sleep in. These spaces are not forced-air ventilated. There is a danger of suffocation due to oxygen deprivation or exhaust from the heater.
- Observe the headroom of the doors.



- As far as the fitted appliances (heater, cooker, refrigerator, etc.) and the base vehicle (engine, brakes, etc.) are concerned, the instruction manuals are authoritative. It is imperative that they be observed.
- Fitting accessories or special equipment can alter the dimensions, weight and road behaviour of the vehicle. Some of the add-on parts must be entered in the vehicle documents.
- Only use wheel rims and tyres which are approved for the vehicle. Information concerning the size of the approved wheel rims and tyres is included in the vehicle documents or can be obtained from authorised dealers and service centres.
- > Firmly apply the handbrake when parking the vehicle.
- If the maximum permissible gross weight of the vehicle exceeds 4 tonnes, a wheel chock must be used when parking on gradients. The wheel chock is provided as standard for vehicles with a maximum permissible gross weight exceeding 4 tonnes.



- When leaving the vehicle, it is imperative that all doors, external flaps and windows are closed.
- Always carry the legally prescribed equipment (e.g. first aid kit, warning vest, hazard warning triangle etc.) with you. The regulations of the host country apply when travelling abroad.
- The vehicle may only be driven by drivers who hold a driving licence which is valid for the respective vehicle class.
- When selling the vehicle, hand over all instruction manuals for the vehicle and the fitted appliances.



2.3 Road safety



- ▶ Before commencing the journey, carry out a functional check of indicating and lighting equipment, the steering and the brakes.
- ▶ If the vehicle has been stationary for a long period (approx.
 10 months) have the braking and gas systems checked by an authorised specialist workshop.
- ▶ Before commencing the journey and after short interruptions of the journey, ensure that the entrance step is completely retracted.
- ▶ Before commencing the journey, secure the pull-down bed.
- Before commencing the journey, open, lock and secure the shades situated on the windscreen and on the driver's and front passenger's windows.
- ▶ Before commencing the journey, rotate all swivel seats in the direction of travel and lock in position. During the journey, the swivel seats must remain locked in place in the direction of travel.
- Carefully store all moving parts and all loose objects before starting your journey.
- ▶ Before commencing the journey, secure the television.
- ▶ Before commencing the journey, remove the loose sink cover (if present) and store it securely in the kitchen unit or wardrobe.
- ▶ During the journey, persons are only to sit on the permitted seats (see chapter 4). The authorised number of seats is stipulated in the vehicle documents.
- Seat belts must be worn by all passengers.
- ▶ When travelling, secure children under 13 years of age that are smaller than 150 cm, with a suitable and officially approved child restraint system.
- ▶ Only attach the child restraint system to seats that are specified for this purpose. We strongly recommend to install child restraint systems preferably in the second row of seats.
- ► Never use rearward-facing child restraints on a seat with activated front airbag. This may lead to death or to serious injuries in children.
- ► The base vehicle is a commercial vehicle (small truck). Adjust your driving technique accordingly.
- ► In the case of subways, tunnels or similar, observe the overall height of the vehicle (including roof loads).
- ▶ In winter, the roof must be free of snow and ice before commencing the journey.
- ► Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle (see section 13.8).
- ▶ Do not operate the heater at petrol stations. Danger of explosion!
- ▶ Do not operate the heater in closed spaces. Danger of suffocation!





- ▷ Before commencing the journey, distribute the payload evenly within the vehicle (see chapter 3).
- When loading the vehicle and during breaks in the journey, e.g. when reloading luggage or food, observe the technically permissible maximum laden mass and the technically permissible maximum laden mass on the axle (see the vehicle documents).
- ▷ Before commencing the journey, close and lock, if possible, all inner doors, adjustable partition walls, drawers and flaps. Let the refrigerator door securing device snap into place.
- ▷ Before commencing the journey, close windows and skylights.
- ▷ Before commencing the journey, close all external flaps and lock them.
- ▷ Before commencing the journey, remove the external supports and retract the corner steadies or steady legs, which are fitted to the vehicle.
- ▷ Before commencing the journey, put the antenna in park position.
- During the initial journey and each time after changing a wheel, retighten the wheel bolts/wheel nuts after 50 km (30 miles). Subsequently inspect them at regular intervals in order to ensure that they are firmly seated. See chapter 13for tightening torque.
- > Tyres must not be older than 6 years as the material becomes brittle over time (see chapter 13).
- When using snow chains, the tyres, wheel suspension and steering are subjected to an additional load. When using snow chains, drive slowly (maximum speed 50 km/h) and only on streets which are completely covered with snow. Otherwise the vehicle could be damaged.

2.4 Towing



- Care is to be taken when connecting and detaching a trailer. Risk of accident and injury!
- ▶ No persons are to be between the motorhome and the trailer during positioning for connecting and detaching.

2.5 Gas system

2.5.1 General instructions



- ► The operator of the gas system is responsible for the performance of recurring inspections and for complying with the maintenance intervals.
- ▶ If there is no DuoControl regulating system with crash sensor installed: Before commencing the journey, when leaving the vehicle or when the gas devices are not in use, close all gas isolator taps and the main regulator tap on the gas bottle.
 - If there is a DuoControl regulating system with crash sensor installed, the gas isolator taps and the main regulator tap may remain open during the journey.
- ► All gas-operated devices (heater, cooker, oven, grill, refrigerator depending on the equipment) must be switched off for refuelling, on ferries or in the garage. Danger of explosion!

16





- ▶ Do not use gas-operated devices in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- Only have the gas system maintained, repaired or altered by an authorised specialist workshop.
- ▶ Have the gas system checked by an authorised specialist workshop according to the national regulations before commissioning. This also applies for not registered vehicles. For modifications to the gas system have the gas system immediately checked by an authorised specialist workshop.
- ▶ The gas pressure regulator, the gas tubes, and the exhaust gas pipes must also be inspected. The gas pressure regulator and the gas tubes must be replaced observing the nationally defined deadlines (the latest after 10 years). The vehicle owner is responsible for seeing that this is carried out.
- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.). Check the tightness of gas-conducting parts and lines with leakage search spray. Do not check with an open flame.
- Only the stipulated devices may be connected to internal connections. Do not operate any device outside the vehicle if it is connected to an internal connector.
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open a window or the skylight.
- ► Cooking is prohibited during the journey.
- ▶ Do not use gas-operated cooking and baking facilities for heating purposes.
- ▶ If there are several gas devices, each gas device must have its own gas isolator tap. If individual gas devices are not in use, close the respective gas isolator tap.
- ▶ Ignition safety valves must close within 1 minute after the gas flame has extinguished. A clicking sound is audible. Check function from time to time.
- ▶ The built-in gas devices are exclusively meant for use with propane or butane gas or a mixture of both. The gas pressure regulator as well as all built-in gas devices are designed for a gas pressure of 30 mbar.
- ▶ Propane gas is capable of gasification up to -42 °C, whereas butane gas gasifies at 0 °C. Below these temperatures no gas pressure is available. Butane gas is unsuitable for use in winter.
- ▶ Due to its function and construction, the gas bottle compartment is a space which is open to the exterior. Never cover or block up the standard forced ventilations. Otherwise gas that is emitted can not be diverted to the outside.
- ▶ The gas bottle compartment must not be used as storage space.
- Secure the gas bottle compartment against unauthorised access. To do this, lock the compartment.
- ▶ The regulator tap on the gas bottle must be accessible.





- Only connect gas-operated devices which have been designed for a gas pressure of 30 mbar.
- ► The exhaust gas pipe must be fitted tightly to the heating system and to the vent and must be sealed. The exhaust gas pipe must not show any evidence of damage.
- ► Exhaust fumes must be able to escape into the atmosphere unhindered and fresh air must be able to enter unhindered. For this reason, keep the exhaust pipe and intake openings clean and unobstructed (e.g. free from snow and ice). For this reason, no snow walls or aprons may lie against the vehicle.

2.5.2 Gas bottles



- ► Handle full or emptied gas bottles outside the vehicle only with closed regulator tap and attached protective cap.
- ► Gas bottles are only to be transported within the designated gas bottle compartment.
- Place the gas bottles in vertical position in the gas bottle compartment.
- ► Fasten the gas bottles so that they are unable to turn or tilt.
- Connect the gas tube to the gas bottle without tension.
- ▶ If the gas bottles are not connected to the gas tube, always place the protective cap on top.
- ► Close the regulator tap on the gas bottle before the gas pressure regulator or gas tube are removed from the gas bottle.
- ▶ Depending on the connection, unscrew the gas tube from the gas bottle and screw it on the gas bottle again by hand or using an suitable special spanner. The screw connection on the gas bottle generally has a left-hand thread. Do not tighten too firmly.
- Only use special gas pressure regulators with a safety valve designed for vehicle use. Other gas pressure regulators are not permitted and cannot meet the demanding requirements.
- ► Use the gas pressure regulator defroster (EisEx) if the temperature falls below 5 °C.
- ▶ Use only 11 kg or 5 kg gas bottles. (The size of the gas bottles may vary depending on the country.)
- ▶ Use the shortest possible tube lengths (150 cm max.) for external gas bottles.
- Never block the floor ventilation openings below the gas bottles.



2.6 Electrical system



- ▶ Only allow qualified personnel to work on the electrical system.
- Prior to carrying out work on the electrical system, switch off all devices and lights, disconnect the battery and disconnect the vehicle from the mains.
- ▶ Only use original fuses with the stipulated values.
- Only replace defective fuses when the cause of the defect is known and has been remedied.
- Never bridge or repair fuses.

2.7 Water system



- ➤ Water left standing in the water tank or in the water pipes becomes undrinkable after a short period. Therefore, before each use of the vehicle, thoroughly clean the water pipes and the water tank. After each use of the vehicle completely empty the water tank and the water pipes.
- ▶ In the case of lay-ups lasting more than a week, disinfect the water system before using the vehicle (see section 11.8.3).



If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Make sure that the 12 V power supply on the panel is switched off. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.





Chapter overview

This chapter contains important information which has to be noted before commencing your journey or carrying out any tasks before the journey.

At the end of the chapter there is a checklist which once again summarises the most important points.

3.1 **Initial start-up**



During the initial journey and each time after changing a wheel, retighten the wheel bolts/wheel nuts after 50 km (30 miles). Subsequently inspect them at regular intervals in order to ensure that they are firmly seated. See chapter 13 for tightening torque.

The motorhome is supplied with a set of keys, consisting of keys for the base vehicle and keys for the body.

Always deposit a replacement key outside the vehicle. Make a note of the key number. Our authorised dealers and workshops can offer assistance in case of loss.

Further information in chapter 12.

When starting up for the first time or after a lay-up, the electrical system must be started up as follows:

- Switch on the fuses or (if the fuses have been pulled out) insert the fuses.
- Set battery cut-off switch to on.
- Switch 12 V power supply on.



- The 12 V power supply must only be switched on in vehicles without SCU (System Control Unit). On vehicles with SCU, the 12 V power supply is activated automatically.
- The vehicle is not ready for operation until the above measures have been carried out.

3.2 Vehicle load capacity



- Overloading the vehicle and the axles may result, for example, in a diminished steering response (altered driving behavior), an overloading of the tires, and, as a result, an increased risk of tire blowouts or an extended braking distance. This may cause you to lose control of the vehicle, endangering yourself and other road users. If you are not sure whether the loaded vehicle complies with the technically permissible maximum laden mass, you can weigh/check the vehicle on public scales or have it weighed by certain dealers.
- The vehicle documents state the technically permissible maximum laden mass or the mass including optional equipment ex works (actual vehicle mass), but not the weight of the laden vehicle (see section 3.2.1). For your own safety, we recommend that you have your loaded vehicle (with all passengers, luggage and personal objects) weighed on a public weighbridge before you set out on your journey.
- Adapt the speed to the payload. The stopping distance is increased if the payload is high.





- Do not exceed the technically permissible maximum laden mass and the technically permissible maximum laden mass on the axle as stated in the vehicle documents by the payload.
- On loading, make sure that the payload's centre of gravity is as low as possible (directly above the floor of the vehicle). Otherwise this may affect the driving characteristics of the vehicle.



▷ If you drive the vehicle even though it exceeds the technically permissible maximum laden mass specified by the manufacturer, you may face legal consequences, such as a fine or loss of insurance.

3.2.1 Terms



Technically speaking, the term "mass" has now replaced the term "weight". However, "weight" is still the term more frequent in common use. For better understanding, "mass" is therefore only used in the following sections for fixed formulations.

Technically permissible maximum laden mass

The technically permissible maximum laden mass is a value specified by the manufacturer that, for safety reasons, the vehicle must never exceed, even when loaded (e.g. 3500 kg). Information on the technically permissible maximum laden mass of the model you have chosen can be found in the registration papers and on the body manufacturer's nameplate in the vehicle.




Fig. 1 Nameplate

- 1 Vehicletype
- 2 Consecutive serial number
- 3 Manufacturer
- 4 Vehicle type approval
- 5 Body stage
- 6 Chassis number
- 7 Technically permissible maximum laden mass
- 8 Permissible total towing mass (with caravan coupling option)
- 9 Technically permissible maximum laden mass on axle 1
- 10 Technically permissible maximum laden mass on axle 2

The technically permissible maximum laden mass consists of the **actual vehicle mass** and the **payload**.

In the vehicle documents, the manufacturer has specified the technically permissible maximum laden mass.

Actual vehicle mass

The actual vehicle mass consists of the mass in running order and the weight of the optional equipment fitted at the factory.



Mass in running order

The mass in running order is the weight of the ready-to-drive series vehicle (excluding optional equipment fitted at the factory).

The mass in running order is made up as follows:

- Unladen weight (mass of the empty vehicle) with factory-installed standard equipment (excluding optional equipment fitted at the factory)
- Driver's weight
- Basic equipment weight
- Greases, oils and cooling liquids filled in
- Fresh water tank filled up to 100 %
- Aluminium gas bottle filled up to 100 %
- Fuel tank filled to 90 %

75 kg are calculated for the weight of the driver, regardless of how much the driver really weighs.

Basic equipment includes all equipment and fluids required for safe and proper vehicle use. The weight of the basic equipment includes:

- A full fresh water system
- A full heating system
- The power cables for the 230 V power supply
- A full toilet flushing system
- The installation kit for an auxiliary battery if an auxiliary battery can be used

The waste water tank and the sewage container are empty.

Example for calculating the basic equipment

Water tank with 20 I (during the journey)	20 kg
Gas bottle (11 kg _{gas} + 14 kg _{bottle})	+ 25 kg
Boiler with 12 I	+ 12 kg
230 V power cable	+ 4 kg
Installation kit for auxiliary battery	+ 20 kg
Total	= 81 kg

The mass in running order and the actual vehicle mass are specified by the manufacturer in the vehicle documents.

Remaining load capacity

To determine the remaining load capacity, it is important that you know the actual weighed mass of your vehicle. Upon completion of your vehicle, therefore, we determine the actual weight of your vehicle for the first time by weighing it at the end of the line. This includes the mass in running order plus the weight of all ordered and factory-fitted optional equipment.

You can use this actual weighed mass to calculate the remaining load capacity for baggage or other accessories.

Example:

Technically permissible gross weight	-	actual weighed mass	-	mass of the passengers	=	remaining load capa- city
3500 kg	-	3000 kg	-	225 kg (3 x 75 kg)	=	275 kg





- Please note that the factory calculation of the remaining load capacity for the mass of the driver (included in the actual weighed mass) and the mass of the passengers is based on a generalized mass of 75 kg per seat. Due to deviating body weights, however, the actual remaining load capacity of your vehicle may vary.
- The actual factory-weighed mass of your vehicle may vary slightly afterwards due to weather conditions and, for example, the associated absorption or release of moisture. Any further subsequent modification of your vehicle, e.g. through the additional installation of accessories by the dealer or other attachments and/or conversions, will additionally influence the actual weighed mass of the vehicle communicated and consequently also the remaining load capacity. It is the responsibility of the dealer after picking up the vehicle at the factory until delivery, and subsequently your responsibility from the time of handover by the dealer, to ensure that the technically permissible maximum laden mass is not exceeded. If you are not sure whether the loaded vehicle complies with the technically permissible maximum laden mass, you can weigh/check the vehicle on public scales or have it weighed by certain dealers.
- We will inform your dealer of the actual weighed mass of your vehicle and the remaining load capacity when we issue the invoice. Your dealer is required to pass on the information to you. If you have not received this information, you can contact your dealer and request it. Our scales meet all legal and standard requirements and are regularly maintained, tested and, calibrated. Nevertheless, a slight tolerance is technically unavoidable. Moreover, the weight of the vehicle may vary slightly due to weather conditions and, for example, the associated absorption or release of moisture. The actual weight of the vehicle may therefore deviate from the actual weight communicated by a few kilograms.

The payload is made up as follows:

- Conventional load
- Optional equipment
- Personal equipment



The vehicle load capacity can be increased by reducing the actual weight. To do this, it is allowed for example to empty the fluid containers or to remove the gas bottles.

You will find explanations on the individual components of the payload in the following text.

Conventional load

The conventional load is the weight specified by the manufacturer for the passengers.

Conventional load means: 75 kg are calculated for every seat specified by the manufacturer, regardless of how much the passengers actually weigh. The driver's seat is already included in the mass in running order and must not be counted.

In the vehicle documents, the manufacturer specifies the number of seats.



Optional equipment

Optional equipment includes all equipment not included in the standard equipment which is fitted to the vehicle under the responsibility of the manufacturer.

- Caravan coupling
- Bike or motorcycle rack
- Satellite unit

Chapter 15 lists the weights of the various items of optional equipment; they may also be obtained from the manufacturer.

Personal equipment

Personal equipment includes all items carried in the vehicle that are not included in the conventional load and optional equipment. For example, personal equipment can include the following:

- Foodstuffs
- Crockery
- Television
- Radio
- Clothes
- Bedding
- Toys
- **Books**
- **Toiletries**

No matter where kept, personal equipment also includes:

- **Animals**
- **Bikes**
- **Boats**
- Surfboards
- Sports equipment

For the personal equipment, according to the applicable regulations, the manufacturer must use a minimum weight that is determined according to the following formula:

Formula

Minimum weight M (kg) = $10 \times N + 10 \times L$

Explanation

N = maximum number of people including the driver, as stated by the manufacturer

L = total length of the vehicle in metres



3.2.2 Calculating the vehicle load capacity



- ▶ Never exceed the technically permissible maximum laden mass!
- ▶ The technically permissible maximum laden mass and the weight including optional equipment fitted at the factory (actual mass) is shown in the vehicle documents, but not the weight of the laden vehicle (see section 3.2.1). For your own safety, we recommend that you have your loaded vehicle (with all passengers, luggage and personal objects) weighed on a public weighbridge before you set out on your journey.

The vehicle load capacity (see section 3.2.1) is the difference in weight between

- the technically permissible maximum laden mass and
- the actual vehicle mass.

Example for calculating the vehicle load capacity

	Mass in kg to be calculated	Calculation
Technically permissible maximum laden mass according to vehicle documents	3500	
Actual vehicle mass including standard equipment according to the vehicle documents	- 3070	
This results in a permissible load capacity of	430	
Flat-rate value of 10 kg per meter vehicle length (in the example: 7.00 m)	- 70	
Conventional load e.g.: 3 persons each weighing 75 kg	- 225	
Optional equipment and accessories	- 40	
For the personal pay-mass this results in	= 95	

The pay-mass is calculated based on the regulation (EC) no. 1230/2012.

The calculation of the vehicle load capacity from the difference between the technically permissible maximum laden mass and the actual vehicle mass specified by the manufacturer is however only a theoretical value.

Only if the vehicle is weighed on a public scale with filled tanks (fuel and water), filled gas bottles and complete optional equipment (and accessories) can the actual vehicle load capacity be determined.

To do this, proceed as follows:

- First only drive the vehicle on to the weighbridge with the front wheels and have it weighed.
- Then drive the vehicle on to the weighbridge with the back wheels and have it weighed.

The individual values give the current masses on the axles. These are important for the correct loading of the vehicle (see section 3.2.3). The sum of these values is the current weight of the vehicle.

The actual load capacity is the difference between the technically permissible maximum laden mass and the weighed vehicle weight.

26



This can be used to determine the weight that remains for the personal equipment:

Determine the weight of the passengers and subtract it from the value for the actual vehicle load capacity.

The result is the weight that is permitted for the actual load of the personal equipment.

3.2.3 Load securing and load distribution



- For safety reasons, never exceed the technically permissible maximum laden mass.
- Distribute the load evenly on the left and right sides of the vehicle.
- Distribute the load evenly on both axles. Observe the technically permissible maximum laden mass on the axle specified in the vehicle documents. Observe the permissible load-carrying capacity of the tyres (see chapter 13).
- Heavy loads behind the rear axle can reduce the load on the front axle due to the leverage effect $(\frac{1}{\Omega-\Omega})$. This applies especially to long rear extensions, if a motorbike is transported on the rear carrier or if there is a heavy load in the rear storage space. The release of the front axle negatively affects the driving quality, especially for front-driven vehicles.
- Store all objects in such a way that they cannot slip.
- Store heavy objects (awning, tin cans, etc.) close to the axles. Low-lying storage spaces whose doors do not open in the direction of travel are particularly suited for storing heavy objects.
- Stack light objects (laundry) in the roof storage cabinets.
- Distribute items (loads) evenly in the compartments and cupboards.
- Load the bike rack with bicycles only.



- Only load the drawers with a maximum of 15 kg.
- Do not exceed the maximum loading for roof storage cabinets. The maximum loading per running metre of roof storage cabinet is 10 kg.

When loading, consider the respective length of the roof storage cabinet and calculate the maximum load accordingly.

Example of a 0.5 m long roof storage cabinet:

10 kg maximum loading per running metre x 0.5 m length of the roof storage compartment = 5 kg load is possible.





- Please observe the maximum permissible load of the rear garage or rear storage compartment at all times. The specified maximum permissible load of the rear garage or rear storage compartment may be influenced by the selection of further optional equipment, such as trailer couplings or frame extensions. However, the technically permissible maximum laden mass and the technically permissible maximum laden mass on the axle must not be exceeded under any circumstances. Especially when stowing or attaching heavy accessories or heavily laden accessories (such as motorcycle carriers or bicycle carriers) at the rear, the mass on the axle must be checked and complied with. For this reason, please note that the maximum load may not be fully utilized if this would result in the exceedance of the technically permissible maximum laden mass or technically permissible maximum laden mass on the axle.
- Further information on correct loading can be found in the sections
 "Technically permissible maximum laden mass" (page 22) and "Technically permissible maximum laden mass on the axle (mass on the axle)"
 (page 29).

Large storage compartments also offer room for heavy objects. The mass on the front or rear axle may be exceeded as a result.

However, the individual axles may not be overloaded under any circumstances. That is why it is important, at which distance to the axles the load is stored.

When loading the vehicle, please observe the following instructions to ensure safe driving:

- Baggage and other items carried in the vehicle must be evenly distributed between the left and right sides of the vehicle.
- Heavy or bulky items should be stowed as close to the ground as possible in stowage boxes provided for this purpose and near the axles, and they must be secured against slipping.
- Light and other items can be stowed in lockers and storage compartments.
- Always ensure that the doors and flaps on the cabinets and storage compartments are properly secured.
- Use only suitable clamping systems to secure items against slipping.
 Please recheck all tie-downs before commencing travel.



▶ Uneven loading has a negative effect on driving behavior. A rearheavy load in particular results in a reduction of the load on the front axle due to leverage effects and thus, for example, to a loss of traction, a diminished steering response (altered driving behavior), an overloading of the tires and, as a result, an increased risk of tire blowouts. This may cause you to lose control of the vehicle, endangering yourself and other road users. An evenly distributed load over the entire vehicle leads to optimum driving behavior during travel.



The technically permissible maximum laden mass and the technically permissible maximum laden mass on the axle must not be exceeded. Especially when stowing or attaching heavy accessories or heavily laden accessories (such as motorcycle carriers or bicycle carriers) at the rear, the mass on the axle must be checked and complied with. If you are not sure whether the loaded vehicle complies with the technically permissible maximum laden mass and the technically permissible maximum laden mass on the axle, you can weigh/check the vehicle on public scales or have it weighed by certain dealers.





- For individual models, a maximum load is specified by the body manufacturer for cabinets, drawers, storage compartments, or other storage spaces. This maximum load can be seen on the stickers attached on site and must be observed at all times. However, the technically permissible maximum laden mass and the technically permissible maximum laden mass on the axle must not be exceeded under any circumstances. For this reason, please note that the stated maximum load may not be fully utilized if this would result in the exceedance of the technically permissible maximum laden mass or technically permissible maximum laden mass on the axle.
- For further information on correct loading, please refer to the sections "Technically permissible maximum laden mass" (page 22), "Technically permissible maximum laden mass on the axle (mass on the axle)" (page 29) and "Rear garage/rear storage space" (page 33).

To distribute the load correctly, you will need a scale, a tape measure, a calculator and some time.

Two simple formulas are needed to calculate the effect of the weight of the load on the axles:

Formulas

 $A \times G : R = weight on the rear axle$

Weight on the rear axle -G = weight on the front axle


Explanation

- Α = distance between storage space and front axle in cm
- G = weight of the load in the storage space in kg
- R = wheelbase of the vehicle (distance between axles) in cm



Measure the external distances horizontally from the centre of the front wheel to the centre of the storage space or to the centre of the back wheel.

Technically permissible maximum laden mass on the axle (mass on the axle) The technically permissible maximum laden mass on the axle or group of axles (hereafter referred to as mass on the axle) refers to the vehicle- and axle-specific load that may be transferred from the wheels of an axle or group of axles to the road surface. The mass on the axle is a value specified by the manufacturer that, for safety reasons, the vehicle must never exceed, even when loaded. You will find information on the mass on the axle of your vehicle in the registration papers and on the body manufacturer's nameplate in the vehicle.



Nameplate Fig. 2

- Vehicle type 1
- Consecutive serial number 2
- 3 Manufacturer
- 4 Vehicle type approval
- 5 Body stage
- 6 Chassis number
- Technically permissible maximum laden mass
- 8 Permissible total towing mass (with caravan coupling option)
- 9 Technically permissible maximum laden mass on axle 1
- Technically permissible maximum 10 laden mass on axle 2





▶ If the technically permissible maximum laden mass on the axle is exceeded, the vehicle may be damaged (e.g. due to a broken axle or tire blowout) and driving performance may be considerably impaired. This may cause you to lose control of the vehicle, endangering yourself and other road users. We therefore recommend weighing the final loaded vehicle including all passengers, before commencing travel in order to ensure compliance with the mass on the axle and the technically permissible maximum laden mass at all times. For this purpose, you can weigh/check the vehicle on public scales or have it weighed by certain dealers.



- Please note that the mass on the respective axles or axle groups may differ. For this reason, please read the information provided in the registration papers carefully.
- If you drive the vehicle even though it exceeds the technically permissible maximum laden mass on the axle specified by the manufacturer, you may face legal consequences, such as a fine or loss of insurance.
- ▷ It is possible that the chassis manufacturer of your vehicle specifies a minimum load for the front axle in order to achieve optimum driving behavior. Therefore, please also always observe the information regarding this from the operating instructions of the chassis manufacturer.
- Further information on correct loading, can be found in the sections "Load securing and load distribution" (page 27) and "Rear garage/rear storage space" (page 33).

Calculating masses on the axles:

- Multiply the distance between storage space and front axle (A) with the weight of the load in the storage space (G) and divide the result by the wheelbase (R). The result is the weight of the load in the storage space on the rear axle. Make a note of this weight and of the storage space.
- In a second step, subtract the weight in the storage space (G) from the weight calculated beforehand. If the result is a **positive** value (example 1), this means that the load on the front axle is **reduced** by this value. If the result is a **negative** value (example 2), this means that the load on the front axle is **increased**. Make a note of this value, too.
- Calculate all storage spaces of the vehicle in the same way.
- In a last step, add all weights calculated for the rear axle to the mass on the rear axle and add (or subtract) all weights calculated for the front axle to (or from) the mass on the front axle. How to determine the mass on the rear axle and the mass on the front axle is described in section 3.2.2.

If the calculated value exceeds the permissible maximum laden mass on the axle, the load must be distributed in a different way.

If the load on the front axle is too low, the grip of the tyres on the road is reduced (traction). This applies in particular to vehicles with front-wheel drive. In this case, the load must be redistributed, too.



Example calculation

		Example 1	Example 2
Distance to the front axle	Α	(A1) 450 (cm)	(A2) 250 (cm)
Weight in the storage space	G	x 100 (kg)	x 50 (kg)
Wheelbase of the vehicle	R	÷ 325 (cm)	÷ 325 (cm)
Load on the rear axle (add to the axle load)		138.5 (kg)	38.5 (kg)
Weight in the storage space		- 100 (kg)	- 50 (kg)
Load relief to the front axle (subtract from the axle load)		38.5 (kg)	
Load on the front axle (add to the axle load)			-11.5 (kg)

Increase and reduction of load capacity

In the case of an increase of load capacity, a change in the chassis usually increases the technically permissible maximum laden mass of the vehicle, the technically permissible maximum laden mass on the axle and, as a result, the remaining load capacity for luggage, camping equipment, etc.

In contrast to an increase of load capacity, a reduction of load capacity reduces the technically permissible maximum laden mass of the vehicle, the technically permissible maximum laden mass on the axle and, as a result, the remaining load capacity for luggage, camping equipment, etc. As a rule, a technical modification of the chassis is not performed.



- Due to the change in the technically permissible maximum laden mass, increases or reductions of load capacity may affect the permitted seats, the chassis, and the mass on the axle. If you have any questions, feel free to contact the responsible technical testing center for advice.
- A reduction or increase of load capacity may result in changes to the legal requirements resulting from the new technically permissible maximum laden mass of the vehicle. This applies in particular to the legal requirements from the German Road Traffic Act (StVO), the German Road Vehicle Registration Regulation (StVZO), and tax and insurance regulations. An increase of technically permissible maximum laden mass to over 3500 kg may, for example, affect the driving license class or result in different speed limits or prohibitions on passing and overtaking. Toll payment requirements may also change due to the new technically permissible maximum laden mass. Therefore, inform yourself about the current legal situation with regard to the new technically permissible maximum laden mass of the vehicle and seek advice on this from the appropriate bodies. Please note that national regulations in the country of your destination and countries visited in transit may differ from those in your home country.
- For more information on the actual weighed mass of your vehicle and the remaining load capacity, please refer to section "Remaining load capacity" (page 23).



3.2.4 Roof loads



- Only climb on to the roof if a roof rail or step has been fitted. Always use the ladder at the rear to climb onto the roof.
- ► Take care when stepping onto the ladder. There is danger of slipping when the ladder is moist or icy.
- ► Take care when stepping onto the roof. There is danger of slipping when the roof is moist or icv.
- ▶ Do not overload the roof. Road behaviour and brake reaction deteriorate as the roof load increases.



- ▷ If the vehicle is equipped with a roof rail, load racks can be mounted on the roof rail for roof loads (e.g. for surfboards, rubber boats or light canoes). Special girder systems are available as accessory. The authorised dealer or service centre will be happy to advise you.
- If there is a step, only access the roof using the step provided for this purpose.
- > Secure roof loads with tension belts. Do not use rubber expanders.
- Doserve the overall height of the vehicle when the roof rack is loaded.



The driver's cabin should have a clearly visible notice stating the overall height. This eliminates the need for calculations at bridges and thoroughfares.

Roof rail and step




Fig. 3 Roof rail and step

- 1 Roof rail
- 2 Step

If the vehicle is equipped with a roof rail (Fig. 3,1), then depending on the version a step (Fig. 3,2) will also be mounted on the roof. In this case, only access the roof using the step.



Rear ladder



Fig. 4 Lock (rear ladder)

- Rear ladder lock
- Locking cylinder
- Fixed part of the rear ladder
 - Rear ladder
 - Securing bracket

Folding downwards:

- Insert the key into the locking cylinder (Fig. 4,2) of the rear ladder lock (Fig. 4,1) and turn it a quarter turn until the key is in a vertical position.
- Hold the foldable part of the rear ladder (Fig. 4,4) and swing out the securing bracket (Fig. 4,5).
- Pull out the key and fold the rear ladder downwards.

Folding upwards:

- Fold the rear ladder upwards and hold it firmly.
- Insert the key into the locking cylinder (Fig. 4,2) of the rear ladder lock (Fig. 4,1).
- Swivel the securing bracket (Fig. 4,5) inward around the tube of the fixed part of the rear ladder (Fig. 4,3).
- Turn the key a quarter turn until it is in a horizontal position.
- Check the rear ladder lock: Slightly pull on the rear ladder.

3.2.5 Rear garage / rear storage space



- Observe the technically permissible maximum mass on the axle and the technically permissible maximum laden mass when loading the rear garage / rear storage space.
- The maximum permitted load of the rear garage/the rear storage space is 350 kg. If the vehicle is fitted with a caravan coupling or a motorcycle rack, the permitted load is 450 kg. Do not exceed the technically permissible maximum mass on the rear axle.
- Uneven loading or overloading has a negative effect on driving behavior. A rear-heavy load in particular results in a reduction of the load on the front axle due to leverage effects and thus, for example, to a loss of traction, a diminished steering response (altered driving behavior), an overloading of the tires and, as a result, an increased risk of tire blowouts. This may cause you to lose control of the vehicle, endangering yourself and other road users. An evenly distributed load over the entire vehicle leads to optimum driving behavior during travel. If you are not sure whether the loaded vehicle complies with the technically permissible maximum laden mass and the technically permissible maximum laden mass on the axle, you can weigh/check the vehicle on public scales or have it weighed by certain dealers.
- Do not exceed the maximum permissible external load on the rear wall/rear flap. Only equipment components approved by the manufacturer are permitted (e.g. certain bike racks).





- When transporting vehicles powered by gasoline, diesel, gas, or other flammable material, make sure that the tank of the transported vehicle is completely empty. When transporting electric bikes, we also recommend that you remove and securely stow the battery before commencing travel.
- ► Rear garages and rear storage compartments are not designed at the factory to function as sleeping or living areas for people or animals. These spaces are not provided with ventilation at the factory. There is a risk of suffocation due to a lack of oxygen.



- Observe that only factory-fitted equipment components (e.g. storage nets) are permitted on rear doors/rear flap.
- Observe the maximum permissible load of 5 kg for the factory-attached storage nets.
- Depending on the vehicle equipment, clamping rails with clamping eyelets are mounted in the rear garage or in the rear storage space. Always secure loads onto the clamping eyelets. Always use tightening straps or lashing nets for securing the load, never rubber expanders.
- When clamping loads, always check that the clamping eyelets are placed tightly in the clamping rails. If the clamping eyelet is not anchored tightly in the clamping rail, the load may slide or loosen during forcible movements of the steering wheel or when braking.
- Distribute the load evenly. Excessive spot loads can lead to damages of the floor covering.
- Use the supporting system offered by your dealer if two-wheelers are transported in the rear garage.
- Do not drill into the vehicle floor. Do not screw any screws into the vehicle floor.

When loading rear garages and rear storage compartments, please observe the following instructions to ensure safe driving:

- Baggage and items carried in rear garages and rear storage compartments must also be evenly distributed in accordance with the section "Load securing and load distribution" (page 27).
- All items stowed in rear garages and rear stowage compartments must be fastened and secured accordingly using suitable clamping systems at the existing fastening points provided at the factory.
- Before driving off, it must be ensured that the rear garage or rear storage compartment is properly locked.






Fig. 5 Clamping eyelets (rear garage)

- Clamping rail
- Clamping eyelet

Moving the clamping evelets:

Turn the clamping eyelet (Fig. 5,2) half a turn in an anticlockwise direction. Now, the clamping eyelet (Fig. 6) may be moved.







Fig. 7 Clamping eyelet (clamped)

- Push the clamping eyelet into the clamping rail (Fig. 5,1) to the desired position.
- Give clamping eyelet one half turn in a clockwise direction. The clamping eyelet (Fig. 7) sits tightly in the clamping rail again.
- Check that the clamping eyelet is tight.



- Please observe the maximum permissible load of the rear garage or rear storage compartment at all times. The specified maximum permissible load of the rear garage or rear storage compartment may be influenced by the selection of further optional equipment, such as trailer couplings or frame extensions. However, the technically permissible maximum laden mass and the technically permissible maximum laden mass on the axle must not be exceeded under any circumstances. Especially when stowing or attaching heavy accessories or heavily laden accessories (such as motorcycle carriers or bicycle carriers) at the rear, the mass on the axle must be checked and complied with. For this reason, please note that the maximum load may not be fully utilized if this would result in the exceedance of the technically permissible maximum laden mass or technically permissible maximum laden mass on the axle.
- Further information on correct loading can be found in the sections "Technically permissible maximum laden mass" (page 22), "Technically permissible maximum laden mass on the axle (mass on the axle)" (page 29) and "Load securing and load distribution" (page 27).



3.3 Bike rack



- Observe the technically permissible maximum laden mass on the axle and the technically permissible maximum laden mass when loading the bike rack.
- ▶ A total width of 2.55 m must not be exceeded. Adjust the attachments for the bikes accordingly. The overhang to the side and rear must be marked in accordance with the regulations for the country in which you are travelling.
- ► Load the bike rack with bicycles only.
- ▶ Do not transport more than the permitted number of bicycles for the bike rack used (max. 50 kg).
- ► Check the secure attachment of the bicycles on the bike rack after the first 10 km and then at each break in the journey.
- ▶ Do not use the bike rack as luggage rack or ladder.



- The identification plate and rear lights must not be covered.
- Driving with a folded out bike rack without bicycles is not permitted.
- Before every journey, check: Is the bike rack without bicycles folded in correctly? Are the bicycles securely fastened to the bike rack using the bike rack belts?

Loading the bike rack with bicycles

When loading the bike rack, observe the centre of gravity. The centre of gravity of the bicycles must be as close as possible to the rear wall of the vehicle. The bike rack should always be loaded from the inside to the outside.

Loading the bike rack correctly:

- Fold the bike rack downwards.
- Place the heaviest bicycle directly against the rear wall.
- Place the lightest bicycles in the centre or on the outside of the bike rack.
- Secure the front and rear wheels of each bicycle with the retaining straps on the bike rack.
- In addition, fasten the outermost bicycle on the retaining bracket or retaining arm.

If the bike rack is only loaded with **one** bicycle, position the bicycle as closely as possible to the rear wall.

36



Towing 3.4



- Care is to be taken when connecting and detaching a trailer. Risk of accident and injury!
- No persons are to be between the motorhome and the trailer during positioning for connecting and detaching.
- Observe the permissible nose weight and rear axle load of the motorhome. Nose weight and rear axle load must not be exceeded. The values of the nose weight and rear axle load are included in the documents of the vehicle and the caravan coupling.



- Trailer with an overrun brake: Do not connect or detach trailer with the overrun brake on.
- Caravan coupling with detachable ball neck: If the ball neck is mounted incorrectly, there is the danger of the trailer breaking away. Observe the instruction manual for the caravan coupling.



The maximum permissible nose weight of the vehicle is 100 kg.

Caravan coupling



- When attaching a caravan coupling, refer to the vehicle documents for the maximum nose weight and the technically permissible maximum towable mass.
- Retighten the caravan coupling fixing screws after 1000 operating hours.



The bike rack and caravan coupling may not be used simultaneously.



- Have your authorised dealer or authorised service centre install the addon parts. They will also take care of all the formalities for you.
- Observe the manufacturer's instruction manual.



Fig. 8 Caravan coupling (detachable)



3.6 Entrance steps



- ▶ Before commencing the journey and after short interruptions of the journey, ensure that the entrance step is completely retracted.
- ▶ Do not stand in the direct range of the entrance step while it is being retracted or extended.
- ► Do not step on the entrance step until it has extended completely. There is a risk of injury!
- ► To prevent danger of slipping, clean the entrance step if necessary before entering (snow, ice, mud, etc.).
- ▶ Do not under any circumstances raise or lower persons or loads with the entrance step.
- ► Following a cold start, for vehicle-related reasons it can take a few seconds before the warning tone sounds.
- ▶ Observe the maximum load for the entrance step according to the manufacturer's instruction manual.



Do not grease or lubricate the pivot bearing and joints of the entrance step (see chapter 11).

3.6.1 Entrance step

The electrically operated entrance step makes it easier to enter and exit the vehicle through the living area door.

Depending on the model, the switch panel with the rocker switches is installed either in the dashboard or on the side, in the driver's door.



Fig. 9 Rocker button for entrance step (entrance area)



Fig. 10 Rocker switch for entrance step (switch panel)



The rocker button in the entrance area (Fig. 9) has an additional frame to protect it from being actuated unintentionally.

Retracting:

Press upper part of the rocker button in the entrance area (Fig. 9) or press the rocker switch (Fig. 10) on the switch panel in the driver's cabin.

Extending:

■ Press lower part of the rocker button in the entrance area (Fig. 9).

When the engine is running and the entrance step is extended, a warning tone is heard. The warning tone stops as soon as the entrance step has been retracted.



3.6.2 **Driver's door step**

The automatic step on the driver's door makes it easier to enter and exit through the driver's door.

Extending:

Open driver's door. The step extends automatically.

Retracting:

Close driver's door. The step retracts automatically.

3.7 **Electrically heated windscreen**



- The windscreen will only be heated when the engine is running.
- Each heating loop heats its respective half of the windscreen. If one heating loop fails, the other half of the windscreen will continue to be heated.

The windscreen heater is used to dehumidify a misted windscreen and to defrost a frosted windscreen.

Depending on the model, the switch panel with the rocker buttons is installed either in the dashboard or on the side, in the driver's door.



Fig. 11 Rocker switch (windscreen heater)

Switching on:

Press the bottom half of the rocker switch (Fig. 11). The red LED of the rocker switch is lit.



To protect the battery, the windscreen heater switches off automatically after 18 minutes. The red LED of the rocker switch goes out.

Switching off:

Press the top half of the rocker switch (Fig. 11). The red LED of the rocker switch goes out.



3.8 Multimedia system (Mercedes)

The multimedia system includes a DSP box installed in the seat console of the front passenger's seat. The DSP box contains the processor for programming sound.



Do no open the DSP box. Only an authorised specialist workshop may open the DSP box.



- ▷ If during an ongoing sound reproduction of the mobile terminal you switch to a mobile terminal coupled via Bluetooth, a 2-minute interruption of the reproduction occurs.
- > Further information can be obtained in the manufacturer's instruction manual.

3.9 TV unit



- ▶ Before commencing the journey, return the flat screen and the screen holder into the initial position and secure them.
- ▶ Before commencing the journey, ensure that the antenna is in park position. Danger of accidents!



> Further information on positioning the flat screen can be obtained from chapter 6.

3.10 Thitronik WiPro III alarm system



▶ Observe the brief operating instructions and operating instructions of the alarm system manufacturer.

The WiPro III alarm system is a wireless alarm system specially developed for leisure vehicles that warns of break-ins.

It is operated via the Thitronik hand-held radio transmitter supplied (alternatively via the vehicle radio key) and/or via the Thitronik app.

An optional gas sensor and the "Pro-finder" function can be retrofitted by the dealer. The gas sensor warns when a critical gas concentration is reached in the room air. The "Pro-finder" enables an emergency text message to be sent to predefined phone numbers.



Control of the alarm system

	Vehicle radio key	Hand-held radio transmitter	
Condition	Only with closed driver's cabin doors	With closed and open driver's cabin doors	
Activate alarm function	Locking button	Any button	
Reaction Deactivate alarm function	Vehicle direction indicators flash 1 to 2 times depending on the vehicle type. Internal beeper sounds 1 time. Status LED starts flashing. Unlocking button	 Vehicle direction indicators flash 1 time. Internal beeper sounds button 1 time depending on the button. Status LED starts flashing. Any button 	
Reaction	 Vehicle direction indicators flash 1 to 2 times depending on the vehicle type. Internal beeper sounds 2 time. Status LED no longer flashes. 	 Vehicle direction indicators flash 2 time. Internal beeper sounds button 2 time depending on the button. Status LED no longer flashes. 	

Break-in alarm / gas concentration

If the radio magnetic contacts on the doors, windows and flaps register an attempted break-in or if the optionally available gas sensors detect a critical gas concentration, the integrated siren and the vehicle horn (not included for all vehicle types) sound for 30 seconds. In addition, the vehicle's indicator lights and status LED flash for 180 seconds.

After the alarm cycle has ended and an alarm pause of approx. 30 seconds, the alarm is set off again. If the critical gas concentration remains as the cause of the alarm, the flashing lights and the status LED flash until the gas concentration has reached a non-critical level.

Panic alarm

In the event of a threatening situation, the panic alarm function can be used to attract attention. In the event of a panic alarm, the siren, indicators and, depending on the vehicle type, the horn are activated. If an optionally available "Pro-finder" is connected, an emergency text message with the last known position is sent to all predefined destination numbers. The panic alarm can be triggered both when the system is activated and deactivated.

Activating:

Press both buttons on the wireless hand-held radio transmitter simultaneously.

Deactivating:

Press any button on the wireless hand-held radio transmitter.



- The Thitronik app is available free of charge from the App Store or Google Play. For terms of use see www.thitronik.de.
- For further information (e.g. on changing the transmitter batteries), refer to the manufacturer documentation.
- Follow instructions on the manufacturer's website: www.thitronik.de



Do not dispose of the device with household waste. Municipal collection points have suitable disposal containers for electronic devices.



3.11 Sink cover



- ▶ If the sink cover is fixedly attached: close sink cover.
- ▶ If the sink cover can be removed: remove sink cover from the sink and store it securely.

3.12 Gas regulator



Operating gas-operated appliances during the journey is permitted only if the gas system has the relevant equipment. The hose break guard and crash sensor prevent an escape of gas in the event of an accident.

Depending on the equipment, different gas regulators can be installed in the vehicle.

If other gas regulators than the one listed below are installed in the vehicle, the regulator tap on the gas bottle and the gas isolator taps must be closed during the journey.




Fig. 12 Gas regulator (DuoControl CS)

- 1 Hose break guard
- 2 Crash sensor

Gas regulator with crash sensor and hose break guard If a gas regulator with crash sensor (Fig. 12,2) and hose break guard (Fig. 12,1) is installed in the vehicle:

The regulator tap on the gas bottle and the "Heater" gas isolator tap may remain open during the journey. Gas-operated appliances may be on during the journey.

The design details of the gas regulators can vary (vertical or horizontal).



If in doubt, get the relevant information from authorised dealers or service centres.



3.13 **Snow chains**



- Only mount snow chains if there is a clearance of at least 50 mm between the tyres and the vehicle body.
- When using snow chains, the tyres, wheel suspension and steering are subjected to an additional load. When using snow chains, drive slowly (maximum speed 50 km/h) and only on streets which are completely covered with snow. Otherwise the vehicle could be damaged.
- Observe the fitting instructions issued by the manufacturer of the snow chains.
- Do not fit snow chains on alloy wheel rims.

The use of snow chains is subject to the legal regulations of the individual countries.

- Always mount snow chains to the drive wheels.
- After a few metres, check the tension of the snow chains.

3.14 Manufacturer service for original appliances and original built-in parts

Before the journey, check whether manufacturer service for original appliances and original built-in parts is offered in the destination country (Original Equipment Manufacturer (OEM) Service).

3.15 Road safety



- Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle (see section 13.8).
- Add-on parts can be exposed to adverse conditions (storms, ice, vibrations, etc.) and require close monitoring despite careful design and manufacturing. Therefore, check the tight fit of the add-on parts at certain intervals and before long journeys.

Before commencing the journey, work through the checklist:

Service partners

No.	Checks	Checked
1	Service and sales partners noted (see section 12.1)	

Base vehicle

2	All vehicle documents are on board	
3	Tyres in proper condition and tyre pressure correct	
4	Vehicle lighting, brake lights and reversing lights function	
5	Oil levels for engine, gearbox and power steering controlled	
6	Coolant and fluid for windscreen washers filled up	
7	Brakes function	
8	Brakes react evenly	
9	When braking, the vehicle remains in the lane	



Housing body, outside

No.	Checks	Checked
10	Awning completely retracted	
11	Roof free of snow and ice (in winter)	
12	External connections and lines disconnected and stored away	
13	External supports removed	
14	Fitted steady legs retracted and fixed in place	
15	Wheel chocks removed and stored away	
16	Entrance step retracted (observe warning tone)	
17	External flaps closed and locked	
18	Rear living area door locked	
19	Overall height of the vehicle including roof rack when loaded measured and noted. Keep the height information close at hand in the driver's cabin	

Housing body, inside

20	Windows and skylights closed and locked	
21	Television secured	
22	Loose parts stored away or fixed in position	
23	Optional additional make-up mirror removed and securely stored	
24	Open storage spaces empty	
25	Loose sink cover (if present) stored securely	
26	Refrigerator door secured	
27	Refrigerator set to 12 V operation	
28	All drawers and flaps closed	
29	Living area doors and sliding doors secured	
30	Pull-down bed is secured in driving position	
31	Children's seats only mounted on the seats approved for this purpose	
32	Swivel seat locking device for driver's seat and front passenger's seat locked	
33	Shades in the driver's cabin opened and secured	
34	Satellite unit switched off	



Gas system

No.	Checks	Checked
35	Gas bottles firmly fixed in the gas bottle compartment so that they are unable to turn	
36	If the gas bottles are not connected to the gas tube, always place the protective cap on top	
37	Regulator tap on the gas bottle and gas isolator taps are closed	
	If there is a DuoControl regulating system with crash sensor present, the gas isolator taps and the main regulator tap may remain open during the journey.	

Electrical system

Check the battery voltage/battery capacity (in %) of the starter 38 and living area battery (see chapter 8). If the panel indicates that the battery voltage/battery capacity is too low, the respective battery will need to be recharged. Observe the notes and instructions in chapter 8 Commence journey with fully charged starter and 0 living area batteries.



B-MC I/T - 04/24-1 - EHG-0016-04EN

46



Chapter overview

This chapter contains instructions on how to drive the motorhome.

4.1 **Driving**



- The base vehicle is a commercial vehicle (small truck). Adjust your driving technique accordingly.
- Before commencing the journey and after short interruptions of the journey, ensure that the entrance step is completely retracted.
- When you start the engine, warning signals such as "entrance step extended" can sound. Under certain conditions (a cold start in winter) after the engine is started it can take up to 15 seconds for these warning signals to sound.
- A seat belt is fitted for each seat which is permitted for travel. Please keep your seat belt fastened during the journey.
- Never open your seat belts when travelling.
- Passengers must remain in the seats provided.
- The doors must remain locked.
- Avoid braking with a jerk.
- If a navigation system is used, only change the destination when the vehicle is stationary. Drive to a car park or stop in a safe area when changing the destination.
- Do not play DVDs using the monitor of the navigation system during the journey.



- Drive slowly on poor roads.
- Take extreme care when driving onto ferries, crossing uneven roads and driving in reverse. Because of the relatively large overhang, larger vehicles might swing out and "touch ground" in unfavourable conditions. This can cause damage to the underbody or to parts fitted there, e.g. a motorcycle rack.



- If an accident occurs as a result of these instructions not being observed, the manufacturer will not be responsible for damages caused.
- The safety measures stipulated in chapter 2have to be observed.



4.2 Breakdown assistance in the event of vehicle-related technical problems



▶ In case of emergency call the national emergency number or use the Mercedes-Benz emergency call system (SOS button, refer to base vehicle instruction manual).

For breakdown assistance and any questions on the base vehicle, the Mercedes-Benz customer centre is at your disposal. The call to the Mercedes-Benz customer centre is set up via the "me connect" communication module in the vehicle.



Only use the button for the call for breakdown assistance in the event of technical problems with the base vehicle. Any questions on the superstructure of the vehicle cannot be answered.

Position

Depending on the model, the button for the call for breakdown assistance is installed either in the centre console or in the roof operating unit.



Fig. 13 Button for the call for breakdown assistance (centre console)



Fig. 14 Button for the call for breakdown assistance (roof console)

Calling:

■ Press the button (Fig. 13 or Fig. 14) for the call for breakdown assistance. A call to the Mercedes-Benz customer centre is initiated.

On the multifunction display appears a message indicating that the call is being initiated. The audio output is muted. The vehicle data are transmitted; this might take a few seconds. After that, a staff member of the Mercedes-Benz customer centre will contact you.



In some countries, a voice message prompts you to confirm the transmission of the vehicle data. After confirming, the vehicle data are transmitted.

Disconnecting the call:

■ Press phone button on the multifunction steering wheel.



> Further information can be found in the instruction manual of the base vehicle.



4.3 **Driving speed**



- The vehicle is equipped with a powerful engine. This means there are sufficient reserves in difficult traffic situations. This high power enables a high maximum speed and requires above-average driving ability.
- The vehicle provides a large contact surface for wind. A sudden crosswind can be especially dangerous.
- Uneven or one-sided loading affects road performance.
- Driving on unknown streets, you may encounter hazardous road conditions and unexpected driving situations. Therefore, in the interest of safety, make sure your driving speed is appropriate to any given driving situation and environment.
- Adhere to the national legal speed limits.

Air suspension



Make sure that no persons are staying underneath the vehicle or between the wheels when the vehicle is lowered.



- Do not overload the vehicle (do not exceed the axle load nor the permissible gross weight).
- Make sure that it is possible to lower the vehicle can be freely even after a longer stationary period.
- Before setting of, check the system pressure at the pressure gauge. The system pressure shall be within a range from 1 to 6 bar. If required, increase the pressure or decrease the pressure.
- When using snow chains: make sure that there is sufficient free space for the snow chains.

1-circuit system

In addition to the standard equipment of the vehicle with steel springs, two bellows are installed on the rear axle. With that, the vehicle can be lifted several centimetres.






Fig. 15 Electrical control unit

- 1 On/Off button
- 2 Bleeding pin
- 3 Pressure gauge

Raising the vehicle:

Press On/Off button (Fig. 15,1) on the electrical control unit. Fill the system with an external compressor through a valve (on the left side of the left-hand vehicle seat console).

Lowering the vehicle:

Release the pressure. In order to do this, press the bleeding pin (Fig. 15,2) on the electrical control unit.



- Distribute the load evenly on the bellows because otherwise tensions may occur on the body. Tensions may hinder opening and closing the doors and flaps.

4.5 Brakes



► Have defects on the braking system immediately remedied by an authorised specialist workshop.

Before each journey

Before each journey, check by means of a braking test:

- Do the brakes function?
- Do the brakes react evenly?
- Does the vehicle remain in the lane when braking?



4.6 Seat belts

4.6.1 General

The vehicle is equipped with seat belts in the living area on the seats for which seat belts are compulsory by law. National regulations apply to fastening of seat belts.



- Fasten your seat belts before the beginning of the journey and keep them fastened during the journey.
- Do not damage or trap belts. Have damaged seat belts changed by an authorised specialist workshop.
- Do not alter the belt fixing devices, automatic seat belt winders and the seatbelt locks.
- Only use one seat belt for **one** adult person.
- Do not belt in objects together with persons.
- Seat belts are not sufficient for persons who are less than 150 cm tall. In these cases use additional restraining devices. Observe test certifi-
- Only attach the child restraint system to seats that are specified for this purpose. We strongly recommend to install child restraint systems preferably in the second row of seats.
- After an accident, replace the seat belts (have it replaced).
- During the journey, do not tilt the backrest too far backwards. Otherwise the functionality of the seat belt is no longer guaranteed.

4.6.2 Fastening the seat belts correctly



- Do not twist the belt. The belt must be positioned smoothly against the body.
- When fastening the seat belt, adopt the correct sitting position.

The seat belt is correctly fastened when the lap belt passes below your stomach and across the hip bone. The shoulder belt must pass across the chest and shoulder (not across your neck). The belt must always be taut against your body. Any bulky or padded clothing should therefore be removed before you start your journey.



4.6.3 Seat belt cover



When using the bench during the journey: Do not use the bench without the headrests.

If the headrests have been removed from the back cushion of the bench and the seat belt cover (Fig. 16) has been attached (see section 6.9): Remove the seat belt cover and refit the headrests before commencing the journey.



Fig. 16 Seat belt cover attached

4.7 Child restraint systems



- ▶ When travelling, secure children under 13 years of age that are smaller than 150 cm, with a suitable and officially approved child restraint system.
- ► Fasten the children's seat belts before commencing the journey and make sure that their seat belts are kept fastened during the journey.
- ▶ If a front passenger airbag is fitted in the vehicle, do not use a child restraint system ("reboard systems") that faces the back of the front passenger's seat. Follow warning notices in the vehicle.
- Only attach the child restraint system to seats that are specified for this purpose. If the front passenger's seat airbag is activated, only forward-facing child restraint systems may be used on the front passenger's seat.
- Never use rearward-facing child restraints on a seat with activated front airbag. This may lead to death or to serious injuries in children.







Fig. 17 Warning notice on child restraint system (front passenger's seat sun visor)

No rearward-facing child restraint systems on the front passenger's seat The front passenger's seat is equipped with an airbag. When this airbag is activated, it is not permitted to use a rearward-facing child restraint system on the front passenger's seat. In the event of an accident, the triggered airbag may cause serious injuries in the child or to its death. A warning notice (Fig. 17) is attached to the sun visor depicting this hazard.

The airbag of the front passenger's seat can be deactivated. Refer to the instruction manual of the base vehicle for instructions.








Fig. 19 Child seat on L-shaped bench

The arrow in Fig. 18 and Fig. 19 shows the direction of travel.

Child seats are only allowed on the bench (Fig. 18) if the table has been removed and stowed. A maximum of 2 child seats can be fitted.

Only one child seat is allowed next to the window on the L-shaped bench (Fig. 19). The back cushion on the side wall must be removed when a child seat is fitted. If the table is a fixed table, move the table top towards the centre of the vehicle and lock it.

Child restraint systems are divided into five classes:

Class	Body weight	Approximate age
0	Up to 10 kg	Up to 9 months
0+	Up to 13 kg	Up to 18 months
1	9 kg to 18 kg	9 months to 4 years
II	15 kg to 25 kg	3 years to 7 ½ years
III	22 kg to 36 kg	6 years to 12 years



The following table shows, which child restraint systems can be used on which seats.

Seats	Age groups			
	< 10 kg (0-9 months)	< 13 kg (0-24 months)	9-18 kg (9-48 months)	15-36 kg (4-12 years)
Front passenger's seat	Х	X	UF	UF
Second row of seats (individual seat, attachable seat opposite to the direction of travel)	Х	Х	Х	Х
Third row of seats (with 3-belts, vari- ant L-seating group)	U**)	U**)	U	U
Third row of seats (with 3-belts, vari- ant Seating group with removable table)	U***)	U***)	U	U

Meaning of letters:		
U:	Suitable for restraint systems of "universal" category, authorised for the use in this weight category	
UF:	Suitable for front facing restraint systems of "universal" category, authorised for the use in this weight category	
X:	Seat is not suitable for children in this age group	
*):	Only with deactivated airbag	
**):	Only seat next to the window	
***):	Only with table removed	



4.7.1 Isofix fastening system for child seat

Position

The Isofix fastening system is installed on the bench both on the aisle side and the window side.



Fig. 20 Seat with Isofix

- Top tether
- 2 Isofix symbol
- 3 Top tether symbol
- Retaining clip




Fig. 21 Fixing with Isofix

- Top tether strap
- 6 Fixing hook
- Child seat
- 8 Connector



- Only fit child seats that are suitable and classified for the Isofix fastening system with top tether to the Isofix car seat fitting system.
- Observe the safety instructions and fitting instructions of the child seat manufacturer.

Isofix-suitable vehicle seats are provided with the Isofix symbol (Fig. 20,2). The position of the top tether is marked with a symbol (Fig. 20,3), too.

Fitting:

- Connect the connectors (Fig. 21,8) to the retaining clips (Fig. 20,4) such that they are firmly engaged. While doing this, a distinctive click must be heard.
- With a strong jerk, check if the child seat (Fig. 21,7) is firmly connected.
- Route the top tether strap (Fig. 21,5) over the headrest of the vehicle seat.
- Hook the fixing hook (Fig. 21,6) in at the top tether (Fig. 20,1).

The removal is carried out analogously in inverted order.



4.8 Driver's seat and front passenger's seat



- ▶ Before commencing the journey, rotate all swivel seats in the direction of travel and lock in position.
- ► The seats must remain fixed in position during the journey and are not to be rotated.
- ► Always turn the seats such that the seat surface points toward the centre of the vehicle and not to the exterior wall.

The following describes how to adjust the driver's seat and the front passenger's seat on the models I.

The adjustment of the driver's seat and front passenger's seat on the models T is described in the instruction manual for the base vehicle.



Fig. 22 Seat adjustment (Aguti GIS-Liner)

- Knurled wheel (adjusting the armrest)
- 2 Handle (adjusting the backrest)
- Lever (adjusting the seat inclination)
- 4 Bar (adjusting in longitudinal direction)

Driving position

- Push both armrests upward.
- Push the seat backwards or into the central position.
- Rotate the seat inwards, into the direction of travel and lock in position.



Distance to the pedals

Adjust the driver's seat so that the driver can depress the pedals comfortably.

- Pull the bar (Fig. 22,4) upwards.
- Push the seat forwards or backwards.
- Release the bar. The seat must audibly lock into place.

Seat inclination

Adjust the seat inclination so that the thighs rest on the seat surface without any pressure.

- Pull the respective lever (Fig. 22,3) upwards.
- Bring the seat into the desired inclination position by applying or relieving pressure.
- Release the lever. The seat must audibly lock into place.

Seat height

Pull up or press down the lever on the rear right of the seat.



Backrest

Adjust the angle of the backrest of the driver's seat so that the steering wheel can be held with the arms slightly bent.

- Turn the handle (Fig. 22,2).
- Bring the backrest into the desired inclination position by applying or relieving pressure.
- Release the handle. The backrest must audibly lock into place.

Armrest

The height of the armrests can be continuously adjusted.

- For more convenient handling, first move the armrest slightly upward.
- Turn the knurled wheel (Fig. 22,1) for fine adjustments. The armrest inclines upwards or downwards, depending on the rotation direction.
- Swivel the armrest downwards and check the position.

4.9 Seat heater

Depending on the model and the equipment, the driver's and front passenger's seats can be heated. The switch for the seat heater is attached to the side of the seat.



Fig. 23 Switch for seat heater



The seat heater only works while the engine is running.



4.10 Headrests (bench)




Fig. 24 Release button (headrest)

- 1 Bar
- 2 Holder
 - Release button

Before commencing the journey, adjust the headrest so that the back of the head is supported at approximately ear height.

Inserting the headrest:

- Remove the cover on the bench.
- Insert the bars (Fig. 24,1) of the headrest into the holders (Fig. 24,2).
- Push the headrest downward until it engages the first time.
- Press the release button (Fig. 24,3) and push the headrest further to the desired position.

Adjusting the headrest:

- Press the release button (Fig. 24,3).
- Pull the headrest upward or push it downward until it reaches the desired locking position.

Removing the headrest:

- Press the release button (Fig. 24,3).
- Pull the headrest out upwards.

Storage location

The headrests are stored in the rear bed.

If the vehicle is equipped with longitudinal single beds, the headrests are stored in the wardrobe underneath the right-hand bed (seen in the direction of travel).

If the vehicle is equipped with a queen size bed, the headrests are stored in the wardrobe on the right in the rear (seen in the direction of travel).

58



4.11 Attachable seat



Use the seat only in the opposite direction to the direction of travel.

Depending on the model and level of equipment, an attachable additional seat can be located in the storage space under the bench.

The attachable seat is equipped with a lap belt.



Fig. 25 Bench with seat cushion



Storage space under the Fig. 26 bench

Installing the attachable seat: Remove the seat cushion (Fig. 25).




Fig. 27 Holder for attachable seat

- Attachable seat
- Holder

- Place the attachable seat (Fig. 27,1) in the holder (Fig. 27,2).
- Fold the hinged half of the seat box lid upwards to obtain access to the wing nuts on the rods.






Fig. 28 Wing nuts for securing

1 Wing nut

■ Secure the attachable seat with wing nuts (Fig. 28,1).



Fig. 29 Belt lock for attachable seat

- 1 Front passenger's seat (rear side)
- 2 Belt lock
- 3 Retaining belt

■ Secure the retaining belt (Fig. 29,3) on the rear of the seat in the seatbelt lock (Fig. 29,2) on the back of the front passenger's seat (Fig. 29,1).



Fig. 30 Attachable seat unfolded

■ Fold down the seat (Fig. 30).




▷ If the vehicle is equipped with a pull-down bed, the attachable seat must be removed before lowering the pull-down bed.



4.12 **Additional seat**

Depending on the model and level of equipment, a foldable additional seat for the journey is located in the storage space beneath the bench.

The additional seat is installed in the direction of travel and is equipped with a three-point seat belt. If necessary, the additional seat can be completely removed.






Fig. 31 Additional seat folded

Fig. 32 Additional seat unfolded

Folding out the additional seat:

- Open the storage space.
- Press the lever (Fig. 31,1) down and hold it. Fold the backrest fully forwards.
- Press the lever (Fig. 32,1) down and hold it.
- Fold the opened the backrest back as far as it will go. The backrest must audibly lock into place. The additional seat and its seat belt is now ready for use.



Fig. 33 Additional seat ready for use

Removing additional seat:

- Lift seat.
- Release four star knob screws.
- Release bars from the four slotted holes.
- Take seat out.

To install the additional seat, proceed analogously in inverted order.



4.13 Seating arrangement



- ▶ During the journey, persons are only to sit on the permitted seats. The authorised number of seats is stipulated in the vehicle documents.
- ▶ During the journey sitting on the divans is not permitted.
- Seat belts must be worn by all passengers.

Seats which may be used during travel are equipped with a seat belt.

4.14 Electrical window winder



- ▶ Remove hands and other objects from the window before closing.
- ► Even if you leave your vehicle just briefly, remove the ignition key from the steering lock. Otherwise children may be able to operate the window winder and injure themselves.

The driver's cabin door is equipped with an electrical window winder. The rocker switch (Fig. 34) for the electrical window winder is installed in the left-hand driver's cabin door.



Fig. 34 Rocker switch (electrical window winder in the driver's door)



4.15 Electrically adjustable and heatable external mirrors



The main mirror of the two-part external mirror is electrically adjustable and heatable.

The vehicle is equipped with two electrically adjustable and heated external mirrors. The switches for external mirror adjustment and the mirror heater are installed in the dashboard.








Fig. 36 Rocker switch (mirror heater)

Adjusting:

- Select the mirror to be adjusted. To do so, turn the rotary switch (Fig. 35) to the left or right.
- Adjust the mirror by rocking the rotary switch (Fig. 35) in the appropriate direction.

Switching on the heater:

Press lower part of the rocker switch (Fig. 36). The red indicator lamp in the rocker switch indicates the operation.

Switching off the heater:

Press upper part of the rocker switch (Fig. 36). The red indicator lamp on the rocker button goes out.

4.16 Roman shades for driver's window and front passenger's window



During the journey, the Roman shades for the driver's window and front passenger's window must be open, in a fixed position and secured.

Securing:

- Carefully push back the Roman shades for the side panes.
- Secure Roman shades.



4.17 Curtain shades for driver's window, windscreen, and front passenger's window



▶ During the journey, the curtain shade must be open and secured.

Securing:

Push curtain shades back and secure them with straps and snap fasteners.

4.18 Reversing camera




Fig. 37 Camera module

The vehicle is equipped with a reversing camera. The reversing camera is installed in a camera module (Fig. 37) on top, at the rear of the vehicle.

When engaging reverse, the reversing camera switches on automatically and records the close-up area behind the vehicle. The image of the reversing camera is fed into the multimedia system and shown on the display in the driver's cabin.

No camera image is displayed while travelling forward.



▷ If the rear flap is open in strong sunlight, the camera module may overheat. The reversing camera then switches off temporarily until it has cooled down sufficiently.



4.19 **Bonnet**



- When the bonnet is open, there is a risk of injury in the engine compartment.
- Even if the engine was switched off some time ago, it might still be hot. Danger of burns!
- Do not work in the engine compartment while the engine is running.
- The bonnet must be kept firmly closed and locked during the journey. After closing, check whether the lock has engaged. In order to carry this out, pull on the bonnet.





Fig. 38 Release lever for the bonnet

Fig. 39 Correct holding position for opening the bonnet

Opening:

- Pull release lever (Fig. 38) on the left side underneath the dashboard. The bonnet is unlocked.
- Place both hands at the centre of the top and bottom edge of the bonnet (Fig. 39).
- Pull bonnet to the front (in the direction of travel) (Fig. 39).
- Move the bonnet up.

Closing:

- Swivel bonnet downwards. The snap lock engages audibly.
- Check whether the bonnet is locked correctly. In order to do this, pull the bonnet up.



- In the case of the vehicles with an automatic start-stop system, a limit switch in the bonnet's lock prevents a start of the windscreen wipers while the bonnet is open. Otherwise the bonnet could be damaged.
- Further information can be obtained in the manufacturer's instruction manual.



4.20 Filling with windscreen washer fluid



Fig. 40 Filler neck (washer fluid container)

- Unlock and open the bonnet.
- Remove the lid from the filler neck (Fig. 40) of the washer fluid container.
- Slowly fill in washer fluid.
- Push the lid onto the filler neck (Fig. 40) of the washer fluid container.
- Close the bonnet.

4.21 Checking the oil level



> The oil is measured via the combined instrument.

4.22 Refuelling



- ► All gas-operated devices must be switched off for refuelling (heater, cooker, oven, grill, refrigerator depending on the equipment). Danger of explosion!
- ► The cap for the fuel filler neck and for the drinking water filler neck are very similar. Before filling the tank, always check the label.



The fuel filler neck is labelled with the word "Diesel".

The fuel filler neck is situated on the exterior of the vehicle, at the front left.










Fig. 42 Warning notice (fuel filler neck)

Opening:

- Swing the flap (Fig. 41) upwards.
- Insert the key in the locking cylinder (Fig. 41) and turn it in an anticlockwise direction.
- Remove the cap.

Closing:

- Place the cap on the fuel filler neck.
- Turn key in a clockwise direction.
- Remove the key.
- Check that the cap is fastened securely on the fuel filler neck.
- Close the flap and press it down.

4.23 Ad-Blue®



Refer to the instruction manual of the base vehicle for any information and instructions regarding Ad-Blue®.

Position of the Ad-Blue® tank

The Ad-Blue® tank is installed in the engine compartment at the front right.



4.24 Towing



- ➤ To prevent any damages on the vehicle due to inadequate towing, observe the instructions in the operating manual of the base vehicle before towing.
- ▶ If the ignition key cannot be turned in the ignition lock, do not tow the vehicle. The steering will be locked.
- ▶ If, in the case of a vehicle with front-wheel drive and automatic transmission, the engine is not running: carefully push the vehicle a stretch of maximum of 15 meters. In the event of a breakdown, only transport these vehicles on a trailer or a transportation vehicle.



If the engine is not running or the power supply is disrupted, the servo assistance for the steering and brakes will not be operational. A considerable amount of force will be required for steering and braking.

The vehicle manufacturer recommends to transport the vehicle on a transportation vehicle or a trailer. If the vehicle has to be towed, use a towing bar. The towing bar must be approved for the weight of the vehicle.



National regulations apply to towing.

The holder for the towing eye is located behind a cover on the front bumper on the right-hand side.



Fig. 43 Cover (mount of the towing eye)




Fig. 44 Towing eye (mounted)

Installing the towing eye:

- Lever up the cover (Fig. 43) using a screwdriver.
- In the case of integrated vehicles: mount the towing eye extension.
- Fit the towing eye (Fig. 44) in accordance with the instructions in the operating manual of the base vehicle.



Chapter overview

This chapter contains instructions on how to pitch the vehicle at the campsite.

5.1 **Handbrake**

Firmly apply the handbrake when parking the vehicle.

5.2 **Entrance step**



If the entrance step has not been fully extended and is loaded, the mechanics could be damaged. Therefore, only step on the entrance step after it has been fully extended.



If the entrance step is extended while the engine is still running, a warning tone will sound.

5.3 Ramps



Ramps are not included in the scope of delivery. Different models are available at the accessories shop.

To enable the vehicle to be parked on the level, ramps can be used for height compensation when the vehicle is parked on a hill or on uneven ground.

5.4 Wheel chock

When parking the vehicle on slopes or inclines use a wheel chock.

If the technically permissible maximum laden mass of the vehicle exceeds 4 tonnes, a wheel chock must be used when parking on gradients. The wheel chock is provided as standard for vehicles with a technically permissible maximum laden mass exceeding 4 tonnes.



5.5 Rear area lighting

Depending on the equipment and model, the vehicle is equipped with rear area lighting.



Fig. 45 Rocker switch (rear area lighting)

Switching on rear area lighting:

Press the lower part of the rocker switch (Fig. 45). The rear area lighting is switched on.



▷ It is only possible to switch on the rear area lighting when the vehicle engine is shut off. If the rear area lighting is switched on and you start the vehicle engine, the LEDs will go out. When shutting the vehicle engine off, the rear area lighting will switch on again (if the lower part of the rear area lighting rocker switch is pressed).

5.6 Supports

5.6.1 General instructions



- Do not use the fitted supports as a vehicle jack. They supports are only for stabilising the parked vehicle to prevent the rear axle from bottoming out
- ▶ When pitching the vehicle, ensure that the supports are evenly loaded.
- ▷ Before driving away, wind up the supports as far as they can go, fully retract and secure them.



- ▶ When the ground is soft, place a pad or block under the supports in order to prevent the vehicle from sinking into the ground.
- Pitch the vehicle so that it is as horizontal as possible. Otherwise, the water from the shower tray will not be able to drain properly.

5.6.2 Steady legs



- ➤ The steady legs must not be used to jack up the vehicle in order to work beneath it, e.g. to change a wheel or carry out maintenance work
- ▶ Whilst the vehicle is in a jacked up position, persons must not lie down under it.





Always apply the handbrake before extending the steady legs.



Depending on the model, the hexagonal nut has a joint, which can be used to bring the attached socket spanner into a more convenient position for turning.

In order to ensure their correct function, clean and grease the interior tubes of the steady legs regularly.

The length of the steady legs can be adjusted according to the model.




Fig. 46 Steady leg

- 1 Hexagon
- 2 Notch
- 3 Guide disc
- 4 Splint
- 5 Support leg extension

Extending:

- Place the socket spanner on the hexagon nut (Fig. 46,1) and rotate until the steady leg is in a perpendicular downward position.
- Remove the splint (Fig. 46,4) out of the support foot extension (Fig. 46,5).
- Extend the support foot extension until it has reached the required length.
- Insert the splint in the support foot extension.
- Rotate the hexagon nut until the steady leg rests completely on the ground and the vehicle is in a horizontal position.

Retracting:

- Place the socket spanner on the hexagon nut (Fig. 46,1) and rotate until the steady leg is clear of the ground.
- Remove the splint (Fig. 46,4) out of the support foot extension (Fig. 46,5).
- Push in the support foot extension (Fig. 46,5) and insert the splint (Fig. 46,4) in the drilled hole in the support foot extension.
- Rotate the hexagon nut (Fig. 46,1) with the socket spanner until the steady leg has swung upwards and the guide disc (Fig. 46,3) has completely retracted into the notch (Fig. 46,2).



Before commencing the journey, observe the following: Are all steady legs and support foot extensions retracted completely and secured with the splint?



5.7 Hydraulic steady legs



- ▶ Do not raise the vehicle completely off the floor. Unstable and dangerous situations can arise if none of the wheels, particularly the braked wheels, remain in contact with the ground.
- ▶ When operating the hydraulic steady legs, ensure that nobody can be put in danger and that the extension/retraction range of the steady legs remains clear.
- ➤ The steady legs must not be used to jack up the vehicle in order to work beneath it, e.g. to change a wheel or carry out maintenance work.
- ▶ Whilst the vehicle is in a jacked up position, persons must not lie down under it.
- ▶ Before commencing the journey, check that all steady legs are completely retracted.
- ▶ Observe the safety instructions and information in the separate instruction manual of the manufacturer.



Before using the hydraulic steady legs, secure the vehicle to prevent unwanted movements.



- When the ground is soft, place a pad or block under the supports in order to prevent the vehicle from sinking into the ground.
- If one of the steady legs is not on the ground following automatic alignment, the vehicle can rock if persons are inside, despite it being correctly aligned. If this happens, retract the relevant pair of steady legs and then extend them again.
- Do not move inside the vehicle during automatic alignment.
- ➤ The engine can be started with the steady legs extended. However, it is not possible to drive away. The steady legs retract automatically after the engine is started. An audible signal sounds when the steady legs are completely retracted.
- For safe and proper handling of the steady legs, follow the safety and operating instructions in the manufacturer's separate instruction manual.

Conditions for extending

Before extending the steady legs, the necessary conditions must be created:

- If audio equipment is in operation in the vehicle: switch off the audio equipment so that the acoustic signals of the steady legs system can be heard.
- Park the vehicle safely.
- For vehicles with automatic transmission: engage gear P. For vehicles with manual transmission: engage neutral.
- Apply the handbrake.
- Switch on the warning lights.

A signal tone sounds. The hydraulic steady legs system is ready for operation.



Operating options

The steady legs system can be operated via the supplied Bluetooth manual control unit or via the HLC® Smart App on a smartphone.

If the steady legs system does not recognise the manual control unit or smartphone via Bluetooth, connect as follows:

- Make sure that the conditions for extending mentioned above have been created.
- Engage a gear. A signal tone sounds.
- Pair the manual control unit or smartphone with the steady legs system within 5 seconds.
- For vehicles with automatic transmission: engage gear P.
 For vehicles with manual transmission: engage neutral.

Operating modes

The hydraulic steady legs system has two operating modes:

- Manual mode
- Automatic mode (always activated after switching on)

In Automatic mode, the vehicle is automatically aligned horizontally both lengthways and crossways.

Both modes are controlled via the control unit.




Fig. 47 Control unit (hydraulic steady legs)

- 1 "Steady leg" LED Flashing yellow → steady leg is moving Red → steady leg at the extending end stop Green → manual steady leg selection
- 2 "Roll/pitch axis" LED
 Off → axis OK
 On → position too high
- 3 "0 position" LED Green → 0 position reached Flashing red → vehicle in a sloping position
- 4 "Battery status" LED Flashing red → replace battery
- 5 "Retract steady legs" button
- 6 "Change pair of steady legs" button

- 7 "Special position for emptying tank" button Flashing yellow → special position is being approached Yellow → position reached
- 8 "Manual mode" LED Green → Manual mode Flashing red → error
- 9 "On/Off/Mode" button Long → On/Off Short → change mode
- 10 "Automatic mode" LED Green → Automatic mode Flashing red → error
- "Special position for sleeping" button
 Flashing yellow → special position is being approached
 Yellow → position reached
- 12 "Extend steady legs" button



If the vehicle's sloping position is too great, the corresponding red "0 position" LED (Fig. 47,3) will be flashing red. Select a suitable location, or operate the steady legs manually at your own risk.

If when being extended a steady leg reaches its maximum length due to a depression in the ground, the "Manual mode" (Fig. 47,8) and the "Automatic mode" LEDs (Fig. 47,10) will be flashing red. If this happens, retract the steady legs, place suitable supports under the affected steady leg and repeat the procedure.

Switching on/off:

Press the "On/Off/Mode" button (Fig. 47,9) button for longer than 1 second. After switching on, a signal tone sounds and the "Automatic mode" LED (Fig. 47,10) is lit.

If it is not used, the steady legs system deactivates itself automatically after 5 minutes.

Changing mode:

■ Press the "On/Off/Mode" button (Fig. 47,9) briefly. The operating mode changes between manual and automatic mode. The corresponding LED (Fig. 47,8 or Fig. 47,10) lights up.

Stopping every movement:

Press the "On/Off/Mode" button (Fig. 47,9).

Extending the steady legs in automatic mode:

- Switch on ignition.
- Press the "Extend steady legs" button (Fig. 47,12). The alignment procedure is performed automatically. The "Steady leg" LEDs (Fig. 47,1) will be flashing as long as the steady legs are moving. A completed levelling process is confirmed by an acknowledgement tone and the "Steady leg" LEDs (Fig. 47,1) go out.

Retracting the steady legs in automatic mode:

- Switch on ignition.
- Press the "Retract steady legs" button (Fig. 47,5). The steady legs retract completely. The "Steady leg" LEDs (Fig. 47,1) will be flashing as long as the steady legs are moving. A completed retracting process is confirmed by an acknowledgement tone and the "Steady leg" LEDs (Fig. 47,1) go out.

Actuating the steady legs in manual mode:

- Press the "On/Off/Mode" button (Fig. 47,9) in automatic mode briefly. The "Manual mode" LED (Fig. 47,8) is lit.
- Observe the "Roll/pitch axis" LEDs (Fig. 47,2). A lit LED indicates that the vehicle must be raised on this side.
- Press the "Change pair of steady legs" button (Fig. 47,6) as often as necessary until the desired pair of steady legs is selected. The corresponding "Steady leg" LEDs (Fig. 47,1) light up.
- Press the "Retract steady legs" button (Fig. 47,5) or "Extend steady legs" button (Fig. 47,12) until the desired position is reached.
- Press the "Change pair of steady legs" button (Fig. 47,6) again until another desired pair of steady legs is selected. Repeat the procedure until the vehicle is aligned. The vehicle is aligned when the green "0 position" LED (Fig. 47,3) is lit.
- Ensure that all steady legs are in contact with the ground.

Further functions

For further functions such as "Sleep" mode, "Empty tank" mode or calibration, see the manufacturer's instruction manual.

74



Electrical emergency operation (optional)



- ► Standing under the vehicle without adequately securing the raised load is prohibited (danger to life).
- ▶ Inserting the emergency lowering plug into the cigarette lighter triggers an immediate lowering of the vehicle. The operator must ensure at all times that no persons, animals or objects are endangered or damaged.
- ► Keep your hands away from the crushing zone.
- Observe the safety instructions and information in the separate instruction manual of the manufacturer.

An additional adapter block is fitted at the factory for electrical emergency operation, which can be used to operate the steady legs.

Power is supplied to the additional adapter block via an emergency operating cable with an emergency lowering plug. If necessary, the emergency lowering plug is plugged into the cigarette lighter.

Position of emergency operating cable with emergency lowering plug

The emergency operating cable with the emergency lowering plug is installed in the floor compartment between living area door and seating group and is accessible via a service cover.



1 Emergency lowering plug

2 Plug connector (connection to the additional adapter block)

Fig. 48 Emergency operating cable

- Ensure that the vehicle can be lowered safely.
- Plug the emergency lowering plug (Fig. 48,1) into the cigarette lighter of the vehicle. The vehicle is lowered.



- > In some vehicles, the cigarette lighter is only active after the ignition has been switched on.
- After the vehicle has lowered, press the steady legs up to the retraction end stop. Use a lever (crowbar or similar) to do this.



- > If the vehicle is equipped with an air spring, the steady legs can be pressed in by lowering the air spring.
- When all the steady legs are located in the retraction end stop, unplug the emergency lowering plug (Fig. 48,1) from the cigarette lighter.



5.8 230 V connection

The vehicle can be connected to a 230 V power supply (see chapter 8).

5.9 Refrigerator



▶ If the refrigerator is set to 12 V operation, it will constantly consume current. Therefore, switch over to gas operation when the vehicle engine is **not** running, and the vehicle is **not** connected to the 230 V power supply.

For units with an automatic power selection, the 12 V operation of the refrigerator only functions in the automatic mode when the vehicle engine is running. When the vehicle engine is switched off, the automatic energy selection switches the refrigerator to 230 V operation or gas operation.

5.10 Awning



- When the support legs are not positioned, extend the awning a maximum of 1 m.
- ▷ In the case of light rain, shorten one of the support legs so that water can run off.
- ▷ In case of light wind or rain, anchor the awning with ropes on both sides.
- Only retract the awning when the fabric is dry. When the awning must be retracted while the fabric is still wet: Extend the awning as soon as possible, in order to dry out the fabric.
- Before retracting, remove leaves and coarse dirt from the awning.




Fig. 49 Installing crank

- 1 Crank
- 2 Bayonet socket

Extending the awning:

- Take crank (Fig. 49,1) out of the rear garage (Fig. 49,A).
- Insert crank into bayonet socket (Fig. 49,2) of the awning.
- Turn the crank in an anticlockwise direction until the awning is extended to a maximum of 1 m.






Fig. 50 Preparing support legs

- Support leg
- Front bar 2
- 3 Lock
- 4 Holder
- Release support legs (Fig. 50,1) from holder (Fig. 50,4) in the front bar (Fig. 50,2). In order to do this, apply slight outward pressure on the support legs (Fig. 50,A).
- Fold out the support legs.
- Release the locks (Fig. 50,3) of the support legs. In order to do this, fold the catch lever downwards.
- Pull lower part of the support legs out to the desired length (Fig. 50,B).
- Position the support legs.
- Close the locks (Fig. 50,3) of the support legs. In order to do this, fold the catch lever upwards.






Fig. 51 Bringing awning into end position

- Use the crank to completely extend the awning. While doing so, reposition the support legs several times.
- Set the support legs to their final height.
- Pull crank out and store it in the rear garage.
- Fix the support legs to the floor with tent pegs (Fig. 51,A).

Retracting the awning:

- If present, remove guy ropes and tent pegs.
- Insert the crank in the bayonet socket of the awning ant turn in a clockwise direction until the awning has been retracted up to approx. 1 m.
- If necessary, clean the support legs.
- Open the lock on the support legs. In order to do this, fold the catch lever downwards.
- Push the lower part of the support legs in completely.
- Fold both support legs upward into the front bar and let them click into position. In order to do this, apply slight outward pressure on the support legs.
- Continue turning the crank until the awning has been retracted completely.
- Remove the crank from the bayonet socket and store it.



Chapter overview

This chapter contains instructions about living in the vehicle.

6.1 Doors



Only drive with locked doors.



- When leaving the vehicle, always lock the doors.

6.1.1 Central locking system



- The central locking system locks the driver's door, living area door and the right and left garage door of the body. External flaps (except gas bottle compartment flap and toilet flap) are monitored.
- ▷ If one of the doors, garage doors, or external flaps (except gas bottle compartment flap and toilet flap) is open, the central locking system cannot lock.
- When starting the engine, open doors and open storage space and service flaps which allow access to the inside of the vehicle (except gas bottle compartment flap and toilet flap) are indicated on the combined instrument.




Fig. 52 Remote control (central locking system)

- 1 "Locking" button
- 2 "Unlocking" button

79



6.1.2 Living area door, outside




Fig. 53 Door lock (living area door, outside)

- 1 Locking cylinder
- 2 Door handle

Opening:

- Insert the key in the locking cylinder (Fig. 53,1) and turn it in a clockwise direction until the door lock is unlatched.
- Return the key to the central position and remove it.
- Pull on the door handle (Fig. 53,2). The door is open.

Locking:

- Insert the key in the locking cylinder (Fig. 53,1) and turn it in an anticlockwise direction until the door lock is engaged.
- Return the key to the central position and remove it.

6.1.3 Living area door, inside



Fig. 54 Door lock (living area door, inside)

Opening:

- When the door lock is locked: Pull once at the door handle (Fig. 54). The door is unlocked.
- Pull at the door handle. The door is open.

Locking:

Press the door handle (Fig. 54).



6.1.4 Driver's door, outside



Fig. 55 Door lock (driver's door, outside)

Opening:

- Insert the key into the locking cylinder (Fig. 55) and turn until the door lock is unlatched.
- Return the key to the central position and remove it.
- Pull at the door handle (Fig. 55). The door is open.

Locking:

- Insert the key into the locking cylinder (Fig. 55) and turn until the door lock is engaged.
- Return the key to the central position and remove it.

6.1.5 Driver's door, inside



Fig. 56 Door lock (driver's door, inside)

Opening:

Pull at the handle (Fig. 56). The door lock is unlatched or opened.

Locking:

Press the handle (Fig. 56). The door lock is locked.



Lock handle Locking cylinder

6.1.6 Garage door with central locking system




Fig. 57 Door lock (garage door)

- Opening: Put the key in the locking cylinder (Fig. 57,2) and turn in a clockwise direction. The central locking system is unlocked.
 - Turn the lock handle (Fig. 57,1) through half a rotation in a clockwise direction and open the garage door.

Locking: ■ Close the garage door.

- Turn lock handle (Fig. 57,1) one half turn in an anticlockwise direction.
- Insert the key in the locking cylinder (Fig. 57,2) and turn it in an anticlockwise direction. The central locking system is locked.

Emergency release

The garage door may always be unlocked from the interior using the emergency release. This also applies if the garage door has been locked with the key or through the central locking system.




Fig. 58 Garage door (interior emergency release)

Unlocking:

- Press the grey slider (Fig. 58) of the upper and lower lock toward the centre of the door.
- Open the garage door pushing outward.



6.1.7 Insect screen on the living area door, extendable



- Open the insect screen completely before closing the living area door.
- Do not push into the mesh area when opening or closing the insect screen.
- ▷ Before leaving the vehicle, always return the insect screen completely into the door holder.



The body manufacturer excludes any guarantee if the damage of the mesh seems to have been caused through third parties or own fault.



Fig. 59 Insect screen (bottom guide)




Fig. 60 Insect screen (living area door)

- 1 Insect screen
- 2 Holding bar

Closing:

- Hold holding bar (Fig. 60,2) with both hands and pull the insect screen (Fig. 60,1) evenly out of the door holder.
- On the opposite side, push the insect screen as far as it will go.

Opening:

Hold holding bar (Fig. 60,2) with both hands and push the insect screen (Fig. 60,1) back into the door holder applying slight pressure.



6.2 External flaps



- ▷ Before commencing the journey, close all external flaps and lock them.
- ➤ To open and close the external flap, open or close all locks that are fitted to the external flap.
- Do not grab external flap of the gas bottle compartment by the bottom panel.




When leaving the vehicle, close all external flaps.

The external flaps fitted to the vehicle are all fitted with identical locking cylinders. Therefore, all locks can be opened with a single key.

6.2.1 Flap lock, elliptical



During rain, water can penetrate the opened flap lock. Therefore close the lock handle.



- Locking cylinder
 - 2 Lock handle

Fig. 61 Flap lock

Opening:

- Insert key into locking cylinder (Fig. 61,1) and turn one half turn in an anticlockwise direction. The lock handle (Fig. 61,2) snaps out.
- Remove the key.
- Turn lock handle one half turn in an anticlockwise direction. The flap lock is open.

Closing:

- Firmly close the external flap.
- Give the lock handle one half turn in a clockwise direction. The flap lock is now engaged but not locked.
- Insert key into locking cylinder.
- Press down lock handle with key inserted and turn key one half turn in a clockwise direction. The lock handle will stay bolted.
- Remove the key.



6.3 Ventilation



▶ The oxygen in the vehicle interior is used up by breathing and the use of gas operated appliances. Therefore, the used air must be replaced permanently. For this purpose, forced ventilation options (e.g. skylights with forced ventilation) are fitted to the vehicle. Never cover or block forced ventilations from the inside or outside with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves. There is a danger of suffocation due to increased CO₂ levels.



- Although sufficient ventilation is provided, in certain weather conditions, condensation can form on metal objects (e.g. screwed connections in the floor)
- Additional cold spots can occur at thermal "bridges" (e.g. skylight edges, sockets, filler necks, flaps, etc.).

Condensation

Ensure that there is a continuous exchange of air by providing frequent and efficient ventilation. This is the only method for ensuring that condensation and resulting mould is not formed during cool weather. During the colder season, a pleasant living climate is created if heating output, air distribution and ventilation are synchronised. To avoid draft close the air outlet nozzles on the dashboard and set the air distribution of the base vehicle to air circulation.

If the vehicle is laid up for a longer period, occasionally ventilate it well, especially in summer as heat accumulation can occur. Do not only air the interior, but also the storage spaces which are accessible from the outside. Air the parking place as well if the vehicle is parked in a closed space (e.g. garage). The occurrence of condensation could lead to the formation of mould.

6.4 Windows



- The windows are fitted with a blind or Roman shade and with an insect screen or folding insect screen. After the latch has been released, the blind and insect screen automatically spring back to the initial position by tensile force. In order not to damage the tension mechanics, hold onto the blind or insect screen and allow it to slowly return to the initial position. The Roman shade and folding insect screen are made of thin woven fabric. In order not to damage the Roman shade or the insect screen, grasp the respective handle and carefully return it to the initial position.
- Do not keep blinds closed over a longer period of time as that can cause increased material wear.
- If the blind or the Roman shade is completely closed, exposure to direct sunlight can cause heat to accumulate between the blind/the Roman shade and the window. The window could be damaged. For that reason, close the blind/Roman shade only 2/3 of the way in direct sunlight.

Also move the window into the "continuous ventilation" position.





- Before commencing the journey, close the windows.
- Depending on the weather, close the windows far enough to prevent moisture from entering.



- When leaving the vehicle, always close the windows.
- ▷ In extreme weather conditions or if the temperature fluctuates strongly, a light condensation film can form on the double-glazed acrylic glass. The glass is designed in such a way that condensation can evaporate when the external temperature increases. There is no danger of the doubleglazed acrylic glass being damaged by condensation.
- ➤ The upholstery will fade over time, if it is exposed to sunlight. If the temperature within the vehicle rises rapidly as well, the colour will change at an accelerated rate.

Therefore, we recommend to close the shades on the windows when there is strong sunlight. Ensure that heat does not build up when you close the blind.

6.4.1 Front passenger's window



Fig. 62 Handle for opening the front passenger's window

Opening: Fold out the handle (Fig. 62).

■ Push or pull forward the window section into the required position.

Closing: • Close the window as far as possible and let the handle lock in place.

6.4.2 Hinged window with automatic hinges



- Den the window completely, to release the lock. If the locking device is not released and the window is closed nevertheless, there is the danger of the window breaking due to the massive counter-pressure.
- When opening the hinged windows, ensure that there are no torsional forces. Open and close the hinged windows evenly.
- The catch lever is fitted with a safety knob. When operating the catch lever, always press the safety knob.

86






Fig. 63 Catch lever ("closed" position)

- Safety knob
- Catch lever
- 2 Locking catch
- Window catch

Opening:

- Press the safety knob (Fig. 63,1) and keep it pressed.
- Turn the catch lever (Fig. 63,2) a quarter turn towards the centre of the window.



Fig. 64 Hinged window with automatic hinge

Automatic hinge

Open the hinged window to the desired latched position. The automatic hinge (Fig. 64,1) locks in place automatically.

The hinged window remains locked in the required position.

Closing:

- Open the hinged window as wide as is necessary to release the lock.
- Close the hinged window.
- Press the safety knob (Fig. 63,1) and keep it pressed.
- Turn the catch lever (Fig. 63,2) a quarter turn towards the window frame. The locking catch (Fig. 63,3) on the catch lever is entirely on the inner side of the window catch (Fig. 63,4).

87






Fig. 65 Catch lever ("continuous ventilation" position)

- Safety knob
- 2 Catch lever
- 3 Locking catch
 - Window catch

Continuous ventilation

With the catch lever, the hinged window can be placed in two positions:

- "Continuous ventilation" (Fig. 65)
- "Firmly closed" (Fig. 63)

To place the hinged window into the "continuous ventilation" position:

- Press the safety knob (Fig. 65,1) and keep it pressed.
- Turn the catch lever (Fig. 65,2) a quarter turn towards the centre of the window.
- Lightly open the hinged window outwards.
- Return the catch lever to its initial position. Move the locking catch (Fig. 65,3) on the catch lever into the recess of the window catch (Fig. 65,4).
- Release the safety knob (Fig. 65,1).
- Make certain that the safety knob is not pushed in but rather that it secures the catch lever.

During the journey, the hinged window may not be in "continuous ventilation" position.

If it rains, the "continuous ventilation" hinged window position could lead to splashing water penetrating the living area. Therefore, close the hinged windows completely.



6.4.3 Hinged roof window with rotary window supports



> When opening the hinged roof window, ensure that there are no torsional forces. Open and close the hinged roof window evenly.




Fig. 66 Catch lever ("closed" position)

- 1 Window catch
- 2 Locking catch

Knurled knob

Catch lever

Opening:

■ Turn all catch levers (Fig. 66,3) a quarter turn towards the centre of the window.



Fig. 67 Window support (hinged roof window)

Open the hinged roof window to the desired position and use knurled knob (Fig. 67,1) to lock it in position.

The hinged roof window remains locked in the desired position.

Closing:

- Turn knurled knob (Fig. 67,1) until the latch is released.
- Close the hinged roof window.
- Turn all catch levers (Fig. 66,3) a quarter turn towards the window frame. The locking catch (Fig. 66,2) is located on the inside of the window catch (Fig. 66,1).





Fig. 68 Catch lever ("continuous ventilation" position)

Continuous ventilation

The hinged roof window can be brought to 2 different positions using the catch levers:

- "Continuous ventilation" (Fig. 68)
- "Firmly closed" (Fig. 66)

To bring the hinged roof window to the "continuous ventilation" position:

- Turn all catch levers (Fig. 68) a quarter turn towards the centre of the window.
- Press the hinged roof window slightly outwards.
- Return all catch levers to their initial position. The locking catch has to be moved into the corresponding recess of the window catch.

During the journey, the hinged roof window may not be in the "continuous ventilation" position.

In the event of rain, splashing water can ingress into the living area if the hinged roof window is in the "continuous ventilation" position. Therefore, close the hinged roof window completely.

6.4.4 Roman shade and insect screen

The windows are fitted with a Roman shade and an insect screen. Roman shade and insect screen are fixed to each other.




Fig. 69 Roman shade and insect screen (hinged window)

- 1 Handle
- 2 Bottom rod

Roman shade

The Roman shade is located in the upper window frame.

Closing:

Hold the Roman shade in the centre of the bottom rod (Fig. 69,2) and carefully draw it downwards.



Opening:

Hold the bottom rod (Fig. 69,2) of the Roman shade in the centre and carefully slide the Roman shade upwards.

Insect screen

The insect screen is located in the upper window frame.

Closing:

- Pull insect screen at the handle (Fig. 69,1) downwards.
- Move the insect screen continuously.

If the insect screen is not drawn fully to the bottom, the Roman shade can be stretched up to the end of the side window frame.

Opening:

■ Move insect screen at the handle (Fig. 69,1) fully upwards.

6.4.5 Roman shades for driver's window and front passenger's window

Closing:

- Release the retaining strap for the Roman shade.
- Close the Roman shade carefully until the magnet catch keeps the Roman shades closed.

Opening:

- Pull or push back the Roman shades carefully.
- Secure the Roman shade with the retaining strap.

6.4.6 Roman shade for windscreen, driver's window and front passenger's window



Fig. 70 Locking handle (front passenger's window)



Fig. 71 Roman shade (front passenger's window)

Closing:

- Press locking handle (Fig. 70) together and keep it pressed.
- Pull Roman shade carefully to the opposite side until the magnetic catch holds the Roman shade (Fig. 71) in closed position.

Opening:

- Press locking handle (Fig. 70) together and keep it pressed.
- Using the locking handle, carefully push back the Roman shade.
- Release the locking handle. The lock must engage.



6.5 Skylights

Depending on the model, skylights with forced ventilation are fitted to the vehicle. If a skylight is fitted without forced ventilation, the forced ventilation is performed using mushroom-shaped vents.



► The apertures for forced ventilation must always be kept open. Never cover or block forced ventilations with objects such as e.g. a winter mat. Keep forced ventilations clear of snow and leaves.



- The skylights are fitted with a blind or Roman shade and an insect screen. After the latch has been released, the blind and insect screen automatically spring back to the initial position by tensile force. In order not to damage the tension mechanics, hold onto the blind or insect screen and allow it to slowly return to the initial position.
- Do not keep blinds closed over a longer period of time as that can cause increased material wear.
- ▷ If the blind or the Roman shade is completely closed, exposure to direct sunlight can cause heat to accumulate between the blind/the Roman shade and the skylight. The skylight could be damaged. For that reason, close the blind/Roman shade only 2/3 of the way in direct sunlight. Open the skylight slightly or move it to ventilation position.
- Depending on the weather, close the skylights far enough to prevent moisture from entering.
- Do not climb on the skylights.
- ▷ Before commencing the journey, close the skylights.
- Before commencing the journey, check that the skylights are closed and locked.



- When leaving the vehicle, always close the skylights.
- ➤ The upholstery will fade over time, if it is exposed to sunlight. If the temperature within the vehicle rises rapidly as well, the colour will change at an accelerated rate.

Therefore, we recommend closing the shades on the skylights of the parked vehicle by 2/3 when there is strong sunlight.



6.5.1 Skylight with crank handle (KLAKU)



Observe the safety instructions and information in the separate instruction manual of the manufacturer.

The skylight is equipped with a pleated blind (as shade) and with an insect screen. With the integrated crank, the skylight can be opened on one side for ventilation.





Fig. 72 Skylight (closed)

Fig. 73 Crank

Opening the skylight:

- Unfold the crank (Fig. 73) and turn it in a clockwise direction until the skylight has reached the desired position.
- Fold in the crank.



Only turn the crank until you feel a slight resistance. At that point, you will have reached the maximum opening angle of the skylight.

Closing the skylight:

- Unfold the crank (Fig. 73) and turn it in an anticlockwise direction until the skylight is closed.
- Fold in the crank.



Fig. 74 Skylight (pleated blind closed)

Closing/opening the shade:

■ Reach into the recessed grip of the pleated blind and pull the pleated blind to the desired position.

Closing/opening the insect screen:

■ Reach into the recessed grip of the insect screen and pull the insect screen to the desired position.




The pleated blind and the insect screen can be infinitely adjusted independently of each other.



6.5.2 Hinged skylight


The hinged skylight may be opened on one side only. Three inclination angles and a ventilation position are available.



1 Roman shade

- 2 Insect screen
 - Lever

Fig. 75 Hinged skylight



1 Lever

- 2 Lock
- 3 Catch


Fig. 76 Lock (hinged skylight)

Opening:

- Turn the lever (Fig. 75,3 or Fig. 76,1) one quarter turn.
- Grip lever and push hinged skylight upwards.

Closing:

- Grip lever and pull hinged skylight downwards.
- Turn the lever one quarter turn. The lock (Fig. 76,2) must slide into the bottom catch (Fig. 76,3).



1 Lever2 Lock

3 Recess

Fig. 77 Lock (ventilation position)

Locking in the ventilation position:

- Grip lever and pull hinged skylight downwards.
- Turn the lever (Fig. 77,1) one quarter turn. The lock (Fig. 77,2) must slide into the top recess (Fig. 77,3).





If it rains and the hinged skylight is in ventilation position, that could lead to water penetrating the living area. Therefore close hinged skylight completely.

Roman shade

The Roman shade may be closed at any position, either with the hinged skylight open or closed.

Closing:

Pull out Roman shade (Fig. 75,1) and release in the required position.
 The Roman shade will stay in that position.

Opening:

■ Slowly push Roman shade at the handle to its initial position.

Insect screen



 The insect screen may be damaged if it is closed with the hinged skylight closed. Therefore only close the insect screen when the hinged skylight is open.

Closing:

Pull insect screen (Fig. 75,2) out until it engages with the latch on the opposite side.

Opening:

- Slightly push up insect screen along the strip. Latch is released.
- Slowly return insect screen into its initial position.

6.5.3 Wind-up skylight




Fig. 78 Hand crank

The wind-up skylight can be opened using the hand crank. The hand crank is folded out (Fig. 78, bottom) for opening and closing. The hand crank is folded in (Fig. 78, top) when in resting position.






Fig. 79 Wind-up skylight

- 1 Handle, insect screen
- 2 Hand crank
- 3 Handle, Roman shade

Opening:

Rotate the hand crank (Fig. 79,2) until a resistance can be felt.

Closing:

- Rotate the hand crank until the wind-up skylight is closed. The wind-up skylight can be locked after rotating two or three more times.
- Check the locking mechanism. To do so, press your hand against the acrylic glass.

Roman shade

The Roman shade can be closed in any position, as desired. If the Roman shade is locked with the insect screen, the insect screen is also moved along on closing the Roman shade.

Closing:

Pull the handle of the Roman shade (Fig. 79,3) in the direction of the arrow and release it in the desired position. The Roman shade will stay in that position.

Opening:

Slowly push the Roman shade at the handle to its initial position.

Insect screen

If the insect screen is locked with the Roman shade, the Roman shade is also moved along on closing the insect screen.

Closing:

■ Use the handle to pull the insect screen (Fig. 79,1) in the direction of the arrow to the opposite handle of the Roman shade (Fig. 79,3) and allow it to engage.

Opening:

- Press the handle of the insect screen (Fig. 79,1) at the back upwards and detach the insect screen from the Roman shade (Fig. 79,3).
- Use handle to return the insect screen slowly to its initial position.

6.5.4 Skylight with fan



Do not switch on the fan without a fly screen. Do not put your hands or fingers into the fan while it is running. Switch off the power supply before cleaning work.




A 4 A fuse (Fig. 80,4) protects the fan motor against overloading. If an overload has occurred: Determine and correct the cause (e.g. dirty fan) before replacing the fuse.





- A contact switch switches off the fan when the skylight is closed. The fan only runs when the skylight is opened a few centimetres.



1 Thermostat

- 2 Rotary handle
- 3 Flip switch
- 4 Cover (fuse)
 - Rotary switch

Fig. 80 Skylight with fan

Opening the skylight:

Turn the rotary handle (Fig. 80,2) until the desired opening angle is reached.

Closing the skylight:

Turn the rotary handle until the skylight is closed.

Aerating/venting:

Set the flip switch (Fig. 80,3) to "Aerate" (air flows from the outside inwards) or "Vent" (air flows from the inside outwards).

Switching off the fan:

Set flip switch (Fig. 80,3) to the central position.

Adjusting the fan speed:

■ Turn the rotary switch (Fig. 80,5) to the desired setting:

0 = off

1 = slow

2 = medium

3 = fast

Adjusting the temperature:

- Turn the thermostat (Fig. 80,1) as far as possible in the "blue" direction.
- When the desired temperature is reached: Turn the thermostat in the "red" direction until the fan switches off. When the temperature rises again, the fan switches back on again.

Replacing fuse:

- Turn the black cover (Fig. 80,4) counterclockwise a quarter of a turn.
- Remove the cover by pulling it carefully downwards. The fuse is located on the rear side of the cover.
- Check if the wire inside the fuse is torn.
- If necessary, carefully replace the fuse. The type and the rated power of the new fuse must coincide with those of the original fuse.
- Insert the cover with the fuse.
- Tighten the cover by turning it a quarter of a turn in a clockwise direction.



6.6 Rotating seats



- ▶ Before commencing the journey, rotate all swivel seats in the direction of travel and lock in position. During the journey, the swivel seats must remain locked in place in the direction of travel.
- ▶ Always turn the seats such that the seat points toward the centre of the vehicle and not to the exterior wall.



> Setting the position of the seats and armrests is described in chapter 4.

The lever for rotating the seat is located at the side of the seat.



Fig. 81 Lever for turning the seat

Rotating:

- Push both armrests at the driver's/front passenger's seat upward.
- Push the driver's seat/front passenger's seat backwards or into the central position.
- Pull the lever (Fig. 81) forward to turn the seat. The seat is released from the locking device.

6.7 Storage spaces



- ► Follow the safety instructions (sticker) that indicate when a space may not be used as a storage space (e.g. gas bottle compartment or spaces close to electrical wiring).
- ▶ When loading, observe the technically permissible maximum laden mass on the front and rear axle and the technically permissible maximum laden mass (see section 3.2.3).
- ▶ Do not transport fluids in the living area that emit gases hazardous to health.
- ► Close fluid containers tightly, secure them against sliding and against falling over.
- Always store heavy objects safely and slip-proof in the foot area. Lighter objects can be also stored safely in higher areas.



Do not store wet clothes in cabinets or storage spaces.



While storing the load, take into account how accessible the different objects should be, and how often they are used.

98



In the vehicle, there are the following possibilities for storage:

- Double floor area (interior and exterior access)
- Rear garage
- Storage cases
- Wall-mounted cupboards
- Storage options in the bathroom unit

6.7.1 Floor storage compartment



The floor storage compartments must not be loaded with more than 40 kg.



> Depending on the equipment, a carpet segment will have to be put aside to gain access to the floor storage compartments.

The level underneath the floor is divided into various floor storage compartments.

These floor storage compartments are accessible via service covers in the living area. The disposition of the floor storage compartments depends on the model.



Fig. 82 Service cover (handle recessed)



Fig. 83 Service cover (handle swivelled out)

Opening:

- If necessary, lay carpet segment aside.
- Press the grip plate (Fig. 82) in the service cover downward on one side. The handle (Fig. 83) swivels upwards.
- Remove the service cover upwards.



- ➤ Close the service cover again as soon as possible and recess the handle. Otherwise, there will be danger of tripping due to the open floor storage compartment or the protruding handle.
- ▶ Do not bend the carpet segments.
- ▶ Do not leave the carpet segments laying in the room. Danger of tripping!

Closing:

- Insert the service cover in the frame in the floor.
- Swivel handle downwards.




6.8 Multifunctional sideboard



- Secure pull-out (Fig. 84,4) with lock (Fig. 84,5) against unintentional running in or out.
- The maximum permitted pull-out (Fig. 84,4) load is 80 kg.

The vehicle can be equipped with a multifunctional sideboard instead of the right-hand bench. Possible uses of the multifunctional sideboard:

- Charging multimedia devices
- Stowing objects, shoes, etc.
- Footrest
- Access assistance for the pull-down bed
- Additional seat



- Multimedia compartment with two USB ports and two 230 V sockets
- 2 Drawer
- 3 Cushion
 - Pull-out with storage compartment and top inlay
- 5 Lock
 - Cable passage for multimedia devices

Fig. 84 Multifunctional sideboard

Use as additional seat / footrest

With the cushion (Fig. 84,3), the pull-out (Fig. 84,4) can be used as additional seat or as footrest.

When the pull-out has been pulled out: Secure pull-out with lock (Fig. 84,5).

Use as access assistance

The pull-out (Fig. 84,4) can be used as access assistance for the pull-down bed. In doing so, do not exceed the maximum permitted load of 80 kg.

When the pull-out has been pulled out: Secure pull-out with lock (Fig. 84,5).



6.9 Seat belt cover

When the vehicle has been positioned, the headrests can be removed from the back cushion of the bench to allow for more comfortable seating. The openings for the headrests and the cut-out for the seat belts can then be covered with a seat belt cover (Fig. 86).

The seat belt cover can be made of leather (Fig. 85,1) or fabric (Fig. 85,3).




Fig. 85 Seat belt cover

- Seat belt cover (leather version)
- Metal reinforcement plate 2 3
 - Seat belt cover (fabric version)

Attaching the seat belt cover:

- Remove both headrests.
- Slide the metal reinforcement plate (Fig. 85,2) completely into the pocket of the seat belt cover (Fig. 85,1 or Fig. 85,3).



Fig. 86 Seat belt cover attached

Attach the seat belt cover over the cut-out for the seat belts (Fig. 86).



6.10 Tables

6.10.1 Lift-off table with release button



Do not place a load onto the lowered table top until the cushions have been laid correctly on the table top (see section 6.13.9). Otherwise the table could be damaged.

The table top can be moved in both a lengthways and a crossways direction. Using the lifting mechanism, the table can be lowered and used as a bed foundation.



Fig. 87 Lift-off table with release button

- 1 Release button
- 2 Catch lever

Shifting the table top:

- Pull or press down the catch lever (Fig. 87,2).
- Push the table top to the desired position.
- Press the catch lever (Fig. 87,2) upwards.

Adjusting the table height:

- Press the release button (Fig. 87,1) and hold it down. The table top moves automatically upwards to the limit stop.
- Push the table top downwards into the desired position. Press on the centre of the table top.
- Release the release button (Fig. 87,1). The table top remains in the desired position.

Conversion into bed foundation:

- Press the release button (Fig. 87,1) and hold it down.
- Push the table top downwards as far as it will go. Press on the centre of the table top.
- Release the release button (Fig. 87,1). The table top remains in the lowest position.

6.10.2 Table with extendable table top



If the driver's seat is pushed all the way back, the table and driver's seat may collide. Therefore, enlarge, shift or rotate the table top carefully when the driver's seat is in the rearmost latching position.

The table top can be moved in both a lengthways and a crossways direction, and can also be rotated.

An integrated centre section can be used to enlarge the table top.






Fig. 88 Adjustment possibilities on the table

- Unlocking device
- Knob (shift table top lengthways)
- 2 Knob (shift table top crossways)
- Knob (rotate table top)

Moving in a lengthways direction:

- Pull down the knob (Fig. 88,3) and hold it.
- Move the table top to the desired position.
- Release knob.

Moving in a crossways direction:

- Pull down the knob (Fig. 88,2) and hold it.
- Move the table top to the desired position.
- Release knob.

Rotating:

- Pull down the knob (Fig. 88,4) on the lock.
- Rotate table top to the desired position.
- Rotate the table top to and fro slightly until the lock engages.




Fig. 89 Expanding the table top

- Table top
- 2 Centre section
- Unlocking device

Enlarging the table top:

- Press the release (Fig. 88,1 and Fig. 89,3) upwards.
- Pull on the table top (Fig. 89,1) until the centre section (Fig. 89,2) comes up and is at the same height as the table top.
- Push the table top together from both sides until the table top surface is closed.

Reducing the table top size:

- Press the release (Fig. 89,3) upwards.
- Pull on the table top (Fig. 89,1) until the centre section (Fig. 89,2) is freed.
- Push the table top together slowly from both sides. The centre section lowers automatically.
- Push the table top together further from both sides until the table top surface is closed.



6.10.3 Table with pillar table leg

The table top can be moved in both a lengthways and a crossways direction, and can also be rotated. It is not possible to convert it into a bed foundation.






Fig. 90 Lever for shifting the table top

Fig. 91 Pillar table leg (rotatable)

Shifting the table top:

- Pull or press down the lever (Fig. 90).
- Move the table top to the desired position.
- Press the lever back up.

Rotating the table top:

■ Rotate table top to the desired position. In order to do this, you need a little effort, because the table top rotates against the friction resistance on the pillar table leg (Fig. 91).

6.10.4 Suspension table with separable support leg



> The maximum permissible load on the swung-out table-top extension is 3 kg.



Fig. 92 Suspension table with separable support leg

- 1 Table top extension
- 2 Knob (locking)
- 3 Lower retainer
- 4 Support leg (lower part)
- 5 Support leg (upper part)
- 6 Table top

The suspension table size can be enlarged by swinging out a table top extension.

Extending:

Pull the knob (Fig. 92,2) of the lock down and swing out the table top extension (Fig. 92,1).

Reducing size:

Swing the table top extension (Fig. 92,1) under the table top (Fig. 92,6) until the lock latches in place audibly.

The suspension table's separable support leg enables it to be used as a bed foundation.




Converting into bed foundation:

- Lift the front of the table top (Fig. 92,6) by approx. 45°.
- Pull out the lower part of the support leg (Fig. 92,4) down and lay aside.
- Remove the table top from the upper retainer.
- Hook the table top at a 45° angle to the supports into the lower retainer (Fig. 92,3) and place on the floor with the upper part of the support leg (Fig. 92,5).

6.10.5 Folding worktop



- The folding worktop is designed only for minimal loads (e.g. kitchen utensils). Do not use the folding worktop as a repository for heavy objects.
- Do not place any objects that are fragile or filled with liquids on the table top. If the table top is lifted slightly when accidentally bumping into the table, the table may fold unintentionally.



- 2 Fixation
 - Holder

Table top

Fig. 93 Folding worktop

To increase the size of the kitchen work surface, a folding worktop can be folded out at the side of the kitchen counter.

Bringing the folding worktop into the work position:

- Hold the table top (Fig. 93,1) from below and pull gently to release it from the latching mechanism.
- Swing up the table top until the fixture of the telescopic holder engages. Let go of the table top.

Bringing the folding worktop into the travel position:

- Hold the table top (Fig. 93,1) at the edges and lift gently. With your other hand, swing down the fixture (Fig. 93,2) on the telescopic holder.
- Fold down the table top (Fig. 93,1) until the telescopic holder clicks into position in the holder (Fig. 93,3).



6.11 TV unit



▶ Before commencing the journey, return the flat screen and the screen holder into the initial position and secure them.



- For version with HYMER Smart Multimedia system: When a television is used in conjunction with the special feature "HYMER Smart Multimedia system", the television must have the following data in order to guarantee faultless operation:
 - TV power consumption in stand-by mode < 0.5 W
 - TV power consumption in operation ≥ 15 W (max. 30 W)
 - Headphones output (3.5-mm-jack) on the TV should have a voltage of 1.2 Vss at one third maximum volume



Depending on the version, different televisions and swivel arms will be installed. This section lists the available versions.

Flat screen, integrable

The flat screen is secured on the side by a guide rail (Fig. 94,1).



Fig. 94 Flat screen

- 1 Guide rail
- 2 Release button

Positioning the flat screen:

- Press the release button (Fig. 94,2).
- Pull the flat screen out of the guide rail (Fig. 94,1), into the desired position
- Take hold of the flat screen at the top and bottom edge and tilt it as desired.

Bringing the flat screen into the initial position:

- Take hold of the flat screen at the top and bottom edge and move it into the straight position.
- Push the flat screen back until it engages in the guide rail (Fig. 94,1) on the side.

Handle (unlock height adjustment) Handle (unlock lateral adjustment)



Flat screen, movable laterally

The flat screen can be shifted sideways on a rail.




Fig. 95 Handle to unlock the flat screen

Moving the flat screen:

- Press handle (Fig. 95) towards the flat screen and hold it there. The flat screen is unlocked.
- Push the flat screen to the desired position.
- Release the handle. The flat screen is locked.

Flat screen, movable

The flat screen can be shifted upwards and downwards or sideways.




Fig. 96 Flat screen

- Adjusting height of flat screen:
- Pull and hold handle (Fig. 96,1). The flat screen is unlocked.
- Push flat screen upward or downward into the desired position.
- Release the handle. The flat screen is locked.

Moving the flat screen laterally:

- Pull down the handle (Fig. 96,2) and hold it there. The flat screen is unlocked.
- Push the flat screen to the desired position.
- Release the handle. The flat screen is locked.



6.11.1 Satellite unit with automatic antenna alignment (Oyster)



▶ Before commencing the journey, ensure that the antenna is in park position. Danger of accidents!




- When switching on the ignition, the antenna will automatically retract into the idle position and lock there within a short period of time. However, before setting off, the driver must verify the correct position of the antenna.
- Retract the satellite antenna in case of strong wind or storm.
- Do not wash a vehicle with a satellite antenna in a brush washing system, nor in a vehicle washing installation, nor with high-pressure cleaners.



- The vehicle must be still during the satellite search. Do not walk through the vehicle.
- Pay attention to a "free visibility towards the south". From the European point of view, all the satellites are located approximately to the south.
- Satellite reception is only possible, when the antenna is positioned in direct line of sight of the chosen satellite and the view is not blocked in any way.
- The satellite unit can be adjusted with the control unit. Refer to the manufacturer's instruction manual about this.
- If the location is adjusted with the help of the list of countries, the satellite search will be accelerated.

The satellite antenna will automatically be aligned with a pre adjusted satellite if the receiver system is within the reach of this satellite. The operation of the satellite unit is not possible while the ignition is switched on.



1 Lighted display

- 2 OK Button
- 3 Next/Back buttons
- 4 On/Off button

Fig. 97 Control unit (satellite unit)

Position of control unit

The control unit is installed in a wall-mounted cupboard above the seating group.

The lighted display shows information regarding the current operating status of the satellite unit. To protect the battery, the lighting goes out after a while.

Switching on, erecting and aligning:

- Switch the receiver on. The satellite antenna raises automatically after starting up the receiver (up to 90 seconds).
- Alternatively: Press On/Off button on the control unit.





The satellite unit will start the search with the most recently adjusted position. If the vehicle's location has changed, the fully automatic satellite search will start. When the system has found the satellite, the selected TV programme appears automatically.

Switching off, retracting:

- Switch the receiver off. The satellite unit changes into idle mode. Depending on the adjustment, the satellite antenna will remain extended or will be retracted.
- Alternatively: Press On/Off button on the control unit. The satellite antenna retracts.

Stopping the satellite antenna: Press the OK button. The satellite antenna's movement is stopped immediately.

Selecting and changing adjustments:

- Press the Next and Back buttons until the desired menu item is displayed.
- Press the OK button. The menu item is activated.
- Press the Next and Back buttons to change adjustments.
- Press the OK button to save adjustments.
- Press On/Off button to abandon menu item without saving.



Further information can be obtained in the manufacturer's instruction manual.

6.12 Lighting

6.12.1 Lamps in driver's cabin

The lamps for the driver's cabin are installed on the bottom side of the pulldown bed.

2




Fig. 98 Lamps (driver's cabin)

Reading lamp Interior lamp

The interior lamp (Fig. 98,2) will switch on automatically when unlocking or opening a door of the vehicle.

The interior lamp (Fig. 98,2) will go out automatically a few seconds after closing all the doors, or when locking the vehicle, or after switching on the ignition.

Switching lamp on/off:

- Touch the edge of the reading lamp (Fig. 98,1). The reading lamp is switched on.
- Touch the edge of the reading lamp again. The reading lamp is switched off.



6.12.2 Lamps with two operating levels



Fig. 99 Lamp with switch

Switching the twilight on/off:

Briefly touch the switch (Fig. 99). The switch will be lit as twilight.

Switching on:

Briefly touch the switch again. The lamp is switched on.

Switching off:

Briefly touch the switch again. The lamp is switched off.

Dimmer:

Touch and hold the switch.

6.13 **Beds**

6.13.1 Pull-down bed, mechanically operated



- ▶ The maximum permitted pull-down bed load is 200 kg.
- ► The pull-down bed is not to be used for the storage of luggage. When the bed is not being used, only place the bed linen (max. 8 kg) which is required for two persons in it.
- ▶ Before commencing the journey, fix the pull-down bed in the upper position.
- ▶ Only use the pull-down bed, if the safety net is set up.
- Never allow small children to remain in the pull-down bed without supervision.
- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the pull-down bed.
- ▶ Use separate children's beds or travel cots suitable for children.
- ▶ Store the access ladder underneath the mattress during the journey.



- > Do not use the armrest on the driver's seat to help get into bed.
- ▷ It must be possible to close the pull-down bed without great effort. Objects on the pull-down bed can distort the lifting mechanism on one side, resulting in damage.





Fig. 100 Retaining belt

Opening the pull-down bed:

- Lower height-adjustable steering wheel.
- Rotate the driver's and front passenger's seats in the direction of travel, lock in position, push backwards and fold the backrest as far to the front as possible.
- Close the shade in the driver's cabin.
- Release the retaining belt (Fig. 100).
- Use both hands to pull the pull-down bed down as far as it will go.
- Make sure that the pull-down bed is in the lower end position and is not resting on obstacles such as headrests, cushions or similar.



Fig. 101 Safety net (pull-down bed)

1 Hook

2 Retaining belt

Closing the pull-down bed:

- Switch off the reading lamps on the ceiling.
- Release retaining belts (Fig. 101,2) and place safety net underneath mattress.
- Use both hands to push pull-down bed upwards as far as it will go.
- Close the retaining belt (Fig. 100). When doing this, ensure that the snap lock engages audibly.

Safety net

The safety net and the retaining belts are located underneath the mattress in the pull-down bed. Only use the safety net if persons are already in the pulldown bed.

Setting up:

Attach the retaining belts (Fig. 101,2) to the hooks (Fig. 101,1) on the ceiling.



Access ladder

Depending on the model, only access the pull-down bed via the included access ladder, via the divan, or via the folded-out step of the sideboard. Before descending, make sure that the ladder is still fixed.



Fig. 102 Access ladder (pull-down bed)

- 1 Bracket
- Bed surround

Attaching:

Hook the access ladder into the bed surround (Fig. 102,2) on the pull-down bed by the two brackets (Fig. 102,1). When engaging make sure that the hooks rest on the inner fixtures. This prevents lateral movement of the access ladder.

Storing away:

- Detach the access ladder (Fig. 102).
- Store the access ladder securely underneath the mattress.

6.13.2 Rear bed (if a flat screen is fitted (optional equipment))



When the mattress or the bed base on the rear bed is folded up the flat screen can be damaged.



Fig. 103 Flat screen above the rear bed

- Unlock flat screen and move it back into the initial position.
- Carefully fold up the mattress or bed base.



6.13.3 Pull-down bed, electrically operated



- ▶ Before setting off, move the pull-down bed into the top end position.
- ▶ The maximum permitted pull-down bed load is 200 kg.
- ▶ Do not reach into the area between the bed and the side wall when lowering or raising. Danger of bruises!
- ▶ Do not lower or lift the bed when there are people using the pull-down bed.
- ▶ If sockets are installed in the lowering range of the pull-down bed and devices are connected there: unplug devices before lowering the pull-down bed.
- ▶ Only lower the bed if the lowering area is clear.
- Only lower the pull-down bed so far that it does not lie on any obstacles such as headrests, cushions or anything similar. If possible, remove such obstacles before lowering.
- ▶ When loading the wall-mounted cupboard in which the drive shaft of the pull-down bed is installed, ensure that the drive shaft remains free. The drive shaft must be able to move unimpededly.
- ▶ Do not allow children to play with the pull-down bed.
- ► Store the key for the control unit such that children have no access to it.
- ▶ Only use the pull-down bed, if the safety net is set up.
- ▶ Use separate children's beds or travel cots suitable for children.
- ▶ Never allow small children to remain in the pull-down bed without supervision.
- ▶ But in particular with regard to small children less than 6 years of age, users should ensure that they cannot fall out of the pull-down bed.
- ▶ If an attachable seat is installed: remove attachable seat before lowering the pull-down bed.



> Before starting a journey, the pull-down bed must be in the top end position. Do not stow any bulky items or bedding on the pull-down bed so that the pull-down bed can move to the top end position.




Fig. 104 Control unit

- 1 Arrow key
- 2 Key switch
- 3 Control unit
- 4 Arrow key

Control unit

The pull-down bed is raised or lowered using the arrow keys (Fig. 104,1 and 4) on the control unit (Fig. 104,3). The control unit is protected against unauthorized use with the key switch (Fig. 104,2).

The pull-down bed's height may be adjusted steplessly.



Lowering the pull-down

- Removing any obstacles in the area into which the pull-down bed extends: Push the seats forwards and rotate; remove or fold cushions if necessary. Pull all device plugs out of the socket strips.
- Switch off the lamps underneath the pull-down bed.
- Turn the key in the key switch (Fig. 104,2) by 90° in a clockwise direction to position ON. The control unit (Fig. 104,3) is activated.
- Press the arrow key (Fig. 104,4) and keep it pressed until the pull-down bed has moved down into the desired position.
- Ensure that the pull-down bed is not resting on obstacles such as headrests, cushions or similar.

Lifting the pull-down bed:

- Switch off the reading lamps in the pull-down bed.
- Press the arrow key (Fig. 104,1) and keep it pressed until the pull-down bed has moved down into the final upper position.
- Ensure that there are no objects stuck between the roof and the pulldown bed.




Fig. 105 Pull-down bed complete with applied safety net

- 1 Safety nets
- 2 Retaining belt
- 3 Holder
- 4 Bow
- Access ladder



Fig. 106 Pull-down bed, completely lowered (dependent on model)

Safety net

The safety nets (Fig. 105,1) with their retaining belts (Fig. 105,2) are located underneath the mattress in the pull-down bed. Only use the safety nets if persons are already in the pull-down bed.



If the pull-down bed is lowered below 1 m (Fig. 106), it will not be possible to set up the safety nets.

Setting up:

■ Attach retaining belts (Fig. 105,2) to the hooks on the ceiling.



Access ladder

If the pull-down bed is raised over 1 m, only access the pull-down bed using the access ladder provided.

Attaching:

■ Hook both bows (Fig. 105,4) of the access ladder (Fig. 105,5) into the holders (Fig. 105,3).

Storing away:

- Release the access ladder (Fig. 105,5) from the holders (Fig. 105,3).
- Store the access ladder securely.

Emergency operation

If it is no longer possible to move the pull-down bed electrically, first check the fuse 25 A for the motor (on the transformer/rectifier) and the fuse 2 A for the control (F3, next to the transformer/rectifier). If the fuses are okay, but it is still not possible to move the pull-down bed, the pull-down bed can be operated manually with a crank.



- Depending on the model, the motor of the pull-down bed may be installed behind a panel or inside one of the wall-mounted cupboards.
- If present, pull lid off to obtain access to the mount for the crank.
- If the motor is installed into the wall-mounted cupboard: Open the wall-mounted cupboard on the left.
- Take mattress off from the pull-down bed and reduce the load of the possibly attached storage cupboards as far as possible.
- Insert the crank provided or an Allen wrench into the accommodation on the motor.
- Turn crank or Allen wrench manually until the pull-down bed has reached the upper parking position.
- Contact customer service.

6.13.4 Queen size bed in the rear, mechanically height-adjustable



► Lower the bed to its lowest position to sleep in it.



Before using the bed, make sure that the lever of the locking device (Fig. 108,2) is in the locked position (horizontal).

The height of the fixed bed can be adjusted via a crank in the rear garage. The bed can be raised before setting off. This increases the storage space under the bed.





Fig. 107 Queen size bed (example)




Fig. 108 Crank in the rear garage

Crank
 Lever

- Plug crank (Fig. 108,1) onto the journal of the drive.
- Swivel the lever (Fig. 108,2) downwards into vertical position.
- To lift the bed: Turn the crank (Fig. 108,1) clockwise.
- To lower the bed: Turn crank (Fig. 108,1) in an anticlockwise direction.
- Swivel the lever (Fig. 108,2) upwards into horizontal position.
- Remove the crank and store it.

Hinged panel

When the bed has been lifted to the uppermost position, a hinged panel allows the use of the rear garage.




Fig. 109 Panel (closed)

- 1 Panel
- 2 Locking device



1 Lever

Fig. 110 Panel (open)

Opening panel:

- Press locking device (Fig. 109,2) and fold panel (Fig. 109,1) upwards.
- Secure panel with lever (Fig. 110,1).

Closing panel:

- Press lever (Fig. 110,1) to the side and fold panel downwards.
- Secure panel with locking device (Fig. 109,2).

6.13.5 Protective panel / fall out protection

The scope of delivery of vehicles with rear single beds or rear transverse beds, in which the bed is installed at window height, includes a plug-in protective panel.

The protective panel protects the blinds in the lying area from accidental damage.

In addition, the protective panel serves as fall out protection in case the window is open.



Fig. 111 Protective panel / fall out protection




Fig. 112 Note on protective panel

Using the protective panel:

- Insert in the protective panel (Fig. 111) in front of the window, between mattress and window frame. The clamping effect of the mattress holds the protective panel in its position in front of the window frame.
- When the bed is not used (or before setting off), stow the protective panel underneath the mattress.



6.13.6 Width extension of rear bed



- ightharpoonup The maximum permitted load on the long shelf (Fig. 114) is 80 kg.
- Only use the long shelf when the additional cushion is put on.
- Follow the instructions on the stickers.

The two single beds in the rear can be converted into a combined lying surface.



Fig. 113 Short shelf (at the head end of the bed)

- 1 Short shelf
- 2 Flap

Enlarging the lying surface:

■ Remove the short shelf (Fig. 113,1).



Fig. 114 Long shelf (hooked in)

- Attach the long shelf (Fig. 114) to the edge of the single beds.
- Place the additional cushion on the shelf.




Folding the access ladder

out:



Fig. 115 Step (closed)

- - Open flap (Fig. 115,1 and Fig. 113,2).
 - Remove the panel (Fig. 115,2).



Step (open) Fig. 116

- Access ladder tread
- Narrow flap

Bar

Flap

Panel

1

2

- Fold the narrow flap (Fig. 116,2) to the front.
- Swivel the tread of access ladder (Fig. 116,1) outwards.



Access ladder (folded out)

Fold the bars (Fig. 117,1) fully out and set them down on the floor.



Depending on the equipment, there will be a safety net present. If there is a safety net, it must be used.



6.13.7 Lying surface extension of rear single bed (XXL bed)

The lying surface of the single bed on the right can be extended.



Fig. 118 Lying surface extension with additional cushion


Place the additional cushion (Fig. 118) on the shelf above the half-height wardrobe.


6.13.8 Conversion of L-seating group and individual seat into additional bed



Do not place a load onto the lowered table top until the cushions have been laid correctly on the table top. Otherwise the table could be damaged.

Together with the individual seat on the side and the shiftable lift-off table, the L-seating group can be converted into an additional bed. Two additional cushions are needed to create the lying surface. An additional board is also required, which is equipped with a fold-out support foot and a support bracket.








Fig. 120 After conversion

Setting up the additional bed:

- Shift shiftable lift-off table such that the table top can be lowered.
- Convert the shiftable lift-off table into a bed foundation (see section 6.10.1).
- Remove seat cushion from individual seat.

Fig. 121 Additional board

- 1 Additional board
- 2 Support bracket
- 3 Support foot

- Unfold the support foot (Fig. 121,3) on the additional board (Fig. 121,1).
- Attach the support bracket (Fig. 121,2) of the additional board to the individual seat.
- Place both additional cushions onto the table top.
- Attach the seat cushion of the individual seat again.

6.13.9 Conversion of divan and individual seat into additional bed



Do not place a load onto the converted table top until the cushions have been laid correctly on the table top. Otherwise the table could be damaged.

Together with the individual seat on the side and the lowered table top of the suspension table, the divan can be converted into an additional bed. Two additional cushions are needed to create the lying surface. An additional board is also required, which is equipped with a fold-out support foot and a support bracket.




Fig. 122 Prior to conversion




Fig. 123 After conversion

Setting up the additional bed:

- Convert the suspension table into a bed foundation (see section 6.10.4).
- Remove seat cushion from individual seat.






Fig. 124 Additional board

- 1 Additional board
- 2 Support bracket
- 3 Support foot

- Unfold the support foot (Fig. 124,3) on the additional board (Fig. 124,1).
- Attach the support bracket (Fig. 124,2) of the additional board to the individual seat.
- Place both additional cushions onto the table top.
- Attach the seat cushion of the individual seat again.



Chapter overview

This chapter contains instructions regarding the gas system of the vehicle. The operation of the gas operation appliances of the vehicle is described in chapter 9.

7.1 General instructions



- ► The operator of the gas system is responsible for the performance of recurring inspections and for complying with the maintenance intervals.
- ▶ If there is no DuoControl regulating system with crash sensor installed: Before commencing the journey, when leaving the vehicle or when the gas devices are not in use, close all gas isolator taps and the main regulator tap on the gas bottle.
 If there is a DuoControl regulating system with crash sensor installed, the gas isolator taps and the main regulator tap may remain open during the journey.
- ► All gas-operated devices (heater, cooker, oven, grill, refrigerator depending on the equipment) must be switched off for refuelling, on ferries or in the garage. Danger of explosion!
- ▶ Do not use gas-operated devices in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- Only have the gas system maintained, repaired or altered by an authorised specialist workshop.
- ► Have the gas system checked by an authorised specialist workshop according to the national regulations before commissioning. This also applies for not registered vehicles. For modifications to the gas system have the gas system immediately checked by an authorised specialist workshop.
- ► The gas pressure regulator, the gas tubes, and the exhaust gas pipes must also be inspected. The gas pressure regulator and the gas tubes must be replaced observing the nationally defined deadlines (the latest after 10 years). The vehicle owner is responsible for seeing that this is carried out.
- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.). Check the tightness of gas-conducting parts and lines with leakage search spray. Do not check with an open flame.
- ▶ Only the stipulated devices may be connected to internal connections. Do not operate any device outside the vehicle if it is connected to an internal connector.
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open a window or the skylight.
- ► Cooking is prohibited during the journey.
- Do not use gas-operated cooking and baking facilities for heating purposes.





- ▶ If there are several gas devices, each gas device must have its own gas isolator tap. If individual gas devices are not in use, close the respective gas isolator tap.
- ▶ Ignition safety valves must close within 1 minute after the gas flame has extinguished. A clicking sound is audible. Check function from time to time.
- ► The built-in gas devices are exclusively meant for use with propane or butane gas or a mixture of both. The gas pressure regulator as well as all built-in gas devices are designed for a gas pressure of 30 mbar.
- ▶ Propane gas is capable of gasification up to -42 °C, whereas butane gas gasifies at 0 °C. Below these temperatures no gas pressure is available. Butane gas is unsuitable for use in winter.
- ▶ Due to its function and construction, the gas bottle compartment is a space which is open to the exterior. Never cover or block up the standard forced ventilations. Otherwise gas that is emitted can not be diverted to the outside.
- ▶ The gas bottle compartment must not be used as storage space.
- Secure the gas bottle compartment against unauthorised access. To do this, lock the compartment.
- ► The regulator tap on the gas bottle must be accessible.
- ▶ Only connect gas-operated devices which have been designed for a gas pressure of 30 mbar.
- ► The exhaust gas pipe must be fitted tightly to the heating system and to the vent and must be sealed. The exhaust gas pipe must not show any evidence of damage.
- ► Exhaust fumes must be able to escape into the atmosphere unhindered and fresh air must be able to enter unhindered. For this reason, keep the exhaust pipe and intake openings clean and unobstructed (e.g. free from snow and ice). For this reason, no snow walls or aprons may lie against the vehicle.

7.2 Gas bottles



- ► Handle full or emptied gas bottles outside the vehicle only with closed regulator tap and attached protective cap.
- ► Gas bottles are only to be transported within the designated gas bottle compartment.
- Place the gas bottles in vertical position in the gas bottle compartment
- ► Fasten the gas bottles so that they are unable to turn or tilt.
- Connect the gas tube to the gas bottle without tension.
- ▶ If the gas bottles are not connected to the gas tube, always place the protective cap on top.
- ► Close the regulator tap on the gas bottle before the gas pressure regulator or gas tube are removed from the gas bottle.
- ▶ Depending on the connection, unscrew the gas tube from the gas bottle and screw it on the gas bottle again by hand or using an suitable special spanner. The screw connection on the gas bottle generally has a left-hand thread. Do not tighten too firmly.





- ▶ Only use special gas pressure regulators with a safety valve designed for vehicle use. Other gas pressure regulators are not permitted and cannot meet the demanding requirements.
- ► Use the gas pressure regulator defroster (EisEx) if the temperature falls below 5 °C.
- ▶ Use only 11 kg or 5 kg gas bottles. (The size of the gas bottles may vary depending on the country.)
- ▶ Use the shortest possible tube lengths (150 cm max.) for external gas bottles.
- ▶ Never block the floor ventilation openings below the gas bottles.



In some models, the gas bottle compartment is located right next to the living area door. In these models, only open the gas bottle compartment when the living area door is closed. Risk of damage.



- The screw connections on the gas bottles generally have a left-hand thread.
- Connect gas pressure regulator complete with safety valve directly to bottle valve.
- The gas pressure regulator reduces the gas pressure in the gas bottle down to the operating pressure of the gas devices.
- For filling and connecting the gas bottles in Europe the accessories shops have corresponding Euro filling sets and Euro bottle sets.
- ▷ Information available at the dealers or service centre.

7.3 Gas isolator taps




Fig. 125 Possible symbols for the gas isolator taps

- 1 Cooker
- 2 Hot water
- 3 Refrigerator
- 4 Oven/grill
- 5 Heater
- Hot water/heater

A gas isolator tap (Fig. 125) for every gas device is built into the vehicle. The gas isolator taps can be found under the cooker.






Fig. 126 Gas isolator taps position (example)

- Gas isolator tap open
- 2 Gas isolator tap closed
- 3 Gas pipe
- 4 Pipe to the gas device

Opening:

Position the gas isolator tap of the corresponding gas device parallel (Fig. 126,1) to the pipe (Fig. 126,4) leading to the gas device.

Closing:

■ Position the gas isolator tap of the corresponding gas device transverse (Fig. 126,2) to the pipe (Fig. 126,4) leading to the gas device.

7.4 External gas connection



- ▶ If the external gas connection is not in use, always close the gas isolator tap.
- Only gas appliances with a suitable adapter should be connected to the external gas connection.
- ► Connect only external gas appliances which are designed for an operation pressure of 30 mbar.
- Once you have made the connection and opened the gas isolator tap, make sure that no gas is escaping at the connection point. If there is a leak in the external gas connection, gas will escape into the open air. Immediately close the gas isolator tap and the regulator tap on the gas bottle. Have the external gas connection checked by an authorised specialist workshop.
- ▶ When connecting an external gas appliance, make sure that there is nothing near the external gas connection that could cause a spark.
- Only connect a gas appliance to the external gas connection. Do not use the external gas connection as supply (connection of an additional gas bottle).
- ▶ Do not use the external gas connection to fill gas bottles. Observe the information stickers on the external gas connection.






Fig. 127 External gas connection (gas isolator tap closed)

- Connection point
- Gas isolator tap

The external gas connection is located at the rear or to the left or right of the vehicle depending on the model.

- Connect the external gas device to the connection point (Fig. 127,1).
- Open the gas isolator tap (Fig. 127,2).

7.5 Gas bottle compartment pull-out

To facilitate the changing of gas bottles, the gas bottles and the DuoControl switching facility are stored in an extractable gas bottle compartment.



Fig. 128 Gas bottle compartment pull-out



Fig. 129 Knob with locking device

Pulling out the gas bottle compartment:

- Open flap (Fig. 128) for the gas bottle compartment.
- Pull the knob (Fig. 129) upwards. The gas bottle compartment pull-out is unlocked.
- Pull out the gas bottle compartment pull-out (Fig. 128) until the knob engages again. Now, the gas bottle compartment pull-out is locked in this position.

Changing the gas bottle:

Change the gas bottle as described in section 7.9.





Fig. 130 Gas bottle compartment pull-out in changing position

Pushing in the gas bottle compartment:

- Pull the knob (Fig. 129) upwards. The gas bottle compartment pull-out is unlocked.
- Push the gas bottle compartment pull-out (Fig. 130) inwards until the knob engages again.
- Close flap.

7.6 Gas bottle compartment



Do not grab external flap of the gas bottle compartment by the bottom panel (Fig. 131,1). Grab the external flap by the sides for opening and closing.



Fig. 131 Gas bottle compartment (external flap open)

1 Panel, gas bottle compartment external flap



7.7 Gas pressure regulating system DuoControl CS



- The regulating system and the hose lines shall be changed at the latest 10 years after manufacturing date. The operator is responsible for this.
- Also read the manufacturer's instruction manual.

DuoControl CS is a safety gas pressure regulating system with automatic switching for a two-bottle gas system and with crash sensor. The DuoControl regulating system automatically switches the gas supply from the primary bottle to the reserve bottle as soon as the primary bottle is either empty or no longer ready for operation. The gas appliances may still continue operation. The DuoControl regulating system is suitable for all commercial gas bottles with liquefied gas (propane/butane) and a pressure of 0.7 bar to 16 bar.

The DuoControl regulating system ensures a constant gas pressure for the gas-operated devices, no matter which gas bottle is supplying the gas.

In the event of an accident, the crash sensor in the DuoControl regulating system will interrupt the gas flow.

The gas bottles are connected via high pressure hoses. A hose break guard prevents gas leakage in the event of a damaged hose.

The operation of gas-operated devices during the journey is permitted in all of Europe if the vehicle is equipped with a gas pressure regulating system with crash sensor and high-pressure hoses with hose break guard.




Fig. 132 Safety gas pressure regulating system DuoControl CS

- Regulator tap
- Hose break guard 2
- High-pressure hose
- 4 Gas filter
- 5 Status indicator - primary bottle / reserve bottle (green/red)
- Knob for primary bottle / reserve bottle change-over
- Screw cap (test connection)
- Reset button of the crash sensor (yellow)

Construction of the unit

The DuoControl regulating system consists of a reversing valve and a crash sensor. The DuoControl regulating system is installed between the highpressure hoses (Fig. 132,3) with hose break guard (Fig. 132,2). The knob (Fig. 132,6) on the reversing valve is used to select which of the gas bottles is to be used as primary bottle and which is to be used as reserve bottle.

The status of the gas supply is indicated in the inspection window (Fig. 132,5):

Green: Primary bottle Red: Reserve bottle.



The operation with only one gas bottle is allowed but in this case the open connection must be closed with a blind cover.

Crash sensor

The crash sensor blocks the gas supply in the event of a significant impact (e.g. accident). The situation of the yellow reset button (Fig. 132,8) indicates the operating status of the crash sensor:

- If the yellow reset button (Fig. 132,8) is in the pressed-in position, the crash sensor is ready to operate.
- If the yellow reset button (Fig. 132,8) is protruding, the crash sensor is not ready to operate. Putting into operation, see below.

Hose break guard

The hose break guard (Fig. 132,2) blocks the gas flow if the connected hose breaks. The hose break guard must be activated by pressing the green button

EisEx (defroster)

The DuoControl regulating system can be heated (EisEx). If winter operation is set at the operating unit, the DuoControl regulating system will be heated automatically. Thus, faults of the gas system due to frost in winter are prevented.




Fig. 133 Operating unit (DuoControl)

- Yellow indicator lamp, EisEx (defroster)
- 2 Winter operation position
- 3 OFF position
- 4 Summer operation position
- 5 Red indicator lamp, primary bottle empty
- 6 Green indicator lamp, supply from primary bottle
- 7 Rocker switch

Operating unit

The operating unit shows the status of the primary bottle. When the green indicator lamp (Fig. 133,6) illuminates, the primary bottle is full. When the red indicator lamp (Fig. 133,5) illuminates, the primary bottle is empty. In this case, the reserve bottle is used for the gas supply.

If the heater of the DuoControl regulating system (defroster) is active, the yellow defroster indicator lamp (Fig. 133,1) is lit.

In addition, the operating unit (Fig. 133) is also used to set summer operation or winter operation.

Setting summer operation:

■ Press lower part of the rocker switch (Fig. 133,7) (summer operation position (Fig. 133,4)).

Setting winter operation:

Press upper part of the rocker switch (Fig. 133,7) (winter operation position (Fig. 133,2)).

Putting into operation:

- Connect the gas bottles.
- Use the knob (Fig. 132,6) on the reversing valve to select the gas bottle which is to be the primary source of gas (primary bottle). Always turn the knob as far as it will go.
- Open the regulator taps (Fig. 132,1) on the gas bottles.



- Press and hold the green button of the hose break guard (Fig. 132,2) for about 5 seconds. The green marking is shown in the inspection window (Fig. 132,5).
- If the crash sensor has triggered (the yellow reset button (Fig. 132,8) is protruding):

Press the yellow reset button (Fig. 132,8) in forcefully, turn it slightly in a clockwise direction and hold it for about 5 seconds. Make sure that the reset button remains in the pressed-in position ("ready for operation"). If it is not possible, reset the system as described: Use the Torx insert T20 on the included screwing aid to strengthen the rotary movement.

Switching off:

- Set the rocker switch (Fig. 133,7) to the OFF position (Fig. 133,3). The indicator lamps go out.
- Close the regulator taps (Fig. 132,1) on the gas bottle.

Changing gas bottles



- ▶ When changing gas bottles, do not smoke or create any open fire.
- ▶ When you have changed the gas bottle, check whether gas escapes at the connection points and unions. Use a leakage search spray to spray the relevant connection point or union. These agents are available at the accessories shop.



- Use the included screwing aid to screw the high-pressure hoses on and off. The screwing aid makes the required tightening torque possible and prevents any damage caused by using the wrong tool.
- If there is a gas filter present, also change the filter pad with every change of gas bottles (see section 12.6).

If the green indicator lamp (Fig. 133,6) goes out during operation and the red indicator lamp (Fig. 133,5) lights up, the primary bottle is empty and must be changed. The red marking is shown in the inspection window (Fig. 132,5) of the associated gas bottle. The reserve bottle continues supplying the gas appliances with gas.

You may also change an empty gas bottle while gas-operated devices are in operation.

Changing the gas bottle:

- Turn the knob (Fig. 132,6) as far as it will go in the direction of the gas bottle currently used. In this way, this gas bottle is the primary bottle now, and the empty gas bottle becomes the reserve bottle. The marking in the inspection window (Fig. 132,5) changes from red to green.
- Close the regulator tap (Fig. 132,1) on the empty gas bottle. Pay attention to the direction of the arrow.
- Unscrew the high-pressure hose from the empty gas bottle (normally a left-hand thread).
- Release the fixing belts and remove the empty gas bottle.
- Place a filled gas bottle in the gas bottle compartment and retain with the fixing belts.
- Connect the high-pressure hose to the filled gas bottle (normally a lefthand thread).
- Open the regulator tap on the gas bottle.
- Press the green button of the hose break guard (Fig. 132,2).




7.8 Gas filter



▷ If the gas pressure regulating system fails due to oiling or due to foreign substances, no warranty claim can be made for the gas pressure regulating system.

The gas filter (Fig. 134,1) must be checked periodically. When changing the gas bottles, the filter pad must be replaced (see section 12.6).



1 Gas filter

Fig. 134 Gas filter



> Further information can be obtained in the manufacturer's instruction manual.



7.9 Changing gas bottles



- When changing gas bottles, do not smoke or create any open fire.
- After changing the gas bottles, check whether gas is leaking at the connection points. To do this, spray the connection point with leakage search spray. These agents are available at the accessories shop.



The procedure described below applies to vehicles that are equipped with a single gas connection. If the vehicle is equipped with an regulating system: When changing the gas bottle, proceed as described for the regulating system.




Fig. 135 Gas bottle connection

- Gas tube
- Gas pressure regulator 2
- 3 Knurled nut
- Regulator tap

- Open flap for the gas bottle compartment.
- Close the regulator tap (Fig. 135,4) on the gas bottle. Pay attention to the direction of the arrow.
- Hold the gas pressure regulator (Fig. 135,2) and open the knurled nut (Fig. 135,3) (normally a left-hand thread).
- Remove the gas pressure regulator and the gas tube (Fig. 135,1) from the gas bottle.
- Release the fixing belts and remove the gas bottle.
- Place a filled gas bottle in the gas bottle compartment.
- Fix gas bottle in place with the fixing belts.
- Position the gas pressure regulator (Fig. 135,2) with gas tube (Fig. 135,1) on the gas bottle and tighten the knurled nut (Fig. 135,3) (normally a left-hand thread). Do not tighten too firmly.
- Close flap for the gas bottle compartment.





Chapter overview

This chapter contains instructions regarding the electrical system of the vehicle.

The operation of the electrical appliances of the housing body is described in chapter 9.

8.1 General safety instructions



- ▶ Only allow qualified personnel to work on the electrical system.
- ▶ All electrical devices (e.g. mobile phones, radios, televisions or DVD players) that are retrofitted into the vehicle and operated during the journey must have a CE marking and be verifiably tested according to DIN VDE 0100 721. Please contact an authorised specialist workshop.

Only in this way can the functional reliability of the vehicle be ensured. Otherwise the airbag may be triggered or interference to the on-board electronics may result.



After the vehicle is started, delays to the output or forwarding of electrical impulses are possible.

The control unit of the basic vehicle does not release the D+ signal until the engine has reached full performance. In the event of a cold start in winter, this can take up to 15 seconds.

For this reason, output of warning signals (such as "entrance step extended") may sometimes be delayed.

The automatic retraction of a SAT antenna can also be delayed.

During a storm, to protect the electrical devices disconnect the 230 V connection and retract the antennae.

8.2 Terms

Off-load voltage

The off-load voltage is the voltage of the battery in idle condition, i. e. no current is consumed and the battery is not being charged.



The battery must remain idle for a while before measuring. After charging the last time, or after the last current has been drained by appliances, wait approximately 2 hours before measuring the off-load voltage.

Closed circuit current

Some electrical appliances, such as indicator lamps, TV unit or USB sockets, require electrical current all the time; that is why they are also referred to as inactive appliances. This closed circuit current flows even if the device has been switched off.

Total discharge

Total discharge of the battery is imminent, if a battery is completely discharged by an active appliance and by closed circuit current and the off-load voltage falls below 12 V.





Capacity

Capacity refers to the amount of electricity which can be stored in a battery.

The capacity of a battery is given in ampere hours (Ah). The so-called K20 value is normally used.

The K20 value indicates how much current a battery can deliver over a period of 20 hours without being damaged.

For example, if a battery can dispense 4 amps for 20 hours, then it has a capacity of $4 \text{ A} \times 20 \text{ h} = 80 \text{ Ah}$.

If more current flows, the discharging time of the battery will decrease proportionately.

External influences, such as temperature and age may alter the storage capacity of the battery. Capacity details refer to new batteries operating at room temperature.



- Depending on battery technology, capacity details have a conversion factor of 1.3 to 1.7, which lowers the real capacity by this value.
- A practical example is shown in section 8.4.4.

8.3 Bluetooth connection



The Bluetooth connection is only available in combination with a multimedia system installed in the vehicle.

With the Bluetooth connection, you can connect the installed multimedia system wirelessly to a compatible mobile device (smartphone or tablet computer).

Both devices must be connected with each other before you can use the Bluetooth connection. This process is called pairing. The pairing is only required once for each mobile device.





Fig. 136 Rocker switch (Bluetooth connection)

Pairing the mobile device (only if equipped with a DSP box):

- Press upper part of rocker switch (Fig. 136) and hold approximately 2 seconds until the LED in the rocker switch is flashing.
- Connect the mobile device within 60 seconds (refer to the instruction manual of the mobile device). The multimedia system is visible as "HY BT-DSP PP85" during pairing.

The LED in the rocker switch will be flashing for approximately 60 seconds. During this time, the multimedia system is in the pairing mode and can be connected to the mobile device. Once the mobile device has been paired, you can switch the connection on and off with the rocker switch.

Switching off Bluetooth connection:

Press the lower part of the rocker switch (Fig. 136). The LED goes out.

Switching on Bluetooth connection:

 Switch rocker switch (Fig. 136) to the central position. The LED of the rocker switch is lit.

Technical information

Distance: The devices do not need to be positioned in direct line of sight. The maximum distance between the devices must not exceed 10 m. Obstacles such as walls or other electronic devices may impair the connection.

Compatibility: The function depends on the Bluetooth technology of the mobile device (refer to the instruction manual of the mobile device).

Technical data:

Bluetooth standard: V3.0+DER

Bluetooth profile: A2DP

Bluetooth codec: SBC and aptX

Maximum quantity of paired devices: 8




8.4 12 V power supply



- Only connect devices with a maximum of 10 A to the sockets of the 12 V power supply.
- Connect only devices with a maximum of 2.5 A to the USB sockets.

8.4.1 USB socket



USB A port
 USB C port

Fig. 137 USB socket

The vehicle is equipped with several USB sockets as standard. The USB sockets each contain a connection for a USB A plug (Fig. 137,1) and a connection for a USB C plug (Fig. 137,2).

8.4.2 Starter battery

The starter battery serves for starting the engine and supplies the electrical appliances of the base vehicle as well as optional devices such as the radio, navigation system or central locking system with voltage.



- ➤ Total discharge damages the battery. The consequence may be deformation, heat development, and damage due to scorching.
- Once a battery with acid is discharged, it can freeze in temperatures of below zero. This damages the battery.
- Recharge battery in good time.

The starter battery will be totally discharged via a closed circuit current (inactive appliances). Inactive appliances are optional devices such as a radio, alarm system, navigation system or a central locking system. Inactive appliances discharge the starter battery when the vehicle engine is switched off.

Low temperatures outside reduce the capacity available.



If the radio unit is used on Mercedes-based vehicles without the vehicle engine running, the radio unit will put a load on the starter battery. However, in order to always maintain the vehicle's starting ability, it may not be possible to operate the radio (depending on the charging condition of the starter battery).

Charging

Safety instructions and information on charging the starter battery, see instruction manual of the base vehicle.



Position

The starter battery is fitted in the footwell of the driver's cabin under a floor trap.

8.4.3 Living area battery (HYMER Smart Battery System)

The **HYMER** Smart Battery System with two lithium batteries is installed in the vehicle.



- Do not make any changes to the installation of the living area battery carried out at the factory.
- Do not open the living area battery.
- Doserve the recommended operating temperature between 15 and 25 °C. Take any further details on the operating temperature from the manufacturer's instruction manual.
- > Switch the transformer/rectifier of for installation and maintenance.
- Remove the fuses between starter battery and living area battery for installation and any work on the wiring.
- > Transport and dispose of the living area battery only as prescribed by the manufacturer.
- Observe the manufacturer's instruction manual.
- Prior to commencing a journey ensure the living area battery is completely charged. Charge the living area battery for at least 20 hours before commencing the journey.
- During the trip, use every opportunity to charge the living area battery.

- Disconnect the living area battery from the 12 V power supply when the vehicle is not in use and check the voltage regularly.

The living area battery has a service life of up to 10 years if used correctly. It is equipped with a protection function against overloading and deep discharge.

When the vehicle is not connected to the 230 V power supply or the 230 V power supply is switched off, the living area battery supplies the living area with 12 V DC. The living area battery has a limited power supply only. For this reason, electrical appliances such as the radio and the lights should not be operated for a long time without using the 230 V power supply.



Technical data of the living area battery

Nominal voltage	12.8 V DC	
Battery cells	LiFePO4	
Usable lithium capacity	80 Ah/1024 Wh	
Number of cycles at a temperature range between 1 °C and 25 °C	3000 full cycles (then 80 % residual capacity)	
Number of cycles at a temperature range between 0.3 °C and 25 °C	> 5000 full cycles (then 80 % residual capacity)	
Continuous charge/discharge current	Max. 80 A	
Weight	9.9 kg	
Operating temperature (charging)	-30 °C to +60 °C (integrated heater active between -30 °C and +10 °C)	
Operating temperature (discharging)	-20 °C to +60 °C	
Protection functions	Overcurrent, overvoltage, short circuit, overcharge, deep discharge, reverse polarity protection, temperature protection	

Position

The living area battery is installed in the double floor and accessible via a service cover between the living area door and the seating group.

Display

The voltage and charge data of the battery system are displayed on the 7" panel.



Fig. 138 Start screen of the 7" panel

- 1 Starter battery voltage indicator
- 2 Living area battery voltage indicator

The start screen shows the voltage of the starter battery (Fig. 138,1) and the status of the living area battery (Fig. 138,2).



By navigating the display, further information on the starter battery and the living area battery can be called up.

Display of total state of charge (SoC)

The total state of charge is displayed on the 7" panel and in the main menu Vehicle details (Fig. 138) under BOS battery. The total state of charge is referred to as the "State of Charge" (SoC). The value of the SoC is displayed as a percentage and, additionally, as a bar chart.

Charging

Only use the installed transformer/rectifier to charge the living area battery. Therefore, connect the vehicle to an external 230 V power supply system as often as possible. As a principle, only use the 230 V connection on the vehicle (CEE socket outlet) for connecting.

Fully charge the battery system after recommissioning or longer periods of inactivity.



At temperatures below 0 °C, the living area battery consumes less power. At approx. -15 °C, there will be no more power. The living area battery can no longer be charged.



If the living area battery is charged via an "intelligent" charger with float charge functionality, the charger can be connected to the battery and switched on over the entire lay-up time.

Discharging

The closed-circuit current (power consumption in standby) that some electrical appliances constantly consume discharges the living area battery.

An older battery no longer has the complete capacity available.

The higher the number of active electrical appliances, the faster the energy of the living area battery is consumed.



Reset the battery after a total discharge.

Storage

Prior to storage, fully charge the battery system and disconnect it from the transformer/rectifier (switch off battery cut-off switch on the transformer/rectifier).

At the latest, check the charge status on the display of the living area battery after 6 months. When the battery cut-off switch is switched off, the charging condition of the living area battery can drop to approx. 40 to 80 %. To check the charging condition, switch on the battery cut-off switch on the transformer/rectifier. Charge battery if necessary.

In case of a longer storage period: charge and discharge the living area battery several times if necessary to obtain full performance of the battery system.

Store the battery system in a place that is dry, cool, and well ventilated.

Observe the recommended storage temperature between 10 and 20 °C. Take any further details on the storage temperature from the manufacturer's instruction manual.



Battery change



When changing batteries, use only batteries which meet the minimum capacity of the charger. Observe the separate instruction manual for the charger. Lower-capacity batteries will generate a great deal of heat when they are charged. Danger of explosion!

When the living area battery is changed, only use batteries of the same type and the same capacity. Living area batteries must have a capacity of at least 80 Ah.

Only use batteries for which there are charging characteristics available. After changing the battery the charging characteristics must be adjusted at the transformer/rectifier or at the auxiliary charging unit.

If the living area battery is replaced and the charging unit does not provide a charging current of at least 10 % of the rating of a new battery, install an auxiliary charging unit.

Example

With a battery capacity of 80 Ah, the charging unit must supply at least 8 A charging current.



- ▷ Before disconnecting or connecting the terminals of the battery, switch off the vehicle engine as well as the 230 V and 12 V power supplies and all appliances. Danger of short circuit!
- ▷ If the starter battery or living area battery are disconnected, do not apply the ignition. There is a danger of short circuit from exposed cable ends.
- When changing, ensure that the batteries are properly installed. Install the batteries so that the positive terminal on one battery is lying next to the negative terminal of the other battery.
- When changing, ensure that the batteries are properly connected.

Changing the battery:

- Turn off the vehicle engine.
- Switch off all appliances.
- Switch off 230 V power supply.
- Switch off 12 V power supply.
- Disconnect the negative terminal.
- Disconnect the positive terminal.
- Remove the old battery.
- Insert the new battery in the correct position.
- Connect the positive terminal.
- Connect the negative terminal.
- Switch on 12 V power supply.
- Switch on 230 V power supply.
- Switch on consumers as required.



After changing the battery, have the battery voltage indicators checked at an authorised specialist workshop / service centre.



8.4.4 Energy balance of the living area battery

The living area battery has a limited power supply only. For this reason, the electrical appliances should not be operated without a 230 V power supply for a longer period of time.

Below, the calculation of the maximum operating time of the currently available battery capacity is described.



- The example calculation refers to a new, optimally charged battery. The actual effective battery capacity depends on the current charging condition and the age of the battery. The current battery capacity can be determined by means of special indicator units.

- Record the daily requirement. Note the switching on times and the power output of the devices used (see table below).

Example:

The television (power consumption 36 W) with satellite unit (power consumption 36 W) is in operation every day for 2 hours.

Convert the power data into the required capacity in accordance with the following formulas:

Power consumption [W]: 12 V = Current [A]
Current [A] x Operating time [h] = Capacity [Ah]

36 W + 36 W = 72 W 72 W : 12 V = 6 A 6 A x 2 h = 12 Ah

The table for a whole day could look like this:

Balance of energy consumption (example)

Appliance	Power consumption [W]	Current [A]	Operating time [h]	Capacity [Ah]
Submerged pump	42	3.5	0.1	0.35
Heater	12	1.5	3.0	4.50
Television	36	3.0	2.0	6.00
Satellite unit	36	3.0	2.0	6.00
Refrigerator control	2	0.2	24.0	4.00
Lighting (10 LED lamps à 2 W)	20	1.6	3.0	4.80
Average daily requirement				25.65

 Calculate the maximum effective energy with the following formula or determine it with a special indicator unit:
 Current capacity [Ah]: Deep discharge protection = Maximum effective energy [Ah]



Example: 95 Ah : 1.4 (lead battery) = 67.9 Ah

Calculate the maximum operating time in accordance with the following formula:

Max. effective energy [Ah]: Daily requirement [Ah] = Max. operating time (in days)

Example: 67.9 Ah : 25.65 Ah = 2.65

The current battery capacity would be sufficient for more than two and a half days if the daily requirement remains the same.

Solar cells The independent time period can be extended with use of the solar cells.

Two solar cells of 90 W produce the following gain:

- Summer: Approx. 60 Ah/day (independent operation reached)
- Winter: Approx. 15.5 Ah/day (in order to prolong independent operation, another living area battery must be installed)

8.4.5 Retrofitting an AC converter



Retrofitting of an AC converter can lead to damage to the electrical system. We will not be held liable for this damage.

The installation of a 230 V AC converter results in a very high current load. For example an AC converter with a power output of 800 W on the 12 V side has a current consumption of up to 75 A.

This current is much too big for the outputs on the transformer/rectifier (see section 8.13.1).

If the AC converter is connected directly to the battery, the current consumption of the AC converter will not be indicated by panel. Due to the high discharging current, the terminal voltage in the battery drops significantly. The measuring system installed then detects undervoltage and could switch off the 12 V power supply. In addition the living area battery will be drained very quickly if an AC converter is used.

8.5 Transformer/rectifier (EBL 402)



► The unit contains parts that carry 230 V line voltage. Potentially fatal electric shock or fire hazard!

Do not carry out any maintenance or repair work on the unit. If the cable or housing is damaged, do not put the unit into operation and disconnect it from the mains supply. Do not allow liquid to enter the unit.

- Replace defective fuses only when the unit is de-energised.
- Only replace defective fuses when the cause of the defect is known and has been remedied.
- Never bypass or repair fuses.
- Only use original fuses with the values specified on the unit.
- Device components can get hot during operation. Do not touch.
- ▶ Do not cover the ventilation slots. Danger of overheating!





- ▶ Do not store any heat-sensitive objects close to the unit (e.g. temperature-sensitive clothes if the unit is installed in the wardrobe).
- ▶ Observe the safety instructions and information in the separate device manufacturer's instruction manual.



- An extended period of total discharge may cause irreparable damage to the living area battery. Therefore, fully charge the living area battery before and after a lay-up.
- ➤ The transformer/rectifier, 12 V appliances or connected devices can be damaged if the limit values of the 230 V mains voltage are exceeded. Therefore, remember that it is essential for a generator to remain within the mains power ratings.
- Do not connect the vehicle to a generator until the generator is in stable operation.
- When on car ferries, do not connect the transformer/rectifier to the mains voltage (a perfect mains voltage is not always guaranteed with the mains supply on car ferries).




Fig. 139 Transformer/rectifier (EBL 402)

- 1 Block 3 SYNCCHARGE®
- 2 Battery cut-off switch ("Batterie Ein/Aus" (battery on/off))
- 3 Block 10 TSF01 (parallel to block 9)
- 4 Block 6 Solar charge regulator
- 5 Block 1 Refrigerator
- 6 AES 20 A fuse (only if vehicle is equipped with an AES refrigerator)
- Block 2 Input D+, starter battery, refrigerator control
- 8 Block 4 Heater, Step
- 9 Block 18 Independent vehicle heater (not assigned)
- 10 Block 5 Power supply for 12 V appliances
- 11 Block 8 Power supply for 12 V appliances
- 12 Block 7 Auxiliary charging unit (not assigned)
- 13 Flat fuses (protection for the 12 V appliances)
- 14 Solar fuse (not assigned)
- 15 Fuse, Internal charger module
- 16 Block 11 LIN BUS
- 17 Block 9 TSF01 (parallel to block 10)
- 18 Block 12 (not used)
- 19 Block S1 Fresh water probe
- 20 Block S2 Waste water probe/sensors
- 21 Block S4, block S5, block S6 LIN BUS



Position

The transformer/rectifier is installed in the double floor and accessible via a service cover between the living area and the kitchen.

Operation

The transformer/rectifier is operated with the connected 7" operating panel (exception: battery cut-off for lay-up, see below).

In normal operation, no operating steps are required on the transformer/rectifier

In following cases, adjustments are required:

- For initial commissioning.
- When the battery type is changed.
- When accessories are retrofitted.

This adjustment work must be carried out by an authorised service centre.

Purpose

Together with the control unit SCU and the BUS modules, the transformer/rectifier EBL 402 forms the central control and power supply system for all 12 V appliances in the electrical system on board of the vehicle.

Functions

- The transformer/rectifier charges the living area battery. The transformer/rectifier charges the starter battery with a float charge only.
- The transformer/rectifier monitors the voltage in the living area battery.
- When the vehicle engine is turned off, the transformer/rectifier separates
 the starter battery electrically from the living area battery. This prevents
 the 12 V living area appliances from discharging the starter battery.
- The transformer/rectifier controls and monitors connected solar charge regulators and auxiliary charging units.
- The transformer/rectifier supplies all BUS modules and the connected sensors and appliances with current.
- Via BUS lines, the transformer/rectifier provides the communication with the BUS modules, the panel will and the control unit SCU.

The transformer/rectifier only works in conjunction with a BUS-capable panel.

The power in the transformer/rectifier is divided into charging current and current to the appliances. The charging current is always just the portion that is not being used by any appliances. If the current to the appliances exceeds the current available, then the living area battery is discharged.

Lay-up

Some circuits are still supplied with current even when the 12 V power supply is switched off on the panel. These are all appliances connected to the 12 V constant positive, for example:

- Entrance step
- Heater

When the vehicle is laid up, these appliances are also disconnected from the battery.

Lay-up:

- Switch off the 12 V power supply on the panel.
- Move the battery cut-off switch (Fig. 139,2) to the "Aus" (Off) position on the transformer/rectifier EBL 402.

146





When the battery cut-off switch is switched off, the central locking system only opens the driver's door or, depending on the vehicle, also the passenger's door. If the vehicle is laid up, the living area door must be unlocked manually using the mechanical key (see section 6.1.1).

Coming out of lay-up:

- Move the battery cut-off switch (Fig. 139,2) to the "Ein" (On) position on the transformer/rectifier EBL 402.
- Switch on the 12 V power supply on the panel.



Further information can be obtained in the manufacturer's instruction manual.

Panel (LT 94) 8.6




Fig. 140 Panel (LT 94)

- Indicator scale for battery voltage
- Indicator scale for tank fill level
- 3 Alarm warning light
- 4 12 V indicator lamp
- 5 Rotary knob
- Starter battery symbol 6
- Waste water tank symbol
- Water tank symbol
- Living area battery symbol
- 10 230 V indicator lamp



Further information can be obtained in the manufacturer's instruction manual.



8.6.1 Switching the 12 V power supply on/off

The rotary knob (Fig. 140,5) switches the panel and the 12 V power supply to the living area on and off.

Exception: Heater, basic light (lighting in the entrance area), entrance step and the refrigerator are always ready to operate.

Switching on:

Press the rotary knob (Fig. 140,5): The 12 V living area power supply is switched on. The 12 V indicator lamp (Fig. 140,4) lights up.

Switching off:

■ Press the rotary knob (Fig. 140,5): The 12 V living area power supply is switched off. The 12 V indicator lamp (Fig. 140,4) goes out.



- When leaving the vehicle, switch off the main 12 V power supply at the rotary knob. This prevents any unnecessary discharge of the living area battery.
- Appliances, such as control units (e.g. solar charge regulator, defroster or panel) or fitted appliances (e.g. heater, refrigerator or step) continue to take power from the battery capacity, even if the 12 V power supply on the panel is switched off. Therefore disconnect the living area battery from the 12 V power supply via the switch on the transformer/rectifier if the vehicle will not be used for a long period of time.

8.6.2 Battery voltage display



- The panel shows the battery voltage of the entire battery system. If the vehicle has a *HYMER* Smart Battery System (optional equipment), a further display panel is installed. You can read the exact voltage values on this additional display panel.
- The battery voltage will be displayed for approx. 20 seconds after it has been called up.

Use the rotary knob (Fig. 140,5) for reading the voltage of the living area battery as well as that of the starter battery. The voltage is displayed on the indicator scale for battery voltage (Fig. 140,1).

Displays:

■ Turn the rotary knob (Fig. 140,5) until the symbol for the desired battery lights up.

Symbol	Meaning
	Living area battery voltage is displayed (Fig. 140,9)
	Starter battery voltage is displayed (Fig. 140,6)

Read the voltage from the indicator scale for battery voltage (Fig. 140,1).



The following tables will help you to correctly interpret the battery voltage display.

Notes regarding the battery voltage

Battery voltage (values during operation)	Mobile operation (vehicle moving, no 230 V connec- tion)	Battery operation (vehicle station- ary, no 230 V con- nection)	Power operation (vehicle station- ary, 230 V con- nection)
Less than 11 V Danger of total discharge	No charging via the alternator	If appliances are switched off: Battery flat	No charging via the transformer/rectifier
	12 V power supply overload	If appliances are switched on: Bat- tery overload	12 V power supply overload
11.5 V to 13 V	No charging via the alternator 1) Normal range		No charging via the transformer/rectifier 1)
	12 V power supply overload 1)		12 V power supply overload 1)
13.5 V or more	Battery being Occurs only briefly charged Battery bei charged charged		Battery being charged

¹⁾ If the voltage does not exceed this range for several hours.

Values for off-load voltage	Charging condition of the battery
Less than 12 V	Totally discharged
12.2 V	25 %
12.3 V	50 %
More than 12.8 V	100 %



Total discharge causes irreparable damage to the battery.



Measure the off-load voltage preferably several hours after the previous charging (e.g. in the morning) and not directly after a current drain.

8.6.3 Displaying the tank level



The tank fill level will be displayed for approx. 20 seconds after it has been called up.

Use the rotary knob (Fig. 140,5) for checking the fill level of the water tank or the waste water tank. The fill level is displayed on the indicator scale for the tank fill level (Fig. 140,2).



Displays:

■ Turn the rotary knob (Fig. 140,5) until the symbol for the desired tank lights up.

Symbol	Meaning
	The level of the water tank is displayed (Fig. 140,8)
	The level of the waste water tank is displayed (Fig. 140,7)

Read the level from the indicator scale for the tank fill level (Fig. 140,2).



▷ If the indicator scale displays flash while the fill level is being checked, a sensor error has occurred. Clean sensors or contact customer service.

8.6.4 Alarms

The Alarm warning light (Fig. 140,3) flashes if set limit values are exceeded or fallen below.

Battery alarm

The Alarm warning light (Fig. 140,3) flashes if the battery voltage falls below 11 V. If the 12 V power supply is switched on, the relevant battery symbol (Fig. 140,6 or 9) also lights up and "11.0" starts flashing on the indicator scale for battery voltage (Fig. 140,1). Danger of total discharge.



Total discharge damages the battery.



If the voltage of the batteries falls below 10.5 V, the battery monitor in the transformer/rectifier switches off all the 12 V appliances.

Measures:

When the battery alarm comes on, switch off all appliances and charge the battery, either by mobile operation or by connection to a 230 V power supply.

Tank alarm

The Alarm warning light (Fig. 140,3) starts to flash and the corresponding tank symbol (Fig. 140,7 or 8) lights up as soon as the water tank is empty or the waste water tank is full.

Measures:

Fill water tank or empty waste water tank.

230 V indicator lamp



If the vehicle is connected to the 230 V power supply, the 230 V indicator lamp is lit even if the 12 V power supply is switched off via the rotary knob.

The 230 V indicator lamp (Fig. 140,10) illuminates whenever line voltage is available at the transformer/rectifier input.



8.7 7" panel

The 7" panel is only installed if the vehicle is equipped with a BUS system (optional). (Other components of the BUS system are the transformer/rectifier EBL 402, the system control SCU and the HYMER Connect app). Various functions can be displayed, monitored and controlled on the 7" panel. The 7" panel can be connected to the HYMER Connect app.



3

tion and Water tanks fill level Display field HYMER Connect App 2

Display field Battery charging condi-

Main menu

7" panel, start screen

Position

The 7" panel is installed above the living area door.

Start screen

The start screen (Fig. 141) shows the following information:

- Charging condition of the batteries
- Fill level of fresh water and waste water tank
- Information of the HYMER Connect App
- Main menu

Further sub menus can be called up via the buttons in the main menu line.

8.8 **HYMER Connect App**

Mobile devices can be connected to the vehicle via the HYMER Connect арр.

Requirements for connecting the mobile device to the SCU:

- Completed installation of the HYMER Connect app on a mobile device
- Vehicle QR code
- Compatible vehicle equipped with a SCU

For each vehicle equipped with a SCU, a main user can connect to the SCU via their mobile device (using the HYMER Connect app and the vehicle QR code). This main user can create guest accesses for other mobile devices via the HYMER Connect app and also manage them there.



- The HYMER Connect app is available free of charge in the Apple App Store (iOS) and the Google Play Store (Android).
- The vehicle QR code can be found in the vehicle's document pocket. Keep the vehicle QR code in a safe place. If the vehicle QR code has been lost, contact the manufacturer's customer service or an authorised dealer.

To connect the mobile device to the vehicle, follow the instructions in the HYMER Connect app.



8.9 System Control Unit (SCU)



- - https://www.hymer.com/de/en/connect-app
 - The FAQs are constantly being expanded.
- ▶ When the SCU fails / is faulty, contact an authorised specialist workshop.

The SCU takes over central control and monitoring functions in the vehicle. The control and monitoring functions are operated on the 7" panel or using the HYMER Connect app. Operation on the SCU is limited to starting the connection process (pairing).




Fig. 142 System Control Unit

- 1 LED indicator (green)
- 2 Pairing button to connect with Bluetooth-enabled device
- 3 LED indicator (blue)
- Bluetooth antenna connection (curry)
- 5 GPS antenna connection (blue)
- 6 LTE antenna connection (bordeaux)
- 7 Diagnostics connection
- 8 Vehicle communication connection

Active operation

The 7" panel displays the following data:

- 12 V On/Off
- 230 V indicator
- Water pump on/off indicator (only when 12 V on)
- Starter battery indicator
- Living area battery indicator with lithium bat. in %
- Settings
- Menu bar



After a longer absence, it can take up to 2 minutes until the 7" panel displays current data (see energy-saving mode).

Emergency operation

When it is no longer possible to control the vehicle functions using the 7" panel or the HYMER Connect app, emergency mode can be activated manually. The following functions are active in emergency mode:

- 12 V power supply
- Lamps via light switches
- Water pump



During emergency operation of the vehicle, the display of the SCU is without function. Battery and water levels cannot be retrieved.



Requirements for emergency operation:

- No external power supply connected
- Engine switched off
- All water taps closed



▶ Before activating the emergency operation, make sure that all water taps in the vehicle are closed.

If not all water taps are closed, the pump can run dry and water can escape uncontrollably. Property damage may occur.

Activating the emergency operation:

- Gain access to the transformer/rectifier.
- Switch the battery cut-off switch ("Batterie Ein/Aus" ("Battery On/Off"))
 off and on again four times in succession.
- Leave the battery cut-off switch in the "Ein" (On) position.

Energy-saving mode

The SCU will automatically enter energy-saving mode after 48 hours if no user is connected to the SCU and the vehicle is not connected to an external power supply.

The energy-saving mode is ended by the following actions, for example, and the SCU then returns to "Active operation":

- Connecting the vehicle to an external power supply
- Unlocking/locking the vehicle (depending on the vehicle type)
- Activating the ignition of the vehicle
- Touching the display
- Starting the HYMER Connect app on a mobile device connected to the SCU



After a longer absence, it can take up to 2 minutes until the display displays current data.

Position

The SCU is installed in the floor trap behind the driver's seat.

8.10 AC converter (MSI 1812T)



- ▶ If, when the AC converter is switched on, the 230 V connection is disconnected or the 230 V main fuse is switched off, this will not activate the sockets since these are supplied by the AC converter.
- ► The safety cut-out in the additional fuse box for the AC converter secures and breaks the circuit only for the sockets in the vehicle.
- Only by switching off both fuse boxes and the AC converter is the mains power supply fully activated.



- When connecting appliances, always observe the permissible values for output power and peak output power:
 - Output power (for 10 min at 25 °C): 1800 W
 - Peak output power: 3200 W

Appliances with higher power demands must not be connected.

Do not cover the ventilation slots. Danger of overheating!





- During continuous operation, the fuse may blow due to overheating. Position of the fuse, see section 8.13.2.
- Do not place additional objects in the storage space of the AC converter. Danger of overheating!
- Check the fault current protection switch for each connection to the 230 V power supply, at least once every 6 months.
- If the vehicle is not connected to the 230 V power supply and no electric-ity is required, switch off the AC converter. Even in idle state, the AC converter still uses power from the living area battery.



- The AC converter is equipped with a 230 V priority circuit. If an external 230 V voltage is connected, it will be used primarily. Only if no external 230 V voltage is connected, the living area battery will be used for voltage supply.
- ▷ If not external 230 V power supply is connected, the AC converter draws energy from the living area battery. The living area battery has a limited power supply only. For this reason, the electrical appliances should not be operated from the electrical sockets for long periods without using the 230 V connection.
- ➤ To protect the living area battery against total discharge, the AC converter automatically switches itself off if there is undervoltage. The AC converter automatically switches itself on again when the voltage is back up to the standard value.
- ▷ In the event of overload or insufficient cooling, the AC converter switches itself off automatically. The AC converter automatically switches itself back on when there is no longer an overload and the temperature of the device is down to a safe level.
- ▷ If the appliance fuse has triggered, it must be pushed in again manually.
- > Further information can be obtained in the manufacturer's instruction manual.




Fig. 143 AC converter (exemplary illustration)

- 1 Appliance fuse
- 2 Main switch ON/OFF/REMOTE
- 3 LED input voltage range
- 4 LED LÖAD LEVEL

Functions

The AC converter has the following functions:

If no external 230 V power supply is connected, the AC converter generates a 230 V voltage for all sockets in the vehicle out of the 12 V DC voltage of the living area battery.

If an external 230 V power supply is connected, this will be used to supply the sockets. In this case, the AC converter will not draw power from the living area battery.






Fig. 144 Additional fuse box

- Fuse box 1
- 2 Safety cut-out for sockets
- Fault current protection switch for sockets

The sockets are protected by a safety cut-out (Fig. 144,2) and a fault current protection switch (Fig. 144,3) in the additional fuse box (Fig. 144,1).

Position

The AC converter and the additional fuse box are installed in the double floor and accessible via a floor trap.

Operating the AC converter

The operating controls are located on the front of the AC converter.

Switching on:

- Switch the main switch (Fig. 143,2) to position ON. The input voltage range LED (Fig. 143,3) will be lit green.
- Switch the main switch (Fig. 143,2) to position REMOTE. The control via the remote control switch will be activated.

Switching off:

Switch the main switch (Fig. 143,2) to position OFF. The input voltage range LED (Fig. 143,3) goes out.




Fig. 145 External switch (AC converter)

- External switch
- 2 LED
- On/Off button

Position of external switch

The external switch (Fig. 145,1) is installed in the wall-mounted cupboard above the table.



The main switch directly on the AC converter must be in the position REMOTE.

Switching on:

Press On/Off button (Fig. 145,3). The LED (Fig. 145,2) is on.

Switching off:

Press On/Off button (Fig. 145,3). The LED (Fig. 145,2) goes out.



Operating and indicator elements

During normal operation, the AC converter does not require any operation except switching on and off through the external switch. The indicator elements on the AC converter are mainly used for the diagnosis of faults.

No. in Fig. 143	Designation	Function
1	Appliance fuse	Protects the AC converter against overload. Before pushing in the appliance fuse again, the cause of the fault must have been eliminated
2	Main switch	Position OFF = AC converter switched off Position ON = AC converter switched on Position REMOTE = external switch enabled
3	LED input voltage range	Indicates the voltage range of the input voltage: Red, slow flashing = undervoltage (< 10.6 V) Red = undervoltage (10.6 to 11.0 V) Orange = undervoltage (11.0 to 12.0 V) Green = input voltage OK (12.0 to 14.2 V) Orange, flashing = overvoltage (14.2 to 15.0 V) Red, fast flashing = overvoltage (> 15.0 V)
4	LED LOAD LEVEL	Indicates the power range of the AC converter output: Off = 0 to 160 W Green = 160 to 640 W Orange = 640 to 1440 W Red, slow flashing = 1440 to 1600 W Red, fast flashing = > 1600 W

Checking the fault current protection switch:

■ When the vehicle is connected to the 230 V power supply, press the test button on the fault current protection switch (Fig. 144,3). The fault current protection switch (FI-switch) must be activated.



8.11 230 V power supply



- ▶ Only allow qualified personnel to work on the electrical system.
- ► Have the vehicle's electrical system checked by a qualified electrician at least once every 3 years. If the vehicle is used frequently, an annual check is recommended.

The 230 V power supply provides electricity for the following devices (if present):

- Sockets with earth contact for appliances with maximum 10 A
- Refrigerator
- Transformer/rectifier
- Auxiliary charging unit
- Air conditioning unit

The electrical appliances connected to the 12 V power supply of the living area are supplied with voltage by the living area battery.

Connect the vehicle to an external 230 V power supply system as often as possible. The charger module in the transformer/rectifier automatically charges the living area battery. In addition to this, the starter battery is charged with a float charge of 2 A.

Depending on the equipment, optional devices are fuse-protected by their own two-pole automatic circuit breaker.

8.11.1 230 V connection (CEE socket outlet)



Overvoltage can damage connected devices. Overvoltage can be caused by lightning, irregular voltage sources (e.g. petrol-operated generators) or power connections on ferries for example.

Requirements concerning the 230 V connection

- The connecting cable, the plug connectors at the point of supply and the plug connector to the vehicle must comply with IEC 60309. The standard designation for the plug connectors is "CEE blue".
- Use H07RN-F rubber sheathed cable with a minimum cable cross-section of 2.5 mm² and a maximum length of 25 m.
- Earth contact connectors (safety) are not permitted. The interconnection of CEE/safety adapters is also prohibited.

8.11.2 Connecting the 230 V power supply



- ► The external 230 V power supply must be protected by fuse with a fault current protection switch (FI-switch, 30 mA).
- ► To prevent overheating, the cable must be fully uncoiled from the cable reel.
- ▶ In case of doubt or if the 230 V supply is not available or is faulty, contact the operator of the power supply device.



- The 230 V connection in the vehicle is equipped with a FI switch.
- For the connection points on camp sites (camping distributors)
 FI switches, (30 mA) are obligatory.



The vehicle can be connected to an external 230 V power supply. As a principle, only use the 230 V connection on the vehicle (CEE socket outlet) for connecting.



Fig. 146 Safety cut-out and FI-switch (230 V fuse box)

- 1 Safety cut-out
- 2 Safety cut-out
- 3 Fuse box
- 4 FI switch
- 5 Test button



> The second safety cut-out (Fig. 146,2) is optional. Whether this safety cut-out is present or not depends on the equipment of the vehicle.

Connecting the vehicle:

- Check whether the power supply device is suitable regarding connection, voltage, frequency and current.
- Check whether the cables and connections are suitable.
- Check the plug connectors and cables for visible damage.
- Switch off both safety cut-outs (Fig. 146,1 and Fig. 146,2) in the fuse box (Fig. 146,3).



Fig. 147 230 V connection on the vehicle (CEE socket outlet)

- Open the cover of the 230 V connection on the vehicle (Fig. 147) and insert the plug connector. Ensure that the detent of the spring-mounted pivoting cover is engaged in position.
- Plug the connector of the connecting cable into the socket of the camping distributor. Ensure that the detent of the spring-mounted flap is also engaged here.
- Switch on both safety cut-outs in the fuse box.

Checking the FI switch:

- When the vehicle is connected to the 230 V supply, press the test button (Fig. 146,5) of the FI switch (Fig. 146,4) in the fuse box (Fig. 146,3). The FI switch must trip.
- Switch FI switch (Fig. 146,4) back on again.



Unplugging the connection:

- Switch off both safety cut-outs (Fig. 146,1 and 2) in the fuse box (Fig. 146,3).
- Loosen the detent on the camping distributor and unplug the connecting cable from the socket.
- Loosen the detent on the vehicle unplug the plug connector and close the cover of the 230 V connection.

8.12 Solar installation

The information about the solar installation is shown on a display panel.

Position The display panel is installed in the wall-mounted cupboard above the table.




Fig. 148 Solar installation display panel

- 1 Display
- 2 Button Switch the display on/off, reset the meter reading
- 3 Button Back/upwards
- Button Continue/downwards

Switching on/off

The solar installation is not switched manually. As soon as solar radiation is present, the solar regulator charges the living area battery. The display panel is supplied with power by the solar regulator.

Operating modes

The device has the following operating modes:

- Standby: Nothing is displayed except for the Charge symbol (if the battery is discharged) and the sun symbol (if the solar regulator is active)
- Display with and without lighting: When any button is pressed on the display panel, the display lighting goes on and remains active for 3 minutes.

If no further button is pressed during these 3 minutes, the lighting switches off again. The symbols are still visible on the display. The button functions are only executed if a button is pressed while the lighting is switched on.

Operation

The following information is displayed successively by pressing the continue button (Fig. 148,4):

- The solar installation's current electrical current in amperes (A)
- Voltage of battery in volts (V)
- The energy generated by the solar installation (counted continuously and displayed in ampere-hours (Ah) as well as watt-hours (Wh)/kilowatthours (kWh))

To reset the meter reading: display desired meter reading, press On/Off button (Fig. 148,2) for approx. 3 seconds until "Set ----" is displayed.

Current output of the solar installation in watts (W)



Further information can be obtained in the manufacturer's instruction manual.

8.13 Fuses



- Only replace defective fuses when the cause of the defect is known and has been remedied.
- Replace defective fuses only after the power supply has been turned off
- ▶ Do not replace screwed fuses yourself. Contact an authorised specialist workshop to have these replaced.
- ▶ Never bridge or repair fuses.
- Only replace faulty fuses with a new fuse with the same rating.

8.13.1 12 V fuses

The appliances connected to the 12 V power supply in the living area are fused individually. The fuses are accessible at different positions in the vehicle.

Before changing fuses, take the function, value and colour of the relevant fuses from the following specifications. When changing fuses, only use flat fuses with the values shown below.

Some signals are protected by "Polyswitch" fuses. Polyswitch is an internal self-resetting fuse. After the overcurrent or short circuit has been remedied, the operating current is enabled again automatically. This can take a few seconds (cooling-down phase).

8.13.2 Positions of fuses



▷ All positions and values of fuses are indicated by stickers.

Most of the fuses can be found at one of the following positions:

- In the transformer/rectifier
- In the two fuse holders next to the transformer/rectifier
- In the seat console of the driver's seat


160



Transformer/rectifier with fuse holders

Several fuses are attached to the transformer/rectifier EBL 402 (Fig. 149,1). The fuses are clearly identified by their colour and by the indications about function and value. Next to the transformer/rectifier there are fuse holders (Fig. 149,2) with further fuses.

The transformer/rectifier and fuse holders are installed in a compartment of the double floor and are accessible via a service cover.



Transformer/rectifier EBL 402 and fuse holders

- Transformer/rectifier EBL 402
- 2 Fuse holders

Seat console of the driver's seat

The fuses in the seat console of the driver's seat are accessible via a removable cover. A sticker on the seat console or a separate assignation diagram hold information about the installed fuses.



Fig. 150 Seat console of the driver's seat



Other positions for fuses:

Fuses on the starter battery

See instruction manual of the base vehicle.

Fuse for the Thetford toilet


The toilet has a maintenance-free fuse which resets automatically.

Fuse of ventilation system

The fuse (10 A) for the electrical ventilation system of the toilet is located in circuit 1 or in circuit 2 of the transformer/rectifier.

Fuses for the hot-water heater (Alde)

The electrical system of the hot-water heater is protected by two fuses.



1 3.5 A glass fuse

Fig. 151 Fuses (hot-water heater)

The two 3.5 A fine fuses (glass fuses) (Fig. 151,1) are installed underneath a cover behind the service flap on the left side of the vehicle. This cover can be released from its lock moving it upward.

Fuse for the AC converter

The fuse for the AC converter is installed close to the living area battery.



Fig. 152 Fuse (AC converter (150 A))

The fuse can be identified by its sticker.



Fuses for the satellite unit

The control unit is installed in the wardrobe.



Fig. 153 Control unit (TV satellite unit)

3 A fuse/purple 1 10 A fuse/red

Fuse for the pull-down bed

The fuse (25 A) for the motor of the pull-down bed is located on the transformer/rectifier (basic light).

The fuse (2 A) for the control of the pull-down bed is installed on the fuse holder next to the transformer/rectifier (F3).

Fuse for skylight

The fuse for the skylight with fan is located at the skylight in a cover.



Fig. 154 Fuse (skylight)

Cover with glass fuse 4 A/type "SLO BLO"



8.13.3 230 V fuse

For vehicles with an AC converter as optional equipment, observe the following:



- ▶ If, when the AC converter is switched on, the 230 V connection is disconnected or the 230 V main fuse is switched off, this will not activate the sockets since these are supplied by the AC converter.
- ► The safety cut-out in the additional fuse box for the AC converter secures and breaks the circuit only for the sockets in the vehicle.
- ▶ Only by switching off both fuse boxes and the AC converter is the mains power supply fully activated.



Check the fault current protection switch (FI switch) every time a connection to the 230 V power supply is established but at least once every 6 months.



Fig. 155 Safety cutout and FI-switch (230 V fuse box)

- 1 Safety cut-out (10 A)
- 2 Safety cut-out (16 A)
- 3 FI switch
- 4 Test button

A FI switch (Fig. 155,3) in the fuse box protects the complete vehicle from fault current (30 mA).

The downstream safety cut-out (10 A) (Fig. 155,1) secures the 230 V sockets, the transformer/rectifier, the auxiliary charging unit and the refrigerator.

For vehicles with optional equipment, e.g. roof air conditioning unit, the device is protected by an additional safety cut-out (16 A) (Fig. 155,2).

Checking the fault current protection switch:

When the vehicle is connected to the 230 V power supply, press the test button (Fig. 155,4). The FI switch must trip.

Position

The fuse box is installed close to the 230 V connection in a compartment of the double floor.



Chapter overview

This chapter contains instructions regarding the appliances of the vehicle.

The instructions refer exclusively to the operation of the appliances.

Further information about the appliances can be found in the instruction manuals for the appliances, included separately with the vehicle.

9.1 **General**



For safety reasons, spare parts for pieces of heating appliances must correspond with manufacturer's instructions and be permitted by the manufacturer as a spare part. These spare parts may only be fitted by the manufacturer or an authorised specialist workshop.



Further information can be obtained in the instruction manual for the respective appliance.

The heater, boiler, cooker and refrigerator are fitted depending on the model of the vehicle.

In this instruction manual a description is given only for the operation of the appliances and their particular features.

To operate gas appliances, first open the regulator tap on the gas bottle and the gas isolator tap corresponding to the appliance.




Fig. 156 Possible symbols for the gas isolator taps

- Cooker
- Hot water 2
- 3 Refrigerator
- Oven/grill
- 5 Heater
- Hot water/heater

165



9.2 Heater and boiler

The heater can both heat up the vehicle interior (heating the room air) and heat up the domestic water (boiler function). The following instructions are also valid if the heater is only used as boiler.

The following heater variants are described:

- Gas hot-air heater and boiler with CP plus digital operating unit (standard)
- Hot-air heater and boiler Combi D with CP plus digital control unit (optional)
- Alde hot-water heater and boiler (optional)



- Never let gas escape unburned due to danger of explosion.
- Never run the heater in gas operation when refuelling, on ferries or in the garage. Danger of explosion!
- Never operate the heater in gas operation in closed spaces (e.g. garages). Danger of poisoning and suffocation!
- ▶ The waste gas vent may neither be closed nor blocked.
- Do not use the space behind the heater as a storage space.
- ▶ The water in the boiler can be heated up to 65 °C. Risk of scalding!



- Never use boiler when empty.
- ▷ If the boiler is not being used, empty it if there is any risk of frost.
- Only operate the boiler with the maximum temperature setting if you require a large quantity of warm water. This protects the boiler against the build-up of limescale.



- Do not use the water from the boiler as drinking water.
- ▷ If the power supply to the heater was interrupted, the time must be reset.

Initial start-up

When lighting the heater for the first time a small amount of smoke and odour will occur. Immediately set the operating switch of the heater to its highest position. Open doors and windows and ventilate well. Smoke and odour will disappear by themselves after a while.

166



9.2.1 Heating properly



- ➤ The air outlet nozzles must always remain unobstructed and must not be blocked or obstructed in order to allow a free air current and to avoid heat build-up.
- Dobjects placed in front of the air outlet nozzles can be damaged by the heat build-up.
- If the air current is persistently blocked, the heat build-up can cause damage to the vehicle.



Fig. 157 Air outlet nozzle (hot-air heater)

Hot air distribution

Several air outlet nozzles (Fig. 157) are installed in the vehicle directing warm air from the heater into the living area. Turn the air outlet air outlet nozzle in a suitable position so the air can escape as required.

When the vehicle's air outlet nozzles on the dashboard are in the open position during heating, the heating air circulates and escapes. To prevent this, close the air outlet nozzles on the dashboard and set the base vehicle's air distribution to air circulation.

Adjusting the air outlet nozzle

- Fully open: full hot air stream
- Half or partially open: reduced hot air stream

When all air outlet nozzles are fully open, less warm air comes out of each nozzle. However, when only some of the air outlet nozzles are open, more warm air will flow out of each nozzle.



9.2.2 Gas hot-air heater and boiler with CP plus digital operating unit



- If there is a risk of frost and the heater is not in operation, empty the boiler.
- The circulation fan is automatically switched on when the hot-air heater is activated, and it stays on. This puts an immense strain on the living area battery, if the vehicle is not connected to an external 230 V power supply. Take into consideration that the living area battery only has limited reserves of energy.



- The hot-air heater can even run on an empty boiler.

Maximum heat output

Gas operation	Electrical opera-	Mixed operation (gas and electrical operation)
6000 W	1800 W	5800 W

Control unit

The control unit is divided into two sections:

- Display
- Operating buttons



Fig. 158 Control unit (hot-air heater and boiler)

- 1 Display
- 2 Rotary push button
- 3 Back button

Position The control unit is installed above the living area door.

After being switched on, the most recently set values/operating parameters are activated.

If no button is pressed, the control unit switches to stand-by mode after a few minutes.

If the time is set, the display in stand-by mode alternates between the time and the room temperature set.

After being switched off, the display in the control unit may remain active for several minutes since the heater is still running.

168



Operating buttons

The operating buttons have the following functions:

Button	Button operation	Function
Rotary push button (Fig. 158,2)	Turn to the right	Menu is run through from left to right
		Values are increased
	Turn to the left	Menu is run through from right to left
		Values are decreased
	Press briefly	Selected value is saved
		Menu item is selected for changing values (selected menu item flashes)
	Press (3 seconds)	Switch on or switch off
Back button (Fig. 158,3)	Press	Return from a menu item without saving values



Fig. 159 Control unit with display

- 1 Display
- 2 Status line
- 3 Upper menu line
- 4 Display line voltage 230 V
- 5 Lower menu line
- 6 Rotary push button
- 7 Back button
- 8 Settings and values display area
 - Timer display

Display The di

The display is divided into four sections:

- Status line (Fig. 159,2)
- Upper menu line (Fig. 159,3)
- Display area (Fig. 159,8)
- Lower menu line (Fig. 159,5)



- The heater can either be controlled via the 7" panel or the control unit (Fig. 158 and Fig. 159), but not via both operating controls at the same time.
- ▶ Before operating the heater using the control unit, exit the corresponding menu on the 7" panel or switch off the 7" panel.

Switching the operating unit on/off:

Press and hold the rotary push button (Fig. 159,6) for approx. 3 seconds. Both menu lines (Fig. 159,3 and Fig. 159,5) are displayed. The first symbol flashes.




Switching the control unit on/off means switching between stand-by and setting mode. In stand-by mode, the display alternates between the room temperature and the time that have been set.

Carrying out settings:

- Turn the rotary push button (Fig. 159,6) until the required menu symbol flashes.
- Press the rotary push button.



- Turn the rotary push button until the required value is displayed.
- Press the rotary push button to save the value set. If you do not wish to change the value originally set: Press the back button (Fig. 159,7).



1 Heater

- 2 Hot water
- 3 Operating mode
- 4 Fan
- 5 Service menu
- 6 Setting the time
- 7 Warning symbol
- 8 Lighting (not used here)
- 9 Timer

Fig. 160 Display (operating unit)

Switching on the heater:

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
- Turn the rotary push button (Fig. 159,6) until the heater menu symbol (Fig. 160,1) flashes.
- Press the rotary push button.
- Turn the rotary push button until required value is displayed.
- Press the rotary push button to save the value set. The symbol in the status line (Fig. 159,2) flashes until the room temperature set is reached. If you do not wish to change the value originally set: Press the back button (Fig. 159,7).

Switching off the heater:

Turn the temperature value back until OFF is displayed. Press the rotary push button to save.



 The required room temperature can also be changed in stand-by mode by turning the rotary push button.

Switching on production of hot water:

- Open the regulator tap on the gas bottle and the gas isolator tap "Heater/boiler".
- Turn the rotary push button (Fig. 159,6) until the hot water menu symbol (Fig. 160,2) flashes.
- Press the rotary push button.
- Turn the rotary push button until the required value is displayed:
 - OFF: Production of hot water is switched off.
 - 40°: Hot water is heated to 40 °C.
 - 60°: Hot water is heated to 60 °C.
 - BOOST: Fast heating of hot water (boiler priority) for max.
 40 minutes. The water temperature is then held at a higher level for two reheating cycles (approximately 62 °C).
- Press the rotary push button to save the value set. The symbol in the status line (Fig. 159,2) flashes until the hot water temperature set is reached. If you do not wish to change the value originally set: Press the back button (Fig. 159,7).



Switching off production of hot water:

Turn the rotary push button until OFF is displayed. Press the rotary push button to save.

Safety/drainage valve

The boiler is equipped with a safety/drainage valve (Fig. 161). The safety/drainage valve prevents water in the boiler from freezing, when there is frost and the heater is not switched on.



- When the vehicle is not used for a long period of time, open the safety/drainage valve and empty the boiler.
- At temperatures below 3 °C the safety/drainage valve opens automatically. Only if the temperature of the safety/drainage valve lies above 7 °C can it be shut again.



The drainage neck of the safety/drainage valve has to be free of dirt (e.g. leaves, ice) at all times.



Fig. 161 Safety/drainage valve (boiler)

- 1 Knob
- 2 Push button

Position

Position of the safety/drainage valve, see section 10.7.

Filling/emptying the boiler

The boiler can be supplied with water from the water tank.

Filling the boiler with water:

- Switch on the 12 V power supply on the panel.
- Close the safety/drainage valve. Turn the knob (Fig. 161,1) perpendicular to the safety/drainage valve and push the push button (Fig. 161,2) in.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the water taps open until the water flowing out of the water taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Close all water taps.

Emptying the boiler:

- Switch off hot water production.
- Open the safety/drainage valve. To do this turn the knob (Fig. 161,1) parallel to the safety/drainage valve. The push button (Fig. 161,2) jumps out. The boiler is drained to the outside by the safety/drainage valve.
- Check whether the water has been drained completely from the boiler (approx. 10 litres).





Fig. 162 Drain cock (water pipe)

 Close the drain cocks. In order to do this, turn the cap of the drain cock (Fig. 162) in a clockwise direction.

Operating modes

The hot-water heater with the boiler can be operated with various energy sources.

Selecting operating mode:

- Turn the rotary push button (Fig. 159,6) until the menu symbol operating mode (Fig. 160,3) flashes.
- Press the rotary push button.
- Turn the rotary push button until the desired operating mode is displayed:
 - **Î** Gas operation
 - 🖺 Electrical operation, output level 1 (900 W)
 - 🖺 Electrical operation, output level 2 (1800 W)
 - 🗓 Gas operation and electrical operation output level 1 (900 W)
 - 🗓 🔭 Gas operation and electrical operation output level 2 (1800 W)
- Press the rotary push button to save the set operating mode. To revert to the original setting: Press the back button (Fig. 159,7).



- ≥ 230 V electrical operation is only possible when the vehicle is connected to the 230 V power supply.
- At output level 1 (900 W), current consumption is 3.9 A. At output level 2 (1800 W), current consumption is 7.8 A.

Setting the fan:

- Turn the rotary push button (Fig. 159,6) until the fan menu symbol (Fig. 160,4) flashes.
- Press the rotary push button.
- Turn the rotary push button until the required value is displayed:
 - OFF: Fan is switched off.
 - VENT: Air circulation
 - ECO: Low fan setting
 - HIGH: High fan setting
 - BOOST: Fast room heating. Boost is available if the current room temperature is at least 10 °C below the selected room temperature.
- Press the rotary push button to save the value set. If you do not wish to change the value originally set: Press the back button (Fig. 159,7).

172



Setting the timer:

- Turn the rotary push button (Fig. 159,6) until the timer menu symbol (Fig. 160,9) flashes.
- Press the rotary push button. The start time is displayed and the hour display flashes.
- Turn the rotary push button until the hour of the selected start time is displayed.
- Press the rotary push button. The minute display flashes.
- Turn the rotary push button until the minute of the selected start time is displayed.
- Press the rotary push button.
- Proceed in the same way to set the switch-off time, the required room temperature, the hot water setting and the fan setting.
- Press the rotary push button. The timer is activated. The timer symbol (Fig. 160,9) flashes when the timer is programmed and active.



The service menu contains items that generally only need to be set once (language, background brightness, calibration), as well as information for service centres (version numbers).

Fault display

The warning symbol (Fig. 160,7) flashes in the event of a warning. The heater continues to operate. In the event of only a temporary fault, the warning symbol goes out automatically.

In the event of a warning, the control unit displays the error code for the fault. The heater is switched off. Press the rotary push button to restart the heater.



> Further information can be obtained in the manufacturer's instruction manual.




Fig. 163 Damper (opened)

Heat distribution in the rear area

The heater for the rear area can be adjusted separately via dampers (Fig. 163).

The dampers are installed in the side walls of the vehicle on the right and left side of the bunk bed mattress.

The heat output varies depending on the position of the dampers.



9.2.3 Hot-air heater and boiler Truma Combi D with digital CP plus digital control unit



- ▶ If leakage occurs at the heater or at the exhaust gas routing, there is a risk of poisoning! If leakage is detected: switch off the diesel hot-air heater. Open windows and doors. Have the system checked by an authorised service centre.
- ▶ Observe the safety regulations and safety instructions of the manufacturer; see separate instruction manual of the manufacturer.



- ➤ The circulation fan is automatically switched on when the hot-air heater is activated, and it stays on. This puts an immense strain on the living area battery, if the vehicle is not connected to an external 230 V power supply. Take into consideration that the living area battery only has limited reserves of energy.



- The hot-air heater can even run on an empty boiler.
- ▷ If the power supply to the heater was interrupted, the time must be reset.

•	Electrical opera-	Mixed operation (diesel and electrical operation)*
6000 W	1800 W	6900 W

Maximum heat output

Control unit

The control unit is divided into two sections:

- Display
- Operating buttons



Fig. 164 Control unit (hot-air heater and boiler)

- 1 Display
- 2 Rotary push button
- 3 Back button

Position The control unit is installed above the living area door.

^{* (}optional for Truma DE)



Operating buttons

The operating buttons have the following functions:

Button	Button operation	Function
Rotary push button (Fig. 164,2)	Turn to the right	Menu is run through from left to right
		Values are increased
	Turn to the left	Menu is run through from right to left
		Values are decreased
	Press briefly	Selected value is saved
		Menu item is selected for changing values (selected menu item flashes)
	Press (3 seconds)	Switch on or switch off
Back button (Fig. 164,3)	Press	Return from a menu item without saving values



Fig. 165 Control unit with display

- 1 Display
- 2 Status line
- 3 Upper menu line
- Display of the line voltage 230 V (optional)
- 5 Lower menu line
- 6 Rotary push button
- 7 Back button
- 8 Settings and values display area
- 9 Timer display

Display

The display is divided into four sections:

- Status line (Fig. 165,2)
- Upper menu line (Fig. 165,3)
- Display area (Fig. 165,8)
- Lower menu line (Fig. 165,5)



- ➤ To prevent a malfunction, do not operate the heater on the 7" panel or in the HYMER Connect app and on the control unit (Fig. 164 and Fig. 165) at the same time.
- ▶ Before operating the heater using the control unit, exit the corresponding menu on the 7" panel or switch off the 7" panel.

Switching the control unit on-/off

After being switched on, the most recently set values/operating parameters are activated.

If no button is pressed, the control unit switches to stand-by mode after a few minutes.

If the time is set, the display in stand-by mode alternates between the time and the room temperature set.

After being switched off, the display in the control unit may remain active for several minutes since the heater is still running.

Press and hold the rotary push button (Fig. 165,6) for approx. 3 seconds. Both menu lines (Fig. 165,3 and Fig. 165,5) are displayed. The first symbol flashes.






Switching the control unit on/off means switching between stand-by and setting mode. In stand-by mode, the display alternates between the room temperature and the time that have been set.

Carrying out settings:

- Turn the rotary push button (Fig. 165,6) until the required menu symbol flashes.
- Press the rotary push button.
- Turn the rotary push button until the required value is displayed.
- Press the rotary push button to save the value set. If you do not wish to change the value originally set: Press the back button (Fig. 165,7).



Display (control unit)

Fig. 166

- Heater
- 2 Hot water
- 3 Operating mode
- 4 Fan
- 5 Service menu
- Setting the time 6
- Warning symbol
- 8 Lighting (not used here)
- 9 Timer

Switching on the heater:

- Turn the rotary push button (Fig. 165,6) until the heater menu symbol (Fig. 166,1) flashes.
- Press the rotary push button.
- Turn the rotary push button until required value is displayed.
- Press the rotary push button to save the value set. The symbol in the status line (Fig. 165,2) flashes until the room temperature set is reached. If you do not wish to change the value originally set: Press the back button (Fig. 165,7).

Switching off the heater:

Turn the temperature value back until OFF is displayed. Press the rotary push button to save.



The required room temperature can also be changed in stand-by mode by turning the rotary push button.

Switching on production of hot water:

- Turn the rotary push button (Fig. 165,6) until the hot water menu symbol (Fig. 166,2) flashes.
- Press the rotary push button.
- Turn the rotary push button until the required value is displayed:
 - OFF: Production of hot water is switched off.
 - 40°: Hot water is heated to 40 °C.
 - 60°: Hot water is heated to 60 °C.
 - BOOST: Fast heating of hot water (boiler priority) for max. 40 minutes. The water temperature is then held at a higher level for two reheating cycles (approximately 62 °C).
- Press the rotary push button to save the value set. The symbol in the status line (Fig. 165,2) flashes until the hot water temperature set is reached. If you do not wish to change the value originally set: Press the back button (Fig. 165,7).



Switching off production of hot water:

 Turn the rotary push button until OFF is displayed. Press the rotary push button to save.

Safety/drainage valve

The boiler is equipped with a safety/drainage valve (Fig. 167). The safety/drainage valve prevents water in the boiler from freezing, when there is frost and the heater is not switched on.



- When the vehicle is not used for a long period of time, open the safety/drainage valve and empty the boiler.
- At temperatures below 3 °C the safety/drainage valve opens automatically. Only if the temperature of the safety/drainage valve lies above 7 °C can it be shut again.
- The water pump and the water fittings are not protected against freezing by the safety-/drainage valve.



The drainage neck of the safety/drainage valve has to be free of dirt (e.g. leaves, ice) at all times.



Fig. 167 Safety/drainage valve (boiler)

- 1 Knob
- 2 Push button



Fig. 168 Drain cock (water pipe)

Position

The safety/drainage valve is installed in the seat box next to the boiler. The drain cock (water pipe) is installed under a floor trap.

Filling/emptying the boiler

The boiler can be supplied with water from the water tank.

When the vehicle is connected to a central water supply, a pressure reducer must be used. The maximum allowed pressure in the boiler is 2.8 bar.



Filling the boiler with water:

- Switch on the 12 V power supply on the panel.
- Close the safety/drainage valve. Turn the knob (Fig. 167,1) perpendicular to the safety/drainage valve and push the push button (Fig. 167,2) in.
- Set all the water taps to "Hot" and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the water taps open until the water flowing out of the water taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Close all water taps.

Emptying the boiler:

- Switch off hot water production.
- Open the safety/drainage valve. To do this turn the knob (Fig. 167,1) parallel to the safety/drainage valve. The push button Fig. 167,2) jumps out. The boiler is drained to the outside by the safety/drainage valve.
- Check whether the water has been drained completely from the boiler (approx. 10 litres).
- Close the drain cocks. In order to do this, turn the cap of the drain cock (Fig. 168) in a clockwise direction.

Operating modes

Depending on the equipment, the hot-water heater with the boiler can be operated by means of various energy sources.

Selecting operating mode:

- Turn the rotary push button (Fig. 165,6) until the menu symbol operating mode (Fig. 166,3) flashes.
- Press the rotary push button.
- Turn the rotary push button until the desired operating mode is displayed:
 - Diesel operation
 - 🖺 Electrical operation, output level 1 (900 W) *
 - Draw Electrical operation, output level 2 (1800 W) *
 - Diesel operation and electrical operation, output level 1 (900 W) *
 - Diesel operation and electrical operation, output level 2 (1800 W) *
 - * (optional for Truma DE)
- Press the rotary push button to save the set operating mode. To revert to the original setting: Press the back button (Fig. 165,7).



- 230 V electrical operation is only possible when the vehicle is connected to the 230 V power supply.
- At output level 1 (900 W), current consumption is 3.9 A. At output level 2 (1800 W), current consumption is 7.8 A.

178



Setting the fan:

- Turn the rotary push button (Fig. 165,6) until the fan menu symbol (Fig. 166,4) flashes.
- Press the rotary push button.
- Turn the rotary push button until the required value is displayed:
 - OFF: Fan is switched off.
 - VENT: Air circulation
 - ECO: Low fan setting
 - HIGH: High fan setting
 - BOOST: Fast room heating. Boost is available if the current room temperature is at least 10 °C below the selected room temperature.
- Press the rotary push button to save the value set. If you do not wish to change the value originally set: Press the back button (Fig. 165,7).

Setting the timer:

- Turn the rotary push button (Fig. 165,6) until the timer menu symbol (Fig. 166,9) flashes.
- Press the rotary push button. The start time is displayed and the hour display flashes.
- Turn the rotary push button until the hour of the selected start time is displayed.
- Press the rotary push button. The minute display flashes.
- Turn the rotary push button until the minute of the selected start time is displayed.
- Press the rotary push button.
- Proceed in the same way to set the switch-off time, the required room temperature, the hot water setting and the fan setting.
- Press the rotary push button. The timer is activated. The timer symbol (Fig. 166,9) flashes when the timer is programmed and active.



 The service menu contains items that generally only need to be set once (language, background brightness, calibration), as well as information for service centres (version numbers).

Fault display

The warning symbol (Fig. 166,7) flashes in the event of a warning. The heater continues to operate. In the event of only a temporary fault, the warning symbol goes out automatically.

In the event of a warning, the control unit displays the error code for the fault. The heater is switched off. Press the rotary push button to restart the heater.



Further information can be obtained in the manufacturer's instruction manual.



9.2.4 Alde hot-water heater and boiler



- Never run hot-water heater without heating fluid. Observe the notes in chapter 12.
- Never drill holes in the floor. This might damage the hot-water pipes.
- Make sure that there is enough fresh water in the fresh water tank to fill the boiler.



- ➤ The circulating pump must always be turned on when the hot-water heater is in operation.
- ▶ When the heater is turned on, it starts with the last settings used.
- For further information, see the separate manufacturer's instruction manual and observe the maintenance instructions found in chapter 12.

Control unit

The control unit is divided into two sections:

- Display (touch screen)
- Operating buttons



- 1 Display (touch screen)
- 2 MENU button
- 3 On/Off button

Fig. 169 Control unit (hot-water heater)

Position The control unit is installed above the living area door.



- When no button is pressed, the control unit automatically switches to home position after two minutes.
- Changes to the settings are saved automatically after 10 seconds.

Operating buttons

The operating buttons have the following functions:

Pos. in Fig. 169	Button	Function
2	MENU	Open settings menu
3	\bigcirc	Activate heating

Display

The display (Fig. 169,1) is designed as a touch screen. Touching the symbols calls up the relevant function.





Fig. 170 Start screen (control unit)

Start screen

The start screen appears on the display after the heater is switched on. The start screen contains the following information:

Symbol	Meaning
Θ	This symbol appears when the circulating pump is activated
<u> </u>	This symbol appears when the Automatic start function of the heater is activated
*	This symbol appears when the daytime automatic mode function is activated
(This symbol appears when the night-time automatic mode function is activated
Δ	This symbol appears when a switching facility for gas bottles is activated
*	This symbol appears when a voltage of 230 V is present at the heater
	The internal temperature is displayed next to this symbol
	The external temperature is displayed next to this symbol if an external sensor is fitted

Settings menu

The MENU button calls up the settings menu. The meanings of the individual symbols are described in the following table.



Settings menu (control unit)

The values can be increased or reduced via the + or – symbols.



Symbol	Meaning
	Setting the desired temperature of +5 to +30 °C
17117	Setting the water temperature in the boiler
4	Setting the heat output in electrical operation
6	Heater button in gas operation On/Off
	Tool menu button
AC	AC button for switching on the automatic air conditioning (only visible when the Truma Aventa air conditioning unit is installed)
A	Button for activated functions

Tool menus

The various heater functions can be called up and adjusted via the tool menus. The arrow symbols are used to change between the menus. The meanings of the individual symbols are described in the manufacturer's instruction manual.

Selecting the operating mode

The hot-water heater can be operated with the following energy sources:

- Gas operation
- 230 V electrical operation
- Gas and 230 V electrical operation

The operating mode is selected via the control unit.

Selecting gas operation:

- Press the button. The button lights up green. The gas operation is activated.
- Press the button again. The button lights up blue. The gas operation is switched off.

Selecting 230 V electrical operation:

■ Press the + button next to the ∮ symbol until the desired heat output is reached.



Select the output level during 230 V electrical operation in such a way that it corresponds to the 230 V connection protection:

Level 1 (1 kW) at 6 A Level 2 (2 kW) at 10 A

Level 3 (3 kW) at 16 A

Selecting gas and 230 V electrical operation:

Select both gas operation and 230 V electrical operation on the control unit.



- ▷ If gas and 230 V electrical operation is selected and if the vehicle is connected to the 230 V power supply, then the hot-water heater at first only operates in 230 V electrical operation. Only if the heat output is insufficient does the gas operation also automatically switch on.
- ≥ 230 V electrical operation is only possible when the vehicle is connected to the 230 V power supply.



When the heater is turned on, it starts with the last set operating mode.

Switching on the heater:

Press the button. The start screen appears in the display. The heater starts automatically.

Switching off the heater:

■ Press the () button. The heater is turned off.

Setting the water temperature in the boiler:

- To set temperature level 1: Press the + button next to the symbol once. Half of the triangular symbol next to the + button turns black.
- To set temperature level 2: Press the + button next to the symbol twice. The entire triangular symbol next to the + button turns black. After 30 minutes, the boiler automatically switches from level 2 back to level 1.

Filling/emptying the boiler

The boiler can be supplied with water from the water tank.



➤ To be able to fill the boiler, sufficient fresh water must be present in the fresh water tank.





Fig. 172 Drain cock (water pipe)

Fig. 173 Drain cock (Alde boiler)

Filling the boiler with water:

- Close the drain cocks. To do so, turn the cap (Fig. 172) in a clockwise direction and set the rocking lever (Fig. 173) in a horizontal position.
- Switch on the 12 V power supply on the panel.
- Set all the water taps to Hot and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the water taps open until the water flowing out of the water taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Close all water taps.

Emptying the boiler:

- Switch off the boiler.
- Open the drain cocks. To do so, turn the cap (Fig. 172) in an anticlockwise direction and set the rocking lever (Fig. 173) in a vertical position.
- Check whether the water has been drained completely from the boiler (approx. 7-10 litres).



- For further information about emptying the water system see section 10.2.6.
- For further information about the boiler see the separate manufacturer's instruction manual and observe the maintenance instructions in chapter 12.



Heat distribution

Depending on the model, the temperature of the convectors in the bed area can be controlled separately. A stopcock and throttle are installed in the vehicle for this purpose.

The flow to the convectors in the bed area is controlled with the stopcock.

The flow of the bypass line in the bed area is controlled with the throttle. The bypass line protects the fresh water pipes in the bed area from frost and maintains the circulation of heat even if the line to the convectors is closed.



 If there is a risk of frost, check that the throttle is slightly open to prevent the fresh water pipes from freezing.



Fig. 174 Stopcock (open)

Opening the line to the convectors:

Set the lever (Fig. 174) parallel to the pipe. The wider the stopcock is opened, the higher is the heat output.

Closing the line to the convectors:

■ Set the lever (Fig. 174) at right angles to the pipe. Heat is circulated by the bypass line.




Fig. 175 Throttle (open)

- 1 Throttle adjusting screw
- 2 Bypass line
- 3 Throttle

Checking the heating circuit:

Touch the bypass line (Fig. 175,2) behind the throttle (Fig. 175,3). The pipe must be warm to the touch.



Auxiliary fan

With the aid of an integrated heat exchanger, the auxiliary fans provide a better heat distribution in the vehicle.

The auxiliary fans are installed at 3 positions in the vehicle. Fig. 176 shows an installation position as an example.

The auxiliary fan is controlled via the control unit (Fig. 177) of the hot-water heater.




Fig. 176 Auxiliary fan with heat exchanger (example)



Fig. 177 Settings menu (auxiliary fan)

- Press the MENU button on the operating unit.
- Press the A button (Fig. 177). The availability functions are displayed.



Fig. 178 Booster function (auxiliary



Fig. 179 Control (auxiliary fan)

- Press the Booster button (Fig. 178). The control display (Fig. 179) for the auxiliary fan is displayed.
- Use the + and buttons (Fig. 179) to set the desired fan power.



Heat exchanger for engine heater

The additional heat exchanger and the additional circulating pump have the following functions:

- Heat distribution to the rear inside the vehicle during the journey
- Engine heater (independent vehicle heater)



Fig. 180 Engine heater function (auxiliary fan)

Switching on the engine heater:

■ Press the Engine heater button (Fig. 180).

Summer operation

An undesirable warming of the heat exchanger and the heating system in summer can be avoided by closing the spherical valve on the heat exchanger.




Fig. 181 Spherical valve (closed)



Fig. 182 Spherical valve (opened)

Closing spherical valve (summer operation):

■ Set the lever (Fig. 181) at right angles to the pipe.

Opening the spherical valve:

Set the lever (Fig. 182) parallel to the pipe.

Position of spherical valve

Vehicles with gas bottle compartment behind the rear axle: The spherical valve is installed in the storage box behind the driver's seat. It is accessible via a storage space flap.

Vehicles with gas bottle compartment in front of the rear axle: The spherical valve is installed in floor compartment underneath the table. It is accessible from the inside via a floor lid.



9.2.5 Rear garage hot-water heater



Never drill holes in the floor. This might damage the hot-water pipes.



- The rear garage can only be heated if the hot-water heater is running.
- The heat output depends on the temperature of the heating liquid in the hot-water heating system.
- Only the distribution of the hot water for heating is adjusted with the inlet valves. The temperature and thereby the power of the heating itself is set at the control unit.




Fig. 183 Inlet valves (rear garage heating)

Switching on the rear garage heating: Adjust the handle (Fig. 183) on the inlet valve for the rear garage heating so that it is parallel to the heating pipe. The rear garage heating is now working at maximum power.

Adjusting heat output:

Set the handle (Fig. 183) on the inlet valve for the rear garage heating to the desired position. This enables the hot water distribution to the rear garage to be continuously adjusted.

Switching off the rear garage heating: Set the handle (Fig. 183) on the inlet valve for the rear garage heating so that it is horizontal to the heating pipe. The rear garage heating is now switched off.



9.2.6 Wall flue

Fresh air and exhaust gases of the heater system are conducted in a twochamber wall flue.



- Park the vehicle such that the wall flue gets enough fresh air.
- > The wall flue must be free at all times. Do not cover the wall flue.
- When camping in winter, maintain wall flue free of snow and ice.
- Check the wall flue periodically depending on the weather (snow, leaf fall, dirt, etc.). If necessary, clean the wall flue.
- When washing the vehicle do not aim the water jet directly at the wall flue.
- ▶ When disregarding this, the flawless operation of the heater can not be guaranteed.





Fig. 184 Wall flue (hot-water heater)

Fig. 185 Wall flue (hot-air heater)

The wall flue is mounted on the left side wall.

9.3 Truma Aventa air conditioning unit



- The cooling circuit may only be opened by the manufacturer or an authorised specialist workshop.
- > Do not block the air inlets and air outlets.
- Do not drive on any gradients or inclines greater than 8 % when the air conditioning unit is in operation. Otherwise the compressor could be damaged.
- Do not operate the unit in cooling mode for extended periods when the vehicle is on an incline. Condensation can enter the interior.



- The air conditioning unit only runs if the vehicle is connected to a 230 V power supply.
- The external 230 V power supply must be protected by a fuse of at least 6 A. It is otherwise not possible to operate the air conditioning unit properly.





- > Always point the remote control at the infrared receiver when using it.

Operating modes

The air conditioning unit can be operated in the following modes:

- Automatic
- Cooling
- Heater
- Air circulation

Remote control

All functions of the air conditioning unit can be operated via the remote control.




Fig. 186 Remote control (air conditioning unit)

- 1 Display
- 2 On/Off button
- 3 Buttons + and for temperature selection
- 4 Sliding door for field with setting buttons
- 5 Fan setting selection button (three levels)
- 6 Mode selection button

Automatic mode

In automatic mode the desired temperature merely has to be set.

Depending on the room temperature, the air conditioning unit automatically selects cooling or heating mode and the fan setting.

Switching on:

Press the On/Off button (Fig. 186,2). The last settings selected are accepted.



- ➤ The circulation fan runs after switching on. The compressor switches itself on after no more than 3 minutes. The blue LED (cooling) or the yellow LED (heating) flashes.
- Use the + and buttons (Fig. 186,3) to set the desired temperature.

Switching off:

Press the On/Off button (Fig. 186,2). The lighting can continue to be operated.






Fig. 187 Function display and air distribution (air conditioning unit)

- 1 Air distribution right/left
- 2 Air distribution ceiling/floor
- 3 IR receiver, function display, manual on/off
- 4 Air distribution front/rear

9.3.1 Operation and display on the unit

Certain functions can be operated directly on the unit.

Air distribution adjustment:

 Set the small adjustment wheel and sliding regulator for stepless air distribution as desired.

Switching on/off manually:

Press the micro button (e.g. with a ballpoint pen if the remote control is not in reach).

Function display

Status LED	Meaning
Blue LED flashes	Compressor starts up (cooling mode)
Blue LED lights up	Cooling operation
Yellow LED flashes	Compressor starts up (heating mode)
Yellow LED lights up	Heating mode
Red LED flashes	Data is transferred
Red LED lights up	Fault

Manual mode

In the manual mode, the cooling, heater, and air circulation can be set separately on the remote control.

Switching on the cooling:

- Press the On/Off button (Fig. 186,2).
- Press the mode selection button (Fig. 186,6) until the cooling symbol appears in the display (Fig. 186,1).
- Use the + and buttons (Fig. 186,3) to set the desired temperature.
- Use the k selection button (Fig. 186,5) to set the desired fan level.

When the room temperature set on the remote control is reached, the compressor switches itself off and the blue LED in the IR receiver goes out. The circulation fan continues to run.

When the room temperature rises above the set temperature, the unit automatically switches itself back to cooling mode.

Switching on the heater:

- Press the On/Off button (Fig. 186,2).
- Press the mode selection button (Fig. 186,6) until the heating symbol appears in the display (Fig. 186,1).
- Use the + and buttons (Fig. 186,3) to set the desired temperature.
- Use the k selection button (Fig. 186,5) to set the desired fan level.



When the room temperature set on the remote control is reached, the compressor switches itself off and the yellow LED in the IR receiver goes out. The circulation fan continues to run.

When the room temperature falls below the set temperature, the unit automatically switches itself back to heating mode.

Switching on air circulation:

- Press the On/Off button (Fig. 186,2).
- Press the mode selection button (Fig. 186,6) until the air circulation symbol appears in the display (Fig. 186,1).
- Use the + and buttons (Fig. 186,3) to set the desired temperature.
- Use the keep selection button (Fig. 186,5) to set the desired fan level.

In air circulation mode, the inside air is circulated and is cleaned by the filter. No LEDs light up in the IR receiver.



Fig. 188 Remote control with setting buttons (air conditioning unit)

- Buttons for setting the time and the timer
- 2 Send button (repeat data transfer)
- Micro button RESET (resetting to the factory setting)
- 4 Setup button for start-up
- 5 Light button (for operating the lighting)
- 6 Soft-start button (for quiet cooling operation)
- 7 Time button (for setting the time)
- "TIMER" buttons for switching time preselection on/off

Activating soft-start:

Press the soft-start button (Fig. 188,6). The fan then runs at low speed in cooling mode, which makes it especially quiet.

Setting the time:

- Press the time button (Fig. 188,7).
- Set the hours and minutes with the buttons (Fig. 188,1).

Switching on the timer:

- Press the On/Off button (Fig. 186,2).
- Set the desired mode and temperature.

Programming the switching on time:

- Press ON button (Fig. 188,8).
- Press the buttons for setting the time (Fig. 188,1) until the desired time span until switch-on is reached.
- Press ON button (Fig. 188,8).

Programming the switch-off time:

- Press OFF button (Fig. 188,8).
- Press the buttons for setting the time (Fig. 188,1) until the desired time span until switch-off is reached.
- Press OFF button (Fig. 188,8).

Deactivating the timer:

Press the ON or OFF button (Fig. 188,8) again.

The integrated timer enables the switch-on/switch-off time for the air conditioning unit to be set between 15 minutes and 24 hours in advance (calculated from the current time).

Switching on the lighting:

Press the light button (Fig. 188,5). The light is switched on at the last set dimming level.



Dimming the lighting:

 Press the light button (Fig. 188,5) and keep it pressed until the desired brightness is reached.

Switching off the lighting:

■ Press the light button (Fig. 188,5).



- The Setup button (Fig. 188,4) is used to connect the remote control with the air conditioning unit during first set-up.
- Further information can be obtained in the manufacturer's instruction manual.

9.4 Cooker



- ▶ During operation of the gas cooker, do not leave the gas cooker unattended. Even if the gas cooker cannot be overseen for only a short time (e.g. Visit to the toilet), switch the gas cooker off.
- ▶ Never let gas escape unburned due to danger of explosion.
- ▶ Before using the cooker make sure that there is sufficient ventilation. Open a window or the skylight.
- Do not use gas cooker or gas oven for heating.
- Always protect your hands with cooking gloves or potholders when handling hot pots, pans and similar items. There is a risk of injury!
- ▶ Do not fit any curtains in the immediate proximity of the cooker. Fire hazard!
- ▶ While a burner is on, always place a pot or a pan over the flame.



Do not place any hot objects such as cooking pans neither on the sink cover nor on the gas cooker cover nor on the work top.

9.4.1 Gas cooker



- During activation and operation of the gas cooker, no flammable objects or highly inflammable objects such as dishcloths, napkins etc. must be near the gas cooker. Fire hazard!
- ► The process of ignition must be visible from above and must not be covered by cooking pans placed on the cooker.
- ▶ If there is a flame protection, always put it up when using the gas cooker. Before driving, remove the flame protection and store it safely.
- ► The gas cooker cover is closed by spring force. When closing there is danger of getting injured!



- Do not use the glass gas cooker cover as a hob.
- Do not close the gas cooker cover while the gas cooker is in operation.
- Do not apply pressure on the gas cooker cover when it is closed.
- Keep the gas cooker cover open after cooking until the burners are cool. Otherwise the glass plate could shatter.





- Only use pots and pans whose diameter is appropriate for the gas cooker burners.
- ▶ When the flame goes out, the thermocouple automatically cuts the gas supply.
- ▶ When the glass gas cooker cover is closed, the gas supply is interrupted.
- > Further information can be obtained in the manufacturer's instruction manual.

The vehicle kitchen unit is fitted with a three-burner gas cooker.

The operating controls for the gas cooker are located on the front side underneath the work top.

Automatic ignition with lighting knob

The gas cooker is equipped with electronic ignition.



Fig. 189 Gas cooker

Switching on:

Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".

2

Lighting knob

Control knob

Open the gas cooker cover (Fig. 189).




Fig. 190 Operating controls (gas cooker)

- Turn the control knob (Fig. 190,2) on the burner you wish to use to the ignition position (large flame).
- Press the control knob down and hold it.
- Press lighting knob (Fig. 190,1). Ignition sparks are generated at the burner.
- Once the flame is burning, the control knob must be held down until the thermocouple keeps the gas supply open.
- Release the control knob and turn to the desired setting.



Switching off:

- Turn the control knob to the "0" position. The flame fades.
- Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.

9.4.2 Cooker with gas grill and gas oven (optional equipment)

The vehicle's kitchen unit is equipped with a cooker consisting of a gas grill and a gas oven.

Cooker

The vehicle's cooker is equipped with 3 gas burners.



- ▶ During the lighting process and once a gas burner is in operation, keep all flammable objects or highly inflammable objects such as dishcloths, napkins etc. away from the burner. Fire hazard!
- ▶ When lighting a gas burner, the burner must be visible from above, i.e. it must not be obscured by cooking pans placed on the cooker.
- ▶ If the burner flame is accidentally extinguished, turn the control knob to the "0" position and leave the burner off for at least 1 minute. Then ignite it again.
- ► The cooker cover is closed by spring force. When closing there is danger of getting injured!



- ▷ Do not use the glass cooker cover as a hob.
- Do not close the cooker cover while the cooker is in operation.
- ▷ Do not apply pressure on the cooker cover when it is closed.
- Do not place hot cooking pans on the cooker cover.
- After cooking, leave the cooker cover open until the gas burners have cooled down. Otherwise the glass plate could shatter.



- Only use pots and pans whose diameter is appropriate for the gas cooker burners.
- When the flame on a gas burner goes out, the thermocouple automatically cuts the gas supply.
- Further information can be obtained in the manufacturer's instruction manual.





Fig. 191 Cooker with gas burners

Gas burners

The cooker is equipped with 3 gas burners (Fig. 191).

Turning on a gas burner:

- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
- Open the cooker cover (Fig. 191).



Fig. 192 Operating controls (kitchen unit)

- Control knob (cooking plate)
- 2 Control knob (gas grill)
- 3 Lighting knob
- Control knob (gas oven)

- Press control knob (Fig. 192,1) of the desired burner, turn it to the ignition position (large flame), and hold it until the flame is burning (for a maximum of 15 seconds).
- Once the flame is burning, the control knob must be held down until the thermocouple keeps the gas supply open.
- Release the control knob and turn to the desired setting.
- If the flame fails to light, wait 1 minute and repeat the procedure from the start.

Turning off a gas burner:

- Turn the control knob to the "0" position. The flame fades.
- Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.



Gas grill

The gas grill is located below the operating controls (Fig. 192).



- ▶ When the gas oven is in operation, the grill area can also become very hot, even though the gas grill itself is switched off. Never touch hot parts with bare hands.
- ▶ When lighting the grill and when grilling, the flap of the gas grill must always remain open.
- ► Keep all flammable or highly inflammable objects such as dishcloths, napkins, etc. away from the gas grill during the lighting process and during operation. Fire hazard!
- ▶ If ignition has not been successful, repeat the entire procedure. If necessary, check if there is gas and/or current in the gas grill.
- ▶ If the gas grill still does not work, close the gas isolator tap and notify an authorised service centre.
- ► If the burner flame is accidentally extinguished, turn the control knob to the "0" position and and leave the burner off for at least 1 minute. Then ignite it again.



Before using the gas grill for the first time, run it empty for 20 minutes at maximum power. This will remove any manufacturing residue. This can result in the formation of non-toxic smoke. Open all windows and ventilate well.

Switching on the gas grill:

- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
- Open the flap of the gas grill to the fully open position.
- Lightly press the control knob (Fig. 192,2) and turn to lighting position (large flame).
- Press the lighting knob (Fig. 192,3) until the flame appears (a maximum of 15 seconds).
- Once the flame is burning, the control knob must be held down until the thermocouple keeps the gas supply open.
- Release the control knob and turn to the desired setting.
- If the flame fails to light, wait 1 minute and repeat the procedure from the start.

Switching off the gas grill:

- Turn the control knob to the "0" position. The flame fades.
- Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.



Gas oven

The gas oven is installed under the gas grill.



- ▶ When the gas oven is in operation, the grill area can also become very hot, even though the gas grill itself is switched off. Never touch hot parts with bare hands.
- ► There must be no flammable or highly inflammable objects such as dishcloths, clothes, etc. near the gas oven when it is being lit or during operation. Fire hazard!
- The oven flap must remain open when it is being lit.
- ▶ If ignition has not been successful, repeat the entire procedure. If necessary, check if there is gas and/or current in the gas oven.
- ▶ If the gas oven still does not work, close the gas isolator tap and notify your service centre.
- ► If the burner flame is accidentally extinguished, turn the control knob to the "0" position and and leave the burner off for at least 1 minute. Then ignite it again.



- ➢ Before using the gas oven for the first time, operate it empty for 30 minutes at 200 °C. This will remove any manufacturing residue. This can result in the formation of non-toxic smoke. Open all windows and ventilate well.
- The temperature in the gas oven is thermostatically controlled. The temperature range is from 130 °C to 240 °C. The set temperature applies to the centre of the gas oven. The gas oven is hotter at the top and cooler lower down.

Switching on the gas oven:

- Open the regulator tap on the gas bottle and the gas isolator tap "Cooker".
- Open the flap of the gas oven to the fully open position.
- Lightly press in the control knob (Fig. 192,4) and turn to the maximum mark (240 °C).
- Press the lighting knob (Fig. 192,3) until the flame appears (a maximum of 15 seconds).
- Once the flame is burning, keep the control knob pressed for another 10 to 15 seconds, until the thermocouple automatically keeps the gas supply open.
- Release the control knob and turn to the desired setting.
- Slide the wire shelf into the gas oven at the desired height and close the oven flap.
- If the flame fails to light, wait 1 minute and repeat the procedure from the start.

Switching off the gas oven:

- Turn the control knob to the "0" position. The flame fades.
- Close the gas isolator tap "Cooker" and the regulator tap on the gas bottle.



9.5 Refrigerator


If there is no gas pressure regulating system with crash sensor present, only operate the refrigerator via the 12 V power supply during the journey. At high ambient temperatures the refrigerator is unable to reach its full cooling power.



- When leaving the vehicle, always mount the refrigerator ventilation grill. Otherwise water can enter during rain.
- The cooling power of the refrigerator depends on the vehicle setup. The cooling power can decrease if the vehicle is inclined by 5° or more. Therefore, always park the vehicle on level ground.
- Absorption refrigerators operate at normal room temperature (approx. 21 °C) within the specified temperature range. At significantly higher ambient temperatures (> 30 °C), the cooling power is reduced.

9.5.1 Refrigerator ventilation grill (optional equipment)

At high external temperatures, the full cooling power of the cooling unit is only guaranteed if the refrigerator is ventilated sufficiently.



B Domets

HYW08987

Fig. 193 Slider on the refrigerator ventilation grill

Fig. 194 Winter cover (refrigerator ventilation grill)

Removing:

- Push slider (Fig. 193) upward.
- Remove refrigerator ventilation grill.

Winter cover

The winter covers (Fig. 194) protect the cooling unit against cold air. Place winter covers in front of both refrigerator ventilation grills when the external temperature falls below +10 °C (both for gas and electrical operation).

In the case of smaller appliances (capacity of less than 130 l) in gas operation, only use the ${f lower}$ winter cover.

In the case of very low temperatures (-5 $^{\circ}$ C to -30 $^{\circ}$ C), use the **insulated** winter cover. Use the insulated winter cover only instead of the **lower** refrigerator ventilation grill.

If the temperature raises again, remove winter covers.

Mounting:

- Open both locks (Fig. 194) (groove in horizontal position).
- Put winter cover in front of the ventilation grill.
- Lock the locks with a small coin (groove in vertical position).

Removing:

- Open both locks (Fig. 194) (groove in horizontal position).
- Remove winter cover from ventilation grill.





- Remove the winter covers when the temperatures rise above +10 °C.
 Otherwise the refrigerator could be damaged.
- Remove the **insulated** winter cover when the temperatures rise above -5 °C. Otherwise the refrigerator could be damaged.



The winter cover may remain mounted during the journey.

9.5.2 Thetford model range N3000 E/A

Depending on the equipment, different versions of the refrigerator will be installed.

Thetford N3000 E model

Manual power selection, automatic ignition

Thetford N3000E+/N3000 A model

Automatic and manual power selection, automatic ignition

Operating modes

The refrigerator has 3 operating modes:

- 230 V operation
- 12 V operation
- Gas operation



- ➤ The refrigerator always requires a 12 V control voltage regardless of which type of energy it is using. The control voltage is present as soon as the transformer/rectifier is switched on. Therefore the closed circuit current always flows even if the refrigerator is switched off. Always switch off the transformer/rectifier for a temporary lay-up.
- Close the gas isolator tap "Refrigerator" when the refrigerator is operated electrically.

230 V operation

The refrigerator is operated via an external power supply.

12 V operation

The refrigerator is operated via the vehicle battery.



In the automatic mode, the 12 Volt operation is only selected, when the vehicle engine is running.

Gas operation

The refrigerator is operated with gas from a connected gas bottle.



▷ If LPG is used, a filter must be used. The filter must be installed by a qualified technician.



Change-over between energy sources

During change-over between the different energy sources, intended delays are installed in the version with automatic power selection. This means, that after a change-over to a new energy source the refrigerator can not be operated immediately. When changing from 12 Volt operation to gas operation, the delay is 15 minutes. This prevents a change-over to gas operation when the vehicle is stopped briefly (e.g. stop to fill tank).

Stop to fill tank



Open flames are prohibited at petrol stations.

If the refrigerator was manually set for gas operation during the journey: switch off the refrigerator in the petrol station area or change over to 12 V operation.

If the refrigerator was operated in the automatic mode during the journey (only in the case of the version with automatic power selection) and the stop for filling the tank takes longer than 15 minutes: switch off the refrigerator. Otherwise, the automatic power selection system will automatically change over to gas operation 15 minutes after stopping the vehicle engine.

Ignition fuse

When selecting gas operation the ignition fuse is opened automatically so gas can get into the burner. At the same time the electronic ignition is activated. If the gas flame is extinguished, e.g. by blast of wind, the ignition is activated immediately and re-ignites the gas.

Operation




Fig. 195 LED operating panel (Thetford refrigerator)

- 1 On/Off button
- 2 Arrow keys
- 3 Confirmation button
- 4 Display of operating mode (A does not exist in all versions)
- 5 Cooling level indicator
- 6 Display "Anti-condensation off"
- 7 Display "Battery flat" (not active)



▷ If the refrigerator shall be operated with gas: Open the regulator tap on the gas bottle and the gas isolator tap "Refrigerator".

Switching on:

- Press and hold the On/Off button (Fig. 195,1) for 1 second. The button lights up green. To save energy, after approximately 10 seconds the display is dimmed.
- Press confirmation button (Fig. 195,3). The operating mode previously selected is displayed.



Selecting operating mode:

- Press and hold the confirmation button (Fig. 195,3) for about 2 seconds. The operating mode symbols flash.
- Manual power selection: use the arrow keys (Fig. 195,2) to select the desired energy source.
- Automatic power selection (only version with automatic power selection): use the arrow keys (Fig. 195,2) to select the operating mode A.
- Confirm your selection with the confirmation button (Fig. 195,3).

In the case of the version with automatic power selection, the power selection is carried out in the following order as a function of the availability of the energy sources:

- 230 V AC
- 12 V DC
- Gas

Setting the refrigerating temperature:

- Press and hold the confirmation button (Fig. 195,3) for about 2 seconds. The operating mode symbols flash.
- Press confirmation button (Fig. 195,3) again. The cooling level indicator (Fig. 195,5) flashes.
- To change the setting, press the arrow keys (Fig. 195,2) until the desired setting is displayed.
- Confirm your selection with the confirmation button (Fig. 195,3).

Switching off:

- Press and hold the On/Off button (Fig. 195,1) for about 2 seconds. All lights go out. Refrigerator is switched off.
- If the refrigerator had been operated with gas: Close the gas isolator tap "Refrigerator" and the regulator tap on the gas bottle.

Refrigerating temperature control

After switching it on, the refrigerator automatically selects the previously selected thermostat position. This position can be adjusted manually by using the arrow keys (Fig. 195,2). It takes a few hours till the refrigerator reaches its normal operating temperature. When changing over to another operating mode, the thermostat setting is kept.

Additional functions

Flashing lamps on the operating unit indicate a fault. For instructions regarding troubleshooting, see chapter 14.



Further information can be obtained from the separate instruction manual "Refrigerator".



9.5.3 Refrigerator door locking mechanism

With some models, the refrigerator has a separate freezer compartment. The specifications in this section correspondingly also apply to the door of the freezer compartment.



During the journey the refrigerator door must always be closed and locked in the closed position.



Lock the refrigerator door in ventilation position when the refrigerator is switched off. This prevents mould forming.

There are two positions for locking the refrigerator door in place:

- Closed refrigerator door during travel and when the refrigerator is in operation
- Slightly opened refrigerator door as a ventilation position when the refrigerator is switched off



 For any further information about the locking device see the manufacturer's separate instruction manual.

Thetford

The refrigerator is opened and closed with the handle on the door.

Ventilation position

The refrigerator door may be locked in ventilation position with a swivelling bracket.



Fig. 196 Locking device (normal position)



Fig. 197 Locking device (ventilation position)

Locking in the ventilation position:

- Open the refrigerator door.
- Swing the bracket (Fig. 196) to the front (Fig. 197).
- Close the refrigerator door up to the first catch; then it is locked in the ventilation position.



Chapter overview

This chapter contains instructions regarding the sanitary fittings of the vehicle.

At the end of the chapter, you will find the positions of the components of the sanitary system.

10.1 Water supply, general



- Fill water tank from supply systems that have been verified to provide drinking water quality.
- ► Only use such hoses or containers when filling that have been approved for use with drinking water.
- ► Thoroughly rinse filling hose or container with drinking water before use (2 to 3 times capacity).
- ► Empty filling hose or container completely after use and close openings of the filling hose or container.
- ▶ Water left standing in the water tank or in the water pipes becomes undrinkable after a short period. Therefore, before each use of the vehicle, thoroughly clean the water pipes and the water tank. After each use of the vehicle completely empty the water tank and the water pipes.
- ▶ In the case of lay-ups lasting more than a week disinfect the water system before using the vehicle (see chapter 11).



- ▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Make certain that the water pump is switched off. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.
- ➤ The water pump will overheat without water and can get damaged after one minute at the latest. Never operate water pump when the water tank is empty.

The vehicle is equipped with a fitted water tank. An electric water pump pumps the water to the individual water taps. Opening a water tap automatically switches on the water pump and pumps water to the tap.

The waste water tank collects the waste water. The water level in the water and waste water tanks can be checked on the panel.

Water pump

Depending on how the vehicle is equipped, the water pump is switched on or off via a separate switch or via the 7" panel.



- ▷ Before using the water fittings, switch the water pump on via the switch or via the 7" panel.
- When the water tank is re-filled, an air bubble may form at the bottom of the pump. This air bubble will prevent water from being drawn in. Shake the water pump up and down energetically in the water.





Fig. 198 Switch for water pump

Vehicles with panel LT 94

In vehicles equipped with the panel LT 94 (see section 8.6), the 12 V appliances are analogue controlled. In this case, a separate switch for the water pump will be installed in the vehicle. The switch is located in the bathroom cabinet.

Vehicles with 7" panel

In vehicles equipped with a BUS system with 7" panel (see section 8.7), the $12\ V$ appliances are digitally controlled. In this case, the water pump is operated via the 7" panel.

10.2 Water system

10.2.1 Water tank

The water tank holds approx. 180 l.

Position of the water tank, see section 10.2.4.

Hot air from the living area heater heats the water tank. This protects the water tank from frost.



If the living area heater is out of order, the water tank no longer is sufficiently protected against frost. If there is a risk of frost, empty the water tank and leave the drain cock open.



 For driving safety and for regulatory reasons, when the vehicle is motion the fill quantity must be reduced to approximately 20 litres. If the water is drained using the safety drainage rotary handle (see section 10.2.5), a residual quantity of approximately 20 litres will remain in the water tank.



10.2.2 Filling the water system



▶ When filling the water tank, observe the technically permissible maximum laden mass of the vehicle. Luggage must be reduced accordingly when the water tank is full.



The water pump will overheat without water and can get damaged after one minute at the latest. Never operate water pump when the water tank is empty.



- The water quantity can be monitored on the panel while the water tank is filled.
- Position the vehicle horizontally.
- Switch on the 12 V power supply on the panel.




Fig. 199 Safety/drainage valve (Truma)

1 Knob

Push button

- Close the safety/drainage valve (Truma). Turn the knob (Fig. 199,1) perpendicular to the safety/drainage valve and push the push button (Fig. 199,2) in.
- If the temperature is below 6 °C, the safety/drainage valve cannot be closed.




Fig. 200 Drain cock (water pipe)



Fig. 201 Drain cock (Alde boiler)

- Close drain cocks (Fig. 200 and Fig. 201). To do so, close the caps by turning them in a clockwise direction and set the rocking lever in a horizontal position. The position of the safety/drainage valve and the drain cocks is specified in the section 10.7 at the end of this chapter.
- Close all water taps.



- Close drainage opening on the water tank.
- Open the drinking water filler neck on the outside of the vehicle.
- Fill the water tank with drinking water. Use a water hose, a water canister with a funnel or similar for filling.
- Switch on the water pump at the switch.
- Set all the water taps to Hot and open them. The water pump is turned on. The warm water pipes are filled with water.
- Keep the water taps open until the water flowing out of the water taps has no bubbles in it. This is the only way to ensure that the boiler is full of water.
- Set all water taps to Cold and leave them open. This will fill the cold water pipes with water.
- Keep the water taps open until the water flowing out of the water taps has no bubbles in it.
- Close all water taps.
- Close drinking water filler neck.
- Check that the cap on the water tank is not leaking.

10.2.3 Topping up the water



- ► The cap for the fuel filler neck and for the drinking water filler neck are very similar. Before filling the tank, always check the label.
- When filling the water tank, observe the technically permissible maximum laden mass of the vehicle. Luggage must be reduced accordingly when the water tank is full.



Fig. 202 Cap (drinking water filler neck)

The drinking water filler neck is on the right or left side of the vehicle, depending on the model.

The drinking water filler neck is marked by the symbol 🖏

Opening the drinking water filler neck:

- Swivel the external flap (Fig. 202) upwards.
- Insert key into locking cylinder and turn a quarter turn. The cap is unlocked.
- Remove the key.
- Turn the blue cap (Fig. 202) one quarter turn.
- Remove the cap.



Filling with water:

Fill the water tank with drinking water. Use a water hose, a water canister with a funnel or similar for filling.

Closing the drinking water filler neck:

- Place cap on the drinking water filler neck.
- Turn cap one quarter turn.
- Insert key into locking cylinder and turn a quarter turn. The cap is locked
- Remove the key.
- Check that the cap sits firmly on the drinking water filler neck.
- Swivel external flap downwards and close it.

10.2.4 Reducing the water quantity for mobile operation

Rotary handle

The rotary handle is installed on the water tank.



Fig. 203 Rotary handle (water drainage)

Opening:

■ Turn the rotary handle (Fig. 203) on the water tank in an anticlockwise direction up to the first catch. Excess water will drain away leaving approx. 20 litres in the tank.

Closing:

Turn the rotary handle (Fig. 203) on the water tank in a clockwise direction as far as it will go.

Position See section 10.7.

10.2.5 Draining water (safety drainage rotary handle)

■ Turn the rotary handle (Fig. 203) on the water tank in an anticlockwise direction as far as possible beyond the resistance to fully open the drainage opening.



10.2.6 Emptying the water system



▷ If the vehicle is not used for several days or if it is not heated when there is a risk of frost, empty the entire water system. Make sure that the 12 V power supply on the panel is switched off. Otherwise, the water pump will overheat and may get damaged. Leave the water taps on in central position. Leave the safety/drainage valve (Truma) and all drain cocks open. Frost damage to appliances, frost damage to the vehicle and deposits in water-carrying components can be avoided in this way.



➤ Take note of the environmental tip in this chapter.

The position of the safety/drainage valve and the drain cocks is specified in the section 10.7at the end of this chapter.

To empty and ventilate the water system, proceed as follows. This will avoid frost damage:

- Position the vehicle horizontally.
- Switch off 230 V power supply.
- Switch off the 12 V power supply on the panel.
- Shut off the boiler (see section 9.2).
- Open the drain cocks. To do so, turn the cap in an anticlockwise direction or set the rocking lever in a vertical position.
- Open the safety/drainage valve (Truma). To do this, turn the knob parallel to the safety/drainage valve.
- Open the water tank drain.
- Open all water taps and set to the central position.
- Hang the shower handset up in the shower position.
- Unscrew the lock ring on the water tank.
- Take water pump (fitted to the cover) as far as the connecting lines allow
- Hold the water pump up until the water pipes are completely empty.
- Check whether the water tank is completely empty.
- Set the shower handset down in the shower tray.
- Blow out the remaining water in the water pipes (max. 0.5 bar). In order to do this, remove the water pipe from the water pump and blow into the water pipe in the direction of the appliances.
- Empty the waste water tank. Take note of the environmental tips in this chapter.
- Empty the sewage container. Take note of the environmental tips in this chapter.
- Clean the water tank and then rinse it out thoroughly.
- Let the water system dry for as long as possible.
- After emptying, leave all water taps on in the central position.
- Leave the safety/drainage valve (Truma) and all drain cocks open.



10.3 Water filter (optional)



- ▶ Do not use the water filter to filter well water, waste water, river water or rainwater. The water filter is not suitable for obtaining drinking water in this way.
- Do not use the water filter to filter hot water.
- ► For handling the water filter safely, observe the separate instruction manual of the manufacturer (especially the safety instructions).

Purpose

The water filter is only intended for filtering cold drinking water.

The water filter produces hygienic fresh water from it.

Position

The water filter is installed on the left side of the vehicle and is accessible via an external flap.

The filter cartridge of the water filter is connected to the filter head via a bayonet lock.

The filter head has an integrated stop valve. No additional stop valves are required in the inlet and outlet.



The procedure for changing the filter and further information can be obtained in the separate manufacturer's instruction manual.

10.4 Waste water tank

The waste water tank holds approx. 150 l.

Position and access, see section 10.7.

Hot air from the living area heater heats the waste water tank. This protects the waste water tank from frost.



- If the living area heater is out of order, the waste water tank no longer is sufficiently protected against frost. If there is a risk of frost, empty the waste water tank and leave the drain cock open.
- Never pour boiling water directly into the sink outlet. Boiling water could cause deformation and leaks in the waste water pipe system.



Only empty the waste water tank at disposal stations, camping sites or caravan sites especially provided for this purpose.

Depending on the equipment, the drain cock is opened and closed via an operating lever or electrically via a rocker switch.



The operation of the waste water tank drainage using the rocker switch is only possible when the vehicle is standing and the vehicle engine is switched off.



Electrically operated drain cock

The drain cock for the waste water tank is opened and closed using a rocker switch of the switch panel in the driver's cabin. To prevent an unwanted opening of the drain cock, the rocker switch is provided with a safety slide button.



Fig. 204 Rocker switch (waste water drainage)

Emptying the waste water tank:

- Position the vehicle over the outflow of the waste water disposal station.
- Push the safety slide button (Fig. 204,1) on the rocker switch downwards and, at the same time, press the lower part of the rocker switch (Fig. 204,2). Doing this, the waste water valve is opened and the waste water tank is emptied. The LED is lit as long as the waste water valve is open.

Operation using operating lever

The drain cock is opened and shut using an operating lever.




Fig. 205 Operating lever (drain cock)

Position of operating lever

The operating lever (Fig. 205) for waste water disposal is located in the rear garage. The drain pipe with a connection for a waste water hose is located under the vehicle.










Fig. 207 Drain pipe with waste water hose

Waste water hose

The waste water hose (Fig. 206) is located in the gas bottle compartment or in the gas bottle compartment pull-out and can be plugged on the drain pipe (Fig. 207) as an extension.

Emptying:

- Attach the waste water hose to the drain pipe.
- Open the drain cock. In order to do this, turn the operating lever (Fig. 205) to the open position (AUF). The waste water will run out.
- Completely empty waste water tank.
- Close the drain cock again once all of the waste water has run out. In order to do this turn the operating lever (Fig. 205) to the closed position (ZU).
- Remove and store the waste water hose.

10.5 Bathroom



> Do not transport any loads in the shower tray. The shower tray or other items of equipment in the toilet compartment can be damaged.



- For ventilation purposes during or after a shower, and for drying wet clothing, close the toilet compartment door and open the window or the toilet compartment skylight. This improves the air circulation.
- After taking a shower, rinse soap residue from the shower tray, otherwise cracks can appear in the shower tray over time.
- > After using the shower, wipe it dry to prevent moisture from collecting.
- Pitch the vehicle so that it is as horizontal as possible. Otherwise, the water from the shower tray will not be able to drain properly.
- Further information about cleaning the toilet compartment can be found in the section 11.3.



Shower shelf

The shelf is made of solid wood. The shelf protects the shower tray and provides a dry floor, even after taking a shower.



Fig. 208 Shelf (example)

Observe the following for a long service life:

- Before taking a shower, remove the shelf (Fig. 208) from the shower.
- Place the shelf back into the shower tray after showering.
- Clean the shelf at least every six months.

10.6 Toilet



- Do not load the toilet with more than a maximum of 120 kg.
- ▷ If there is any risk of frost and the vehicle is not heated, empty the sewage container.
- Do not sit on the lid of the toilet. The lid is not designed to bear the weight of a person and could break.
- Use a suitable chemical for this toilet. The ventilation will merely remove the odour but not germs and gases. Germs and gases will have a detrimental effect on the sealing rubbers.



- ▷ If the vehicle is equipped with an electrical ventilation system, the fan starts up automatically when opening the toilet slide valve.
- > Further information can be obtained in the manufacturer's instruction manual.



Only empty the sewage container at disposal stations, at camping sites or caravan sites, that are especially provided for this purpose.



10.6.1 Swivel toilet

The flushing of the Thetford toilet is fed directly from the water system of the vehicle. The toilet bowl can be moved into the optimal position.



Fig. 209 Thetford toilet bowl (swivelling)

1 Slide lever



Fig. 210 Flush button / indicator lamp (example)

- 1 Flush button
- 2 Indicator lamp

The operating unit is located close to the toilet bowl.

Flushing:

- Before flushing open the sliding trap of the Thetford toilet. To do this, push the slide lever (Fig. 209,1) in an anticlockwise direction.
- For flushing, press the blue flush button (Fig. 210,1).
- After flushing close the sliding trap. To do this, push the slide lever in a clockwise direction.

The indicator lamp (Fig. 210,2) lights up whenever the sewage container needs to be emptied.



10.6.2 Toilet with fixed seat

The toilet is flushed via the fresh water tank.

The toilet can be used with the sliding trap open or closed.




Rotary handle

Fig. 211 Thetford toilet

Opening the sliding trap:

- Turn the rotary handle (Fig. 211,1) in an anticlockwise direction.
- Closing the sliding trap:
- Turn the rotary handle (Fig. 211,1) clockwise.



1 Indicator lamps

- 2 Flush button
- 3 Rotary handle
- 4 Indicator lamp

Fig. 212 Flush button / indicator lamps (Thetford toilet)

Flushing:

- Before flushing open the sliding trap of the Thetford toilet. To do this, turn the rotary handle (Fig. 212,3) in an anticlockwise direction.
- For flushing, press the blue flush button (Fig. 212,2).
- After flushing close the sliding trap. To do this, turn the rotary handle (Fig. 212,3) in a clockwise direction.

The Indicator lamps (Fig. 212,1) show the filling level of the sewage container. The red indicator lamp (Fig. 212,4) is lit whenever the sewage container has to be emptied.



10.6.3 **Emptying the sewage container**



If the vehicle is equipped with an electrical ventilation system: Before emptying the sewage container, remove the hose of the ventilation system from the sewage container.



- The sewage container can only be taken out if the sliding trap is closed.
- Take any further information from the manufacturer's instruction manual.



Locking cylinder Push-button lock

- Fig. 213 Flap (sewage container)
- Slide the slide lever on the toilet bowl in a clockwise direction. The sliding trap is closed.
- Open the flap for the sewage container on the outside of the vehicle. Insert the key into the locking cylinder of the push-button lock (Fig. 213,1) and turn a quarter turn in a clockwise direction.
- Remove the key.
- Press both push-button locks (Fig. 213,2) simultaneously with your thumb and open the flap for the sewage container.
- If the vehicle is equipped with an electrical ventilation system: Pull off the hose of the ventilation system.



Sewage container 2

- Handle
- Safety clamp

Fig. 214 Sewage container (in vehicle)

Pull the safety clamp (Fig. 214,3) upwards and use the handle (Fig. 214,2) to pull out the sewage container (Fig. 214,1).





Fig. 215 Sewage container

- 1 Outlet pipe
- 2 Cover
- 3 Ventilation button

- At a disposal station that is especially provided for this purpose, swivel the outlet pipe (Fig. 215,1) forwards and unscrew cover (Fig. 215,2).
- Press the coloured ventilation button (Fig. 215,3) and hold it there until the sewage container is empty.
- Clean the sewage container with fresh water.
- Close outlet pipe with cover and swivel it back.
- Push sewage container into the disposal chute until it engages.
- If the vehicle is equipped with an electrical ventilation system: Connect the hose of the ventilation system.
- Close flap for sewage container.
- Fill in new sanitary liquid.

10.6.4 Electrical ventilation system

The electrical ventilation system aspirates the air in the toilet compartment, leads it through the sewage container and then outside via an outlet in the floor, in the door, or in the roof.



- If the vehicle is equipped with an electrical ventilation system, the fan starts up automatically when opening the toilet slide valve.
- Further information can be obtained in the manufacturer's instruction manual.

10.6.5 Winter operation



Do not use anti-freeze. Anti-freeze can damage the toilet.

When the vehicle is being heated, the toilet, the water tank and the sewage container are in a frost-protected area. This means that the toilet can also be used in winter.

If the vehicle is not being heated and there is a risk of frost, empty the water tank, the sewage container and the water pipes. This prevents frost damage.



10.6.6 Temporary lay-up



If the toilet is not to be used for an extended period, empty the water tank, the sewage container and the water pipes.

Laying up the toilet:

- Empty the water tank.
- Flush the toilet until no more water runs into the toilet. Note that the pump can get damaged after one minute at the latest if it runs dry.
- Empty the sewage container.
- Rinse the sewage container thoroughly.
- Leave the drainage neck on the sewage container open.
- Allow the sewage container to dry.

10.7 Installation positions



Fig. 216 Drain cock (Alde boiler)




Fig. 217 Drain cock (water pipe)



Fig. 218 Safety/drainage valve (Truma)

Depending on the model, the components of the sanitary fittings are accessible at the following positions:

Fresh water tank (access)	Waste water tank (access, cleaning)	Waste water tank (access, drain cock)	Water drain valves	Safety/ drainage va- lve
In the double floor under- neath floor trap	In the double floor under- neath floor trap	Spherical valve with handle in the rear garage	In the storage compartment on the driver's side	In the storage compartment on the driver's side



218



Chapter overview

This chapter contains instructions regarding the care of the vehicle.

At the end of the chapter there is a checklist of measures you must carry out if you are not going to use the vehicle for an extended period of time.

11.1 General



The vehicle is designed for recreational use. Use that goes beyond normal recreational use (permanent use) can lead to moisture forming in the interior. In addition, the interior may be affected.

11.2 External care

Standard external care consists of regular washing. The use and the environmental conditions will determine how often the vehicle needs to be washed. Wash the vehicle more frequently in areas which are exposed to heavy air pollution or heavy traffic or roads treated with de-icing salts. If the vehicle is exposed to salty and humid air (coastal areas, humid climates), wash the vehicle more frequently.

Do not park under trees if at all possible. The resin-like discharge which many trees secrete, give the paintwork a matt look and can promote the onset of corrosion.

Wash off bird droppings straight away and thoroughly, as the acid it contains is extremely corrosive.

11.2.1 Washing with a high-pressure cleaner



- Do not clean the tyres with a high-pressure cleaner. The tyres might be damaged.
- Do not spray external applications (deco-films) directly with the highpressure cleaner. The external applications could come off.

Before cleaning the vehicle with a high-pressure cleaner, observe the operating manual of the high-pressure cleaner.

When cleaning with the nozzle for circular jet between the vehicle and the cleaning nozzle, maintain a minimum distance of approx. 700 mm.

Take into consideration that the jet of water comes out of the cleaning nozzle with pressure. The vehicle may be damaged by incorrect handling of the high-pressure cleaner. The temperature of the water should not be above 60 °C. Keep the jet of water in constant movement during the washing process. Do not direct the water jet at clearances, built-in electrical parts, plugs, seals, the ventilation grill or the skylights. The vehicle may be damaged or water may enter the interior.



11.2.2 Washing the vehicle



- When cleaning in automatic car washes, water may penetrate openings such as the refrigerator ventilation grille or waste gas vent. Never clean the vehicle in an automatic car wash. When washing by hand, make sure that no water enters through the openings.
- Wash the vehicle only on a washing site intended for this purpose.
- When cleaning in direct sunlight, make sure that the cleaning agent used does not cause harmful reactions.
- When using a cleaning agent, observe the manufacturer's instructions for use. Cleaning agent must be pH-neutral.
- First, test the suitability of the cleaning agent on an inconspicuous spot.
- Only clean external applications and synthetic parts with plenty of warm water, dish washing liquid and soft cloth.
- Wash down the vehicle with plenty of water, a clean sponge or a soft brush. In the case of stubborn dirt add dish washing liquid to the water.
- Painted exterior walls may also be cleaned with a caravan cleaner.
- Do not treat rubber seals with agents that are corrosive or contain silicone (e.g. alcohols, plasticisers, organic solvents). It is possible to use talcum or white Vaseline without any problems. HYMER recommends a high-quality, perfluorinated lubricant to treat the rubber.
- Treat locking cylinder of doors and storage flaps with graphite dust.

11.2.3 Windows of acrylic glass

Acrylic glass windows are delicate and require very careful handling.



- Never rub acrylic glass windows dry as dust particles might damage the surface.
- Only clean acrylic glass windows with plenty of warm water, some dish washing liquid and a soft cloth.
- Never use glass cleaning agents with chemical, abrasive or alcohol-containing additives. Premature brittleness of the panes and associated cracks may result from their use.
- Avoid contact of cleansing agents used for the body (e.g. tar- or silicone-removing agents) with acrylic glass.
- Do not clean vehicle in car wash.
- Do not attach stickers to the acrylic glass windows.
- Treat rubber seals with a conventional rubber care product.



An acrylic glass cleanser with antistatic effect is suitable for a follow-up treatment. Small scratches can be treated with an acrylic glass polish. These agents are available at the accessories shop.



11.2.4 Add-on parts made of glass-fibre reinforced plastic (GRP)



- > Avoid contact between polish and window rubber and piping.
- The glass-fibre reinforced plastic (GRP) may not become too hot. Therefore when polishing with a polishing machine, keep the machine in constant motion.



▷ In the case of large-surface GRP components, superficial cracking may occur due to ageing. This is a property of the GRP material composite with GelCoat coating that does not affect the function of the component. Therefore, there is no reason for complaint.

Add-on parts made of GRP can yellow or weather due to lack of vehicle care and material ageing.

GRP add-on parts should therefore undergo regular follow-up treatment. This way, these parts will not turn yellow and the sealing of the surface remains intact.

Follow-up treatment of GRP add-on parts:

- Wash the vehicle and allow to dry as described above. Check if the GRP add-on parts are clean and dry.
- Apply the polisher with a soft cloth evenly on the surface of the GRP add-on part.
- Wait until a light grey film forms.
- Wipe the GRP add-on part with a dry, soft cloth. Move the cloth in circles over the surface of the GRP add-on part.

We recommend using a polishing machine for this work.



Paint protection has to be used to preserve the polish. Please read the instructions of the paint protection for details on how to apply it.

11.2.5 Underbody

The underbody of the vehicle is partly coated with an age-resistant underbody protection. Should the underbody protection be damaged, repair immediately. Do not treat areas coated with underbody protection with spray oil.



Only use products approved by the manufacturer. Our authorised dealers and service centres will be happy to advise you.

11.2.6 Engine compartment



- Cleaning and care of the engine compartment may only be carried out while the ignition is switched on.
- ▶ Before carrying out any work in the engine compartment, read and observe the corresponding warning and handling instructions in the operating manual of the base vehicle manufacturer.





- Do not aim the steam jet directly at the lamp housings, actuators or seals. This may prevent humidity in the headlights and the defects resulting therefrom.
- Do not aim the steam jet at the windscreen wiper motor and the wiper mechanics.
- Only apply protective engine lacquer when the components in the engine compartment have cooled down and are clean.
- Only use lubricants, greases and fluids authorised by the base vehicle manufacturer.

The body manufacturer excludes any guarantee for damages, leaks, or the failure or electrical components that appear after an engine washing.

11.2.7 Windscreen washer system and windscreen wipers



- Only fill the cleaning agents (with/without frost protection) into the washer fluid container which are listed in the operating manual of the base vehicle manufacturer and in the mixing ratio specified therein. Do not use any radiator frost protection or other products. These products affect the cleaning effect and attack the windscreen blades.
- Do not switch the windscreen washer system or the windscreen wipers on when the windscreen blades are frozen to the windscreen. Release the windscreen blades first using a defrosting product.
- Do not remove the snow accumulated on the windscreen with the windscreen wipers. Remove the snow from the windscreen with a brush first.
- Do not switch on the windscreen wipers on a dry windscreen.
- Do not clean the windscreen wiper mechanics and the windscreen wiper motor with a steam blaster.
- Check the correct functioning of windscreen washer system and windscreen wipers periodically.
- Check the filling level of the washer fluid container periodically. Only if sufficient cleaning fluid reaches the windscreen, the windscreen wipers will be able to clean it in a satisfactory way. A clear view contributes decisively to safe driving.
- Before the frost period starts, fill the washer fluid container with windscreen cleaning product containing sufficient frost protection.
- Refill windscreen washing fluid on time. Only use clean water to dilute the windscreen cleaning product.
- Remove insect residues from the windscreen blades as soon as possible.
- Clean the windscreen blades periodically with a windscreen cleaning product. To do this, move a sponge or a cloth along the rubber strip.
- Remove car wax residues after the vehicle washing using a wax dissolving windscreen cleaning product.
- Remove dirt accumulations on the nozzles of the windscreen washer system periodically.
- After journeys on heavily soiled roads, spray clear water on the wiper nozzles to prevent incrustations.
- Clean obstructed wiper nozzles with a fine needle.



11.2.8 Air conditioning unit



- Do not clean the air conditioning unit with a high-pressure cleaner. Water entering can damage the air conditioning unit.
- Do not clean vehicle in car wash.
- Do not use any sharp or hard objects when cleaning. Otherwise the air conditioning unit and roof window can be damaged.



- Use only the cleaning agents recommended by the manufacturer to clean the roof window. Our authorised dealers and service centres will be happy to advise you.
- Use only water and a gentle cleaning agent to clean the air conditioning unit
- Wipe the air conditioning unit housing and the air outlet occasionally with a damp cloth.
- Clean the remote control occasionally with a slightly damp cloth. Clean the display with a spectacles cleaning cloth.
- If necessary, clean the blinds with a mild soap solution and plenty of water.
- Remove leaves and other dirt from the ventilation openings on the air conditioning unit regularly.
- Check the condensation drain holes regularly to ascertain whether the condensation can run off freely.
- Clean the filters on both sides of the air discharge unit regularly.
- Change the active carbon filters on both sides of the air discharge unit annually.
- Inspect the profile seal to the vehicle roof for damage annually.



Further information can be obtained in the manufacturer's instruction manual.

11.2.9 Entrance step

If the entrance step is lubricated, coarse particles of dirt can settle on the lubricant during the journey and cause damage to the operating mechanism of the entrance step. Therefore, do not lubricate the moving parts of the entrance step.



11.3 Interior care



- Synthetic parts in the toilet and living area are very delicate and should be treated with care. Do not use solvents, alcohol-containing cleansers or scourers. This procedure will help you to avoid brittleness and formation of cracks.
- Do not pour any corrosive agents into the drain holes. Never pour boiling water directly into the drain holes. Corrosive agents and boiling water cause damage to drainage pipes and siphon traps.
- Do not use vinegar based products to clean the toilet and water system, or for descaling the water system. Vinegar-based products may cause damage to seals or parts of the installation. Use standard descaling products for descaling.
- Save water. Mop up all remaining water.



- For information about the use of maintenance products, our representatives and service centres will be glad to advise.
- Surface and knobs of furniture, lamps and synthetic parts in the toilet and living area should be cleaned with water and a wool cloth. A mild cleanser may be added to the water. If required, use furniture polish for the painted surfaces.
- Curtains and net curtains should be dry cleaned.
- Vacuum clean the carpet, if necessary clean with carpet shampoo.
- Clean PVC-floor covering with a mild, soapy cleaning agent for PVC floors. Do not place carpet on wet PVC-floor covering. The carpet and the PVC-floor covering may stick together.
- Brush insect screen with a soft brush or vacuum with the brush attachment of the vacuum cleaner.
- Brush blinds with a soft brush or vacuum with the brush attachment of the vacuum cleaner. Grease or stubborn dirt may be removed with a mild soap at 30 °C (curd soap).
- Brush Roman shades with a soft brush or vacuum with the brush attachment of the vacuum cleaner. Grease or stubborn dirt may be removed with a mild soap at 30 °C (curd soap).
- Unrolled seat belts can be cleaned with warm soapsuds. The seat belt must be completely dry before being rolled up.



11.4 Wall covering, inside (Renolit)



- Do not use scouring (abrasive) cleaning agents such as ATA or Viss.
- Do not use bleaching/oxidising cleaning agents.
- Do not use cleaning agents with care additives such as wax or polymer dispersions. This also includes cockpit or plastic sprays.
- Do not use wood care products or polishes.
- Do not use any high-pressure cleaners.
- Do not use concentrated alcohol (methylated spirits, isopropanol).
- Before using diluted alcohol or cleaning agents containing alcohol, carry out a test on a concealed area.
- Remove any dirt with warm, diluted soapy water. If necessary, use a soft brush or sponge. Dilutions of all common household cleaners recommended for plastic surfaces (ionic and non-ionic surfactants) are suitable. Remove residues of the soapy water with clear water and rub dry with a soft cloth. Test the suitability of cleaning agents of all kinds in advance in a concealed place.
- Any dirt that cannot be removed with soapy water can be removed with diluted alcohol (ethanol) or cleaning agents containing alcohol (e.g. window cleaner). Carry out a test in a concealed place beforehand. Wipe the soiled area only briefly and with little pressure. Do not allow the cleaning agent to take effect for a longer period of time.

11.5 Kitchen installation

11.5.1 General notes on care

- Never clean the sink or the gas cooker with a scourer. Avoid anything which may cause scratching or grooves.
- The surface of the kitchen worktop is not scratch proof. When working with sharp objects, always use a pad. Only use soft cleaning agents for cleaning and care. Do not use any abrasive or scratching intensive treatment products nor scratching sponges.
- Clean the sink cover manually using water and washing-up liquid. Do not clean the sink cover in the dishwasher.
- Clean the burners on the gas cooker using a damp cloth only. Prevent any water from penetrating the burner covers. Water may damage the burners on the gas cooker.
- When cleaning the burner ring, ensure that the holes are not obstructed.
- Clean the surface of the cooker, and particularly the hob, with warm water and some washing-up liquid. Scouring agent or sharp objects damage the surface of the hob.
 - The surface of the hob is easier to clean when it is still slightly warm. Before cleaning, ensure that the hob is only still warm to the touch (residual heat indicator has gone out).
 - Always clean the hob before using it again.
- The knobs can be pulled off for cleaning.
- Clean the external surfaces of the kitchen installation with a wet cloth without abrasive, corrosive or chloride containing cleaning agents. Do not use any steel wool.



- Immediately remove acidic or alkaline substances (vinegar, salt, lemon juice, etc.).
- Let the oven and grill cool down before cleaning. Hot surfaces may be damaged due to cold water or a wet cloth. Clean enamelled surfaces only with soap water or washing-up liquid containing water.

11.5.2 Refrigerator

- Clean the exterior and interior of the refrigerator with a soft cloth and lukewarm water (containing a mild cleaning agent).
- Then, wash the refrigerator out with clear water and let it dry.
- Keep the defrosted water drain channel free of sediments.
- To prevent material changes, do not use any soap, nor any sharp, granular or soda containing cleaning agents.
- Keep oil and grease away from the door seal.

11.6 Stainless steel surfaces



- Do not clean the stainless steel surfaces with bleaching agents, with products that contain chloride or hydrochloric acid, baking powder nor with silver polish.
- Do not use scouring agent nor coarse sponges.



- Prior to cleaning, test the suitability of the cleaning product for the surface on an unobtrusive spot.
- > Dry the surfaces thoroughly after cleaning to prevent limescale.
- ▷ In the case of brushed stainless steel surfaces, wipe in a direction of the grinding.

Removing scratches from the surface:

- Treat the stainless steel surface with a soft cleaning cloth and with a special stainless steel cleaner.
- Rinse the stainless steel surface and dry it with household wipes.

Removing stubborn dirt and burnt-in fat:

- Clean the stainless steel surface with an ordinary household sponge and with cleanser.
- Rinse the stainless steel surface and dry it with household wipes.

Removing fingerprints:

- Clean the stainless steel surface with a soft cleaning cloth and soapy water or a glass cleaning agent.
- Rinse the stainless steel surface and dry it with household wipes.

Removing coffee or tea stains:

- Treat the stainless steel surface with a baking soda solution. Allow the baking soda solution to work in for 15 minutes.
- Rinse the stainless steel surface and dry it with household wipes.

Removing rust stains:

- Clean the stainless steel surface with an ordinary household sponge and with cleanser. If necessary, use a soft cleaning cloth and stainless steel cleaner.
- Rinse the stainless steel surface and dry it with household wipes.



11.7 Cushions

The care and cleaning instructions below are for assistance only. They are not a guarantee of successful cleaning. These instructions cannot form the basis for any warranty claims.



- Never use household cleaners to remove stains (e.g. detergents).
- ▷ Before treating stains, test the cleaning on a hidden part of the upholstery covers. This will show you whether the cleaning will damage the materials or dyes.
- Always only dab moist or greasy stains, never rub them. It is most effective to gently press an absorbent cloth or a sponge onto the stain.
- Do not wash upholstery.
- When cleaning leather covers, make sure that the leather is not soaked through and that no water seeps through the seams of the leather covers.



- Treat the stain from the outside working inwards. This prevents the stain from spreading.
- ▷ In the case of both solid or softer contamination, first remove the coarse parts. Next, carefully scrape off the stain with a blunt knife or spatula.
- ➤ The upholstery will fade over time, if it is exposed to sunlight. If the temperature within the vehicle rises rapidly as well, the colour will change at an accelerated rate.
 - Therefore, we recommend to close the shades on the windows when there is strong sunlight. Ensure that heat does not build up when you close the blind.
- > Depending on the equipment, the cushions will be provided with stain protection.

Removing grease, oil, wine, milk, non-alcoholic beverages:

- Moisten a cloth with commercial water-based cleaning agent. (Alternatively, mix 2 tablespoons of ammoniac with 1 litre of water.)
- Gently dab the stain with the cloth.
- Turn the cloth frequently so that the stain only comes into contact with a clean part of the cloth.

Removing urine, sweat:

- Moisten a cloth with commercial water-based cleaning agent. (Alternatively, mix 2 tablespoons of ammoniac with 1 litre of water.)
- Gently dab the stain with the cloth.
- Turn the cloth frequently so that the stain only comes into contact with a clean part of the cloth.

Removing chocolate, coffee:

- Moisten cloth with lukewarm water.
- Dab the stain with the cloth.

Removing fruit residues:

- Moisten cloth with cold water.
- Dab the stain with the cloth.

Removing wax:

- Carefully scrape off the wax with a blunt knife or spatula.
- Cover the stain with several layers of blotting paper and iron it.



Removing blood:

- Mix 2 tablespoons of salt and 1 litre of water.
- Moisten the stain and dab with a dry cloth.
- Dab stubborn stains with ammonia solution.

Removing (ball pen) ink:

- Moisten cloth with benzine.
- Gently dab the stain with the cloth.
- Turn the cloth frequently so that the stain only comes into contact with a clean part of the cloth.

Removing mud:

- Carefully remove as much mud as possible with a blunt knife or a spatula.
- Allow the mud to dry and then remove it with a vacuum cleaner.
- For stubborn stains, moisten a cloth with commercial water-based cleaning agent. (Alternatively, mix 2 tablespoons of ammonia solution with 1 litre of water.)
- Gently dab the stain with the cloth.
- Turn the cloth frequently so that the stain only comes into contact with a clean part of the cloth.

Removing pencil:

- Moisten cloth with a mild, water-free and pure fabric cleaning agent.
- Gently dab the stain with the cloth.
- Turn the cloth frequently so that the stain only comes into contact with a clean part of the cloth.

Removing vomit:

- Carefully remove vomit.
- Wash cushion with cold water.
- Moisten a cloth with commercial water-based cleaning agent. (Alternatively, mix 2 tablespoons of ammoniac with 1 litre of water.)
- Gently dab the stain with the cloth.
- Turn the cloth frequently so that the stain only comes into contact with a clean part of the cloth.



11.8 Water system

11.8.1 Cleaning the water tank



Fig. 219 Cleaning opening (water tank)

- Empty the water tank and close the drainage opening.
- Remove the cap (Fig. 219) of the water tank.
- Fill water tank with water and some washing-up liquid (do not use any scourers).
- Using a trade standard brush for washing dishes, scrub the water tank until there is no longer any visible deposit.
- Scrub also the pump housing.
- If possible, clean fresh water sensors through the cleaning openings by hand.
- Rinse water tank with copious amounts of drinking water.



> If, due to the design of the water tank, it is not possible to clean the water tank mechanically: Use a suitable chemical cleaning agent.

The authorised dealers would be happy to assist you in choosing a suitable cleaning agent.

Follow the cleaning agent manufacturer's instructions.

11.8.2 Cleaning the water pipes



- > Only use approved cleaning agents as sold by the specialist trade.



- Collect any emerging mixture of water and cleaning agent for correct disposal.
- Empty the water system.
- Close all drainage openings and drain cocks.
- Fill mixture of water and cleaning agent into the water tank.

 Observe the manufacturer's instructions regarding the mixing ratio.
- Open the drain cocks one by one.
- Leave the drain cocks open until the mixture of water and cleaning agent has reached the respective drain.



- Close the drain cocks.
- Set all the water taps to Hot and open them.
- Leave the water taps open until the mixture of water and cleaning agent has reached the drain.
- Set all water taps to Cold and open them.
- Leave the water taps open until the mixture of water and cleaning agent has reached the drain.
- Close all water taps.
- Flush the toilet several times.
- Allow the cleaning agent to act in accordance with the manufacturer's instructions.
- Empty the water system. Collect the mixture of water and cleaning agent for correct disposal.
- For rinsing fill the entire water system with drinking water and empty again several times over.

11.8.3 Disinfecting the water system



- Only use approved disinfectants as sold by the specialist trade. Observe the tolerance of humans and animals.
- The disinfectant must meet national regulations and be approved (if required).



Collect any emerging mixture of water and disinfectant for correct disposal.

When disinfecting the water system, proceed the same way as when cleaning the water pipes (see section 11.8.2). Simply use disinfectant instead of cleaning agent.

11.8.4 Cleaning the waste water tank

Clean the waste water tank after every use.



Fig. 220 Cleaning opening (waste water tank)

Cleaning:

- Empty the waste water tank.
- Open the cleaning opening (Fig. 220) on the waste water tank and the drain cock.



- Thoroughly rinse out the waste water tank with fresh water.
- If possible, clean waste water sensors through the cleaning opening by hand.

Access for cleaning, see section 10.7.

11.9 Skylight with fan



▶ Do not switch on the fan without a fly screen. Do not put your hands or fingers into the fan while it is running. Switch off the power supply before cleaning work.

Cleaning the skylight:

- Clean all plastic parts with a damp cloth.
- Use a mild cleaning agent if necessary.
- If necessary, unscrew the screws on the fly screen and remove the fly screen.
- Clean the fly screen with a vacuum cleaner or a brush.

11.10 Care for vehicle operation in winter

De-icing salt damages the underbody and the parts open to water spray. We recommend that you wash the vehicle more frequently during wintertime. Mechanical and surface treated parts and the underside are under particular strain, and should therefore be cleaned thoroughly.



- ▷ If there is any risk of frost, always run heater at a minimum of 15 °C. Switch the circulation fan (if there is one) to automatic. In the case of extreme external temperatures, the furniture flaps and doors should be left slightly open. The inflowing warm air can help prevent the freezing of water pipes, for example, and counteract the formation of condensation in the storage spaces.
- ▷ If there is a risk of frost, additionally cover the windows on the outside of the vehicle overnight with winter insulation mats.



11.11 Lay-up

11.11.1 Temporary lay-up



- ► Take into consideration that water is undrinkable after only a short
- ▶ Animal damage to cables can lead to short circuits. Fire hazard!

Animals (especially mice) can cause great damage to the interior of the vehicle. This is especially true if the animal remains undisturbed in a parked vehicle.

To keep damages from animals to a minimum or to avoid them altogether, regularly check the vehicle for damage or animal traces.

If animal traces are found, contact the authorised dealer or service centre. If damage to cables has occurred, they can result in short circuits. The vehicle could catch fire.

11.11.2 Recommendation for long periods of inactivity of motorhomes (Mercedes-Benz)

Take into account the instructions and information in the supplied document "Recommendation for longer standing times of motorhomes" from Mercedes-Benz.

11.11.3 General/over winter lay-up

If the vehicle is to be put out of operation for a longer period of time (e.g. at the end of the travel season), some measures must be taken so that a smooth start is possible when the vehicle is put back into operation.

The focus is not only on the base vehicle or chassis, but also on the entire living area with all the components installed in it (water system, gas system, electrical system, furniture, cushions).



- On vehicles with a battery capacity indicator, the data are reset when the main switch on the transformer/rectifier is switched off. Therefore, when putting the system back into operation, a complete charging cycle must be carried out in order to calibrate the system. In addition, the date and time must be reset. If a Duomatic L Plus gas pressure control system is installed in the vehicle (optional equipment), the defroster function must be reprogrammed from "Automatic" to "Off".
- At temperatures below -11 °C AdBlue® freezes. The pump and the lines for Ad-Blue® injection can be damaged. Refer to the manufacturer's documentation for information on Ad-Blue®. Do not expose the vehicle put out of operation to temperatures below -10 °C to avoid freezing of Ad-Blue®.





- ➤ To enable gear selection in the gearbox even if the starter battery is defective, the vehicle is equipped with an "emergency P battery". This emergency P battery is only charged when the vehicle engine is running. Charging via an external charger is not possible. Therefore, the emergency P battery must be disconnected from the power supply during a lay-up (see checklists).
- > Follow the instructions for putting the water filter out of operation seasonally in the manufacturer's separate instruction manual.

Carry out the following measures prior to a lay-up:

Base vehicle

General lay-up measures	Done
Completely fill fuel tank. This can prevent corrosion damage to the inner wall of the fuel tank	
Increase tyre air pressure by 0.5 bar to prevent damage when stationary	
Take the weight off the wheels or move the vehicle every 3 to 4 weeks. In the case of parking sites with natural soil, place suitable wooden or plastic plates underneath the wheels if necessary	
Protect the tyres from direct exposure to the sun. Danger of formation of cracks!	
Check the tyres. Do not continue to use worn tyres or tyres that are more than 6 years old	
Ensure good ventilation at the parking site. Sufficient air circulation is especially important for the underbody. Moisture or lack of oxygen can lead to impairments	
Treat rubber seals with a conventional rubber care product	
Observe the instructions in the instruction manual of the base vehicle	

Additional measures for winter lay-up	Done
For diesel vehicles, fill the fuel tank with winter diesel	
Clean body and underbody thoroughly and spray with hot wax or protect with varnish	
Rectify damage to the paintwork	
Check the radiator frost protection and top up if necessary	
Check the frost protection of the windscreen washer system and top up if necessary	

Body (outside)

General lay-up measures	Done
All vents should be sealed with the appropriate caps and all other openings (apart from forced ventilations) should also be sealed. This prevents animals (e.g. mice) from gaining entry	
To prevent the formation of condensation and subsequently mould: Ventilate the interior, all storage space accessible from the outside and the parking site (e.g. garage) every 3 weeks	



Additional measures for winter lay-up		Done
	Keep the forced ventilation open. Arrange the covers in such a way that the ventilation openings are not covered, or use porous tarpaulins	
Clean veh	icle from outside thoroughly	
Clean and grease installed supports		
Clean and grease all door and flap hinges		
Brush oil or glycerine on all locking mechanisms		
Use graphite dust to treat locking cylinders		
Treat all rubber seals with a conventional rubber care product		
Use refrig	erator winter covers	

Body (inside)

General lay-up measures	Done
Place upholstery in an upright position for ventilation, and cover	
Clean refrigerator (and freezer compartment) and move doors to ventilation position (see section 9.5.3)	
Disconnect the flat screen from the mains	
Open the roller blinds and thereby relieve the springs	

Additional measures for winter lay-up	Done
Set up the de-humidifier (granulate)	
Store cushions and mattresses in a dry place	
Empty all cabinets and storage compartments, open flaps, doors and drawers	
Thoroughly clean the interior	
Air the interior every 3 weeks	
If there is a risk of frost, do not leave the flat screen in the vehicle	

Gas system

General lay-up measures	Done
Close the regulator tap on the gas bottle	
Close all gas isolator taps	
Always remove gas bottles from the gas bottle compartment, even if they are empty.	



Water system

General lay-up measures	
Never operate water pump without water.	
Empty the fresh water system. Blow out residual water from the pipes (max. 0.5 bar)	
Clean the fresh water system using suitable cleaning agents from a specialised store. Open all drain cocks and water taps to empty (see section 11.8.2)	
Leave the water taps on in central position. Leave all drain cocks open.	
Clean the waste water tank (do not forget the probe) and empty it (see section 11.8.4), leave the drain cock open	

Additional measures for winter lay-up	Done
If possible, empty siphons at the sink and wash basin to prevent freezing	

Electrical system

The electrical system of a motorhome consists of two separate supply circuits:

- Starter battery, starter motor and alternator (generator)
- Living area battery, transformer/rectifier (EBL) and operating panel

General lay-up measures	Done
Clean the battery terminals of the starter battery	
If necessary, top up the battery water of the starter battery	
Fully charge starter battery via external charger	
Activate vehicle hibernation (see section 11.11.4)	
Observe the instructions regarding the starter battery in the instruction manual of the base vehicle	
Fully charge the living area battery via the on-board charger (the charging time depends on the equipment). Charge the battery at temperatures above 0 °C so that the battery can also absorb capacity	
Remove the fuse from the water pump on the transformer/rectifier	
Remove the fuses 31 and 32 for the emergency P battery	
Disconnect the living area battery from the 12 V power supply. In order to do this, switch off the transformer/rectifier at the main switch	
Check the voltage of the batteries periodically during the lay-up period. If the battery voltage drops below 12.5 V: recharge the battery	

Additional measures for winter lay-up	Done
Remove the starter battery and the living area battery and store them in a place protected from frost or connect the vehicle to a 230 V supply. Prior to the removal, remove the fuses on the living area battery	



11.11.4 Activating the vehicle's hibernation mode



► Comfort functions drain current from the starter battery even when the vehicle is stationary and the transformer/rectifier has been switched off. This may cause starting problems after longer periods of inactivity.

If the vehicle has been set to hibernation mode, the power consumption is reduced to a minimum. This protects the starter battery. Thereby, the vehicle can be easily started after longer periods of inactivity.

Activating the hibernation mode:

Depending on the equipment, activate the hibernation mode on the MBUX display or on the electronic instrument cluster via the steering wheel buttons. The operation is described in the operating manual of the base vehicle.

Cancelling the hibernation mode:

Switch on ignition. The hibernation mode ends when switching the ignition on, and must be activated again if necessary.

11.11.5 Starting up the vehicle after a temporary lay-up or after layup over winter



On vehicles with a battery capacity indicator, the data are reset when the main switch on the transformer/rectifier is switched off. Therefore, when putting the system back into operation, a complete charging cycle must be carried out in order to calibrate the system. In addition, the date and time must be reset.

If a Duomatic L Plus gas pressure control system is installed in the vehicle (optional equipment), the defroster function must be reprogrammed from "Automatic" to "Off".



- Dobserve the instructions for putting the water filter into operation again in the manufacturer's separate instruction manual.
- On vehicles with SCU (System Control Unit), the 12 V system starts automatically. Manual activation is not necessary.



Go through the following checklist before start-up:

Base vehicle

Activity	Done
If the vehicle has been stationary for a longer period (approx. 10 months) have the braking system checked by an authorised specialist workshop	
Check tyre pressure of spare wheel, if present	
Check the tyre pressure on all tyres	

Body

Clean the pivot bearing of the entrance step	
Check the functioning of the fitted supports	
Check that the doors, windows and skylights are working properly	
Check the function of all external locks, e.g. the storage flaps, the filler necks and the living area door	
Search for traces of animals that have gained entry	
Remove the cover from the waste gas vent of the heater (if there is one)	
Remove the winter cover from the refrigerator grills (if there is one)	

Gas system

If the vehicle has been stationary for a longer period (approx.

10 months) have the gas system checked by an authorised specialist workshop

Put the gas bottles in the gas bottle compartment, tie down and connect to the gas pressure regulator

Electrical system

Connect to 230 V external power supply

Install the living area battery and starter battery, insert the fuses on the living area battery and fully charge the battery

Charge the battery for at least 20 hours after lay-up.

Connect the living area battery with the 12 V power supply. To do this, switch on the battery cut-off switch on the transformer/rectifier (see chapter 8)

Insert the fuses 31 and 32 for the emergency P battery into the corresponding slots

Check that the electrical system are working, e.g. interior light, socket and all installed electrical appliances

Water system

Disinfect water pipes and water tank

Check the functionality of the operating lever for the waste water tank

Close all drain cocks and water taps

Check water system for leaks

Appliances

Check the function of the appliances



11.12 Setting up the vehicle

The vehicle's extensive comfort equipment results in increased closed-circuit current consumption. If the vehicle is to be parked for a longer period of time, the following measures must therefore be taken.

Option 1: Connect the vehicle to an external 230 V power supply.

Option 2: Take the vehicle out of operation electrically as follows:

- Switch off the transformer/rectifier.
- Pull out the 50 A fuse.
- Pull out the 2 A fuse sensor line (next to the living area battery).



- If the above measures have been taken, the functions of the Hymer Connect system are no longer available.
- Depending on the vehicle equipment, the aforementioned measures must already be taken from a parking period of a few days.

To put the vehicle back into operation, reinsert the fuses that have been pulled out into the slots provided.



Chapter overview

This chapter contains instructions about official inspections and inspection and maintenance work in the vehicle.

At the end of the chapter you will find important instructions on how to obtain spare parts and on our dealers and service centres.

12.1 Service and sales partners

The authorised service and sales partners are the contacts when spare parts are needed or/and repairs are required.

You will find the addresses and telephone numbers of the authorised service and sales partners at:

Hymer: on the Internet at https://www.hymer.com/de/en/service/dealer-search

Mercedes: on the Internet at https://www.mercedes-benz.de/vans/de/contentpool/apps/dealer-locator



- Before starting your journey, check what options are available to you in the event of a breakdown.
- Observe that the manufacturer's service and mobility commitments are not valid at all destinations.
- In the case of travelling to countries without a service partner, you travel at your own risk.

12.2 Official inspections

Depending on the national legislative provisions, the following official inspections must be carried out periodically:

- Main inspection
- **Emissions test**
- Inspection of the gas system

The inspection intervals in accordance with the national legislative provisions must be adhered to. The inspection stickers attached to the vehicle indicate when the next inspection is required.

For Germany, for example, the following regulation applies:

From April 1st 2022, the inspection obligation for the gas system as part of the main inspection (HU) will no longer apply. Instead, an independent gas inspection (according to DVGW (German Technical and Scientific Association for Gas and Water) worksheet G 607) must be carried out for recreational vehicles (motorhomes and caravans). The gas inspection is evidenced by the correctly completed yellow inspection book and a valid inspection sticker on the vehicle.



For more information on the gas inspection and the intervals at which it must be carried out, see the following websites:

- German Federal Ministry of Digital Affairs and Transport (BMDV): www.bmvi.de
- German Technical and Scientific Association for Gas and Water (DVGW): www.dvgw.de
- German Association for Liquefied Gas (DVFG): www.dvfg.de

As long as the intervals at which the gas inspection must be carried out are not regulated by law, the DVGW recommends an inspection every two years.

Many camping site operators demand proof of a valid gas inspection when allocating a parking place.



- Any changes on the gas system must be carried out by a certified expert for gas systems.
- ▷ Even in the case of vehicles that are not registered, an inspection of the gas system is required.

12.3 Inspection work

Like any technical appliance, the vehicle must be inspected at regular intervals.

This inspection work must be carried out by qualified personnel.

Special technical knowledge, which cannot be taught within the framework of this instruction manual, is required for these tasks. Personnel possessing this technical knowledge are available for assistance at all service centres. Their experience and regular technical training by the factory as well as the equipment and tools used guarantee expert and up-to-date inspection of the vehicle.

The service centre in charge will confirm the work performed.

Have chassis inspections confirmed in the chassis manufacturer's customer service booklet.



- Observe the inspections indicated by the manufacturer and have them carried out at the specified intervals. The value of the vehicle is thus preserved.
- The confirmation of the inspection work carried out serves as valid proof in the event of damage and guarantee claims.

12.4 Maintenance work

As with every machine, this vehicle requires maintenance. The extent and frequency of the maintenance work required depend on conditions of operation and use. More difficult operating conditions make it necessary to service the vehicle more often.

Have the base vehicle and the appliances serviced at the intervals specified in the corresponding instruction manuals.



12.5 Lubricating the rear axle




- ▷ In addition to the regulations and notes in the operator manual of the basic vehicle as well as in the maintenance manual, the rear axles must be relubricated after 20,000 km, or at least every 12 months. In order to do this, visit an authorised dealer / service partner.
- Keep proof of carrying out the work.
 Instructions for the service partner, see chapter 17.

12.6 Changing the filter pad of the gas filter



 Fire hazard! Do not smoke while opening the gas filter. Do not open the gas filter near open fire.
 Only open the gas filter in depressurised condition.



1 Gas filter

Fig. 221 Gas filter

The filter pad must be changed with every change of gas bottles. Only use original Truma filter pads.

Changing the filter pads of the gas filter (Fig. 221,1) is described in the manufacturer's instruction manual.



- > The filter pads can be obtained from the authorised dealer.
- Further information can be obtained in the manufacturer's instruction manual.



12.7 Alde hot-water heater



- Check the level of the heating fluid regularly on the compensator reservoir.
- During or after the first operating hours of the hot-water heater, the filling level may fall below the minimum mark. If this is the case, top up the heating fluid.
- We recommend to bleed the heating system after the initial heater operation and to check the glycol content.
- Only top up heating system with a standard G12 EVO water-glycol mixture (60 : 40). This mixture offers frost protection up to approx. -25 °C. When topping up hot-water heaters that are connected to the engine's cooling circuit, please observe the instructions in the manufacturers' instruction manuals.



- Further information can be obtained in the manufacturer's instruction manual.
- Standard G12 EVO is miscible with standard G13 and can be used to top up the heating system operated with standard G13.

12.7.1 Changing the heating fluid

Have the heating fluid changed every five years by an authorised dealer.

12.7.2 Checking the fluid level



The openings at the front and rear of the compensator reservoir are used for installation. However, the compensator reservoir is sealed and liquid cannot escape.



Fig. 222 Compensator reservoir (hot-water heater)




Fig. 223 Marking "MIN/MAX"

- Switch off the hot-water heater and allow it to cool down.
- Remove the cover for the compensator reservoir in the right-hand upper part of the shower.
- Check if the fluid level is between the markings "MIN" and "MAX" (Fig. 223) on the compensator reservoir.



12.7.3 Topping up heating fluid

- Position the vehicle horizontally. This prevents the formation of bubbles.
- Switch off the hot-water heater and allow it to cool down.
- Unscrew or pull off the panel.
- Open the rotary lid on the compensator reservoir.
- Remove cover.
- Check anti-freeze with an anti-freeze hydrometer. The frost protection content must be 40 % or provide frost protection of up to -25 °C.
- Fill water-frost protection mixture (standard G12 EVO) slowly into the compensator reservoir.



The optimum fluid level is reached when the fluid in the compensator reservoir is 1 cm above the "MIN" mark when it is cooled down.

12.7.4 Bleeding the heating system

The bleeding valves of the hot-water heater are installed at the following points in the vehicle:

- Revision lid on the dashboard
- Seating group underneath the window
- Kitchen (behind drawers)
- With the booster in the electrical installation compartment
- With the booster in the staircase in the bed ascent
- Right and left at the head end of the rear bed
- Behind the small bench seat at the conversion door (only in some ground plans)

To gain access to the bleeding valves, it might be necessary to remove the associated ventilation grill above the convector. Sometimes the access is possible through panels (e.g. in the back cushion ventilation). Bleeding must be done on all bleeding valves.




Fig. 224 Bleeding valves (hot-water heater)

- 1 Bleeding valve on hose extension
- 2 Valve opening
- 3 Bleeding valve on pipeline
- 4 Valve opening

Bleeding:

- Switch off the hot-water heater and allow it to cool down.
- Open the bleeding valve (Fig. 224,1 or 3) and keep it open until no more air comes out of the valve opening (Fig. 224,2 or 4).



Depending on the position, one of two bleeding valve types will be installed.



12.8 Cooker/oven/refrigerator

The manufacturer recommends a yearly inspection service in a authorised specialist workshop to maintain the appliances' efficiency. After service and maintenance work, the appliance must be checked for electrical safety as well as for gas safety.

12.8.1 Refrigerator

The gas burner must be cleaned of dirt when required but at least once a year. When using LPG (tank or refillable bottles), the maintenance must be carried out half yearly, or quarterly.

Keep the records of maintenance work carried out on the refrigerator.

12.9 Changing windscreen blade



- Only fill the cleaning agents (with/without frost protection) into the washer fluid container which are listed in the operating manual of the base vehicle manufacturer and in the mixing ratio specified therein. Do not use any radiator frost protection or other products. These products affect the cleaning effect and attack the windscreen blades.



> The windscreen blades are changed in the same way as on a car.




Fig. 225 Changing windscreen blade

- 1 Windscreen blade
- 2 Wiper nozzle
- 3 Wiper arm

- Remove the ignition key to prevent an involuntary activation of the windscreen wipers.
- Lift the wiper arm (Fig. 225,3) off the windscreen and fold out as far as it will go.
- Push the synthetic clamping element on the windscreen blade (Fig. 225,1) out of the bent holder on the wiper arm (arrow).

244





- A small amount of resistance will be felt. If necessary, compress the synthetic clamping element slightly.
- Install the new windscreen blade in the reverse order. Push the synthetic clamping element into the bent holder of the wiper arm until it locks into place.
- Clean the wiper nozzles (Fig. 225,2).

12.10 Replacing bulbs, external



- ➤ Xenon spotlights are under high voltage. Touching the Xenon lamp contacts can lead to serious or fatal injuries due to electric shock. Do not remove the housing cover of the Xenon spotlight.
- ► Have the bulbs of the Xenon spotlights changed at a qualified specialist workshop. These workshops have the necessary knowledge and the required tools. HYMER GmbH & Co. KG recommends the HYMER service centres.
- ▶ Bulbs and lamp holders can be extremely hot. Therefore, allow lamps to cool down before changing bulbs.
- ▶ Store bulbs in a safe place inaccessible to children.
- ▶ Do not use any bulb that has been dropped or which shows scratches in its glass. The bulb might burst.



- Do not touch a new bulb with bare fingers. Use a cloth when installing the new bulb.
- Use only bulbs of the same type and with the correct wattage (see section 12.10.4).
- ▷ If LEDs in lamps are defective, contact an authorised dealer or service centre.



Types of bulbs

Different types are used in the vehicle. Below, we have described how to change the different types of bulbs.




Fig. 226 Types of bulbs

Pos. in Fig. 226	Fixture type/bulb type	Changing
1 Plug-in fixture		To remove, pull out the bulb
		To mount, push the bulb into the socket with gentle pressure
,	To remove, press the bulb down and turn in an anticlockwise direction	
		To insert, place the bulb in the socket and turn in a clockwise direction
3	Cylindrical bulbs	To remove and to insert, carefully bend the contacts of the lamp holder outwards
4	Halogen bulb	To remove, release the retaining spring / release the bayonet fitting
		After inserting, reattach the retaining spring /insert the halogen bulb into the bayonet fitting

12.10.1 Front lights



- > The daytime running light burns when the ignition is switched on.
- When the daytime running light burns, the side marker lights do not burn.
- When the low beam is turned on, the daytime running light goes off.
- ▷ In extreme weather conditions or if the temperature fluctuates strongly, a light condensation film can form on the inside of the clear glass spotlight. The spotlight is designed so that this film evaporates when the spotlight is switched on or during driving. There is no risk of reduced lighting intensity or damage to the spotlight by condensation.





Fig. 227 Front lights

- Front headlight
- Curve light/fog light

Front headlight

Daytime running light and direction indicators are integrated in the front headlight (Fig. 227,1). The bulbs for low beam and main beam are changed from the engine compartment.




Fig. 228 Front headlight

- LED lamps (daytime running light, direction indicators)
- Low beam/main beam

Housing cover

Daytime running light and direction indicator

Daytime running light and direction indicators are LED lamps (Fig. 228,1). To change the LEDs, contact an authorised dealer or a service centre.

Low beam/main beam (Fig. 228,2)





Fig. 229 Front headlight (rear side)

- Switch ignition and lighting off.
- Open the bonnet (see chapter 4).
- Turn the housing cover (Fig. 229,1) in an anticlockwise direction and remove.





1 Holder

Fig. 230 Bulb (low beam/main beam)

- Turn the holder (Fig. 230,1) with the lamp in an anticlockwise direction and take it out of the lamp housing.
- Pull the bulb out of the holder.
- Insert the new bulb (H7 12 V/55 W) into the holder such that the socket plate fits into the recess of the holder.
- Insert the holder (Fig. 230,1) with bulb into the lamp housing and tighten in a clockwise direction. The holder engages audibly.
- Place the housing cover (Fig. 229,1) and tighten in a clockwise direction.
- Close the bonnet.

Curve light/ fog light (Fig. 227,2)



Fig. 231 Curve light/fog light




Fig. 232 Curve light/fog light (from below)

1 Holder

- Reach behind the combined headlight for curve light/fog light (Fig. 231), turn holder (Fig. 232,1) with the bulb in an anticlockwise direction and take it out of the headlight housing.
- Pull the bulb out of the holder.



- Insert the new bulb (H7, 12 V/55 W) into the holder such that the socket plate fits into the recess of the holder. While doing this, do not touch the bulb with bare fingers.
- Insert the holder (Fig. 232,1) with the bulb from behind into the headlight housing and turn in a clockwise direction. The holder engages audibly.

12.10.2 **Rear lights**



To change the lamps equipped with LEDs, contact an authorised dealer or a service centre.





Fig. 233 Rear lights unit

Hexagon socket screw

- Loosen the hexagon socket screws (Fig. 233,1).
- Remove rear lights unit.



Direction indicator

- 2 Reverse light
- Fog tail light


Fig. 234 Rear lights unit (removed)

- Turn defective bulb (Fig. 234) in an anticlockwise direction to unlock the bayonet socket.
- Change the faulty bulb.



Licence plate light

The licence plate light is the same for all models.



1 Housing screw

Fig. 235 Rear lights (licence plate light)

- Loosen the two housing screws (Fig. 235,1).
- Remove the housing.
- Change the faulty bulb.

Third brake light

The brake light has LEDs.

To change the LEDs, contact an authorised dealer or a service centre.

12.10.3 Side lights



Fig. 236 Side lights

- 1 Awning light
- 2 Side marker light
- 3 Direction indicator
- 4 Marker light

Side marker light

- Use a suitable tool (e.g. a screwdriver) to lever out the cover.
 Apply the tool to the notch in the housing.
- Remove the housing.
- Change the bulb.

Direction indicator

The lamp is glued in. If the bulb is faulty, contact an authorised dealer or service centre.

Marker light

The lights have LEDs. To change the lamps, contact an authorised dealer or a service centre.

Awning light

The lamp is equipped with LEDs. To change the lamp, contact an authorised dealer or a service centre.

250



12.10.4 Types of bulbs for exterior lighting

Front

No. in Fig. 227	Exterior lighting	Type of bulb
1	Low beam/main beam	H7 12 V 55 W
2	Curve light/fog light	H7 12 V 55 W

Rear

No. in Fig. 234	Exterior lighting	Type of bulb
1	Direction indicator	P 12 V 21 W
2	Reverse light	P 12 V 21 W
3	Fog tail light	P 12 V 21 W
-	Brake light	Contact a dealer or service centre
-	Rear light	Contact a dealer or service centre
-	Licence plate light	Contact a dealer or service centre
-	Third brake light	Contact a dealer or service centre

Side

No. in Fig. 236	Exterior lighting	Type of bulb
1	Awning light	Contact a dealer or service centre
2	Side marker light	C 12 V 5 W
3	Direction indicator	Contact a dealer or service centre
4	Marker light	Contact a dealer or service centre

Lighting for living area 12.11



Do not replace the LEDs in lamps with standard light bulbs. Risk of fire due to intense heat build up.

All of the lights in the living area are equipped with LED technology. LED lights are economical, low-maintenance and have a very long life. It is not normally necessary to replace a light.



If LEDs in lamps are defective, contact an authorised dealer or service centre.

12.12 Air suspension



Do not clean air suspension components with steam cleaner or highpressure cleaner. Do not use any organic solvents or scouring agents. Approved cleaning agents are mild soap, methanol, ethanol and isopropyl alcohol.

Inspect the air suspension bellows periodically for damage and leaks.

When not in use for an extended period, the vehicle level may gradually become lower. To prevent permanent deformation and damage to the bellows: Support the vehicle with steady legs or fill the air suspension bellows with compressed air once weekly.

12.13 Electrical ventilation system

If the aspired air is led into the open via an outlet in the door or in the floor, change the inserted active carbon filter once a year. If the air is led into the open via the roof, the ventilation system is maintenance-free.



Further information can be obtained in the manufacturer's instruction manual.

12.14 Spare parts



- Every alteration of the original condition of the vehicle can alter road behaviour and jeopardize road safety.
- ▶ The optional equipment and original spare parts recommended by HYMER GmbH & Co. KG have been specially developed and supplied for your vehicle. These products are available at the authorised dealer or service centre. The authorised dealer or service centre is informed about admissible technical details and carries out the required work correctly.
- ► The use of accessories, parts and fittings not supplied by HYMER GmbH & Co. KG may cause damage to the vehicle and jeopardize road safety. Even if an expert's report, a general type approval or a design certification exists, there is no guarantee for the proper quality of the product.
- No liability can be assumed for damage caused by products which have not been released by HYMER GmbH & Co. KG. This also applies to impermissible alterations to the vehicle.

For safety reasons, spare parts for pieces of equipment must correspond with manufacturer's instructions and be permitted by the manufacturer as a spare part. These spare parts may only be fitted by the manufacturer or an authorised specialist workshop. The authorised dealers and service centres are available for any spare parts requirement.

Here are some examples of important spare parts:

- Fuses
- Bulbs
- Water pump (submerged pump)

When ordering spare parts, please indicate the serial number and the vehicle type to the authorised dealer or service centre.



The vehicle described in this instruction manual is built and equipped to factory standards. Optional equipment is offered depending on its purpose or use. When fitting optional equipment check if such equipment has to be entered in the vehicle documents. Observe the technically permissible maximum laden mass. The authorised dealer or service centre will be happy to advise you.

12.15 Vehicle identification plate




Fig. 237 Vehicle identification plate

- Vehicle type
- 2 Consecutive serial number
- 3 Manufacturer
- 4 Vehicle type approval
- 5 Body stage
- 6 Chassis number
- 7 Technically permissible maximum laden mass
- 8 Permissible total towing mass (with caravan coupling option)
- 9 Technically permissible maximum laden mass on axle 1
- 10 Technically permissible maximum laden mass on axle 2

The vehicle identification plate with the serial number is attached to the right-hand wall in the rear bottom area.

Do not remove the vehicle identification plate. The vehicle identification plate:

- identifies the vehicle
- helps with the procurement of spare parts
- together with the vehicle documents identifies the vehicle owner



➢ Always include the **serial number** with all inquiries for the customer service office.



12.16 Vehicle identification plate on the chassis



Fig. 238 Vehicle identification plate on the chassis

- 1 EC type-approval number
- 2 Indication of level
- 3 Base vehicle identification number (17 digits)
- 4 Technically permissible maximum laden mass of the vehicle
- 5 Technically permissible maximum laden mass of the vehicle with trailer
- 6 Permissible front axle load
- 7 Permissible rear axle load axle (axle 2)
- 8 Permissible rear axle load axle (axle 3)
- 9 Serial number
- 10 Type designation

The vehicle identification plate is attached to the seat console of the driver's seat, on the side pointing toward the driver's entrance.

Do not remove the vehicle identification plate.

For any inquiries from the customer service hold the information on the vehicle identification plate ready.

12.17 Warning and information stickers

There are warning and information stickers on and inside the vehicle. Warning and information stickers are for the sake of safety and must not be removed.



Replacement stickers can be obtained from an authorised dealer or a service centre.

12.18 Replacement keys

To order replacement keys make a note of the following:

Locks for:	To order keys you need:	Obtainable at:	Telephone information:
Mercedes-Benz base vehicle	Chassis number	Mercedes-Benz authorised work- shop	_
Body	Serial number, chassis number, second key or key number	Dealers	-



Chapter overview

This chapter contains instructions regarding the tyres of the vehicle.

At the end of the chapter there is a table you can use to find the correct tyre pressure for your vehicle.

13.1 General



► Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle (see section 13.8).



- > Check the tyre pressure on cold tyres. Do not reduce the higher tyre pressure when the tyres are warm.
- ➤ Tubeless tyres have been installed on the vehicle. Never install tubes in these tyres.
- > Read the instruction manual for the base vehicle.
- ➤ The maximum depth of a body of water that a vehicle can pass through without being damaged is called the "wading depth". The maximum wading depth is determined by the lower edge of the bumper, but is a maximum of 40 cm. This applies to all loading conditions.

Never cross deeper bodies of water. Water and dirt can damage the vehicle

The driver must make sure that no equipment can be damaged before driving through bodies of water or mud and before driving over raised obstacles.

For further details, refer to the Mercedes Benz instruction manual.



- Depending on the model, the vehicle may only be equipped with a tyre repair kit as standard.
- In the case of a puncture, pull the vehicle over to the side of the road. Make vehicle safe with a hazard warning triangle. Switch on the warning lights.
- ➤ Tyres must not be older than 6 years as the material will become brittle over time. The four-digit DOT number on the tyre flank indicates the date of manufacture. The first two digits designate the week, the last two digits the year of manufacture.

Example: 0723 Week 07, year of manufacture 2023

Observe:

- Check the tyres regularly (every 2 weeks) for equal tread wear, tread depth and external damage.
- Replace tyres at the latest, when the minimum depth of tread stipulated by law is reached.
- Always use tyres of the same model on one axle.
- Observe the instructions in the vehicle documents.
- Only use tyres approved for the wheel rim type fitted. The permitted rim and tyre sizes are quoted in the vehicle documents and the authorised dealer or service centre will always be glad to give you advice.



- Run-in new tyres for approx. 100 km (60 miles) at low speed since only then do they reach full strength.
- Check regularly that the wheel nuts or wheel bolts are firmly seated.
- For lay-ups or long periods of inactivity, keep the tyres and tyre bearings free from pressure points: Jack up the vehicle so that the wheels do not bear any load, or move the vehicle every 4 weeks in such a way that the position of the wheels is changed.

13.2 Tyre selection



A wrong tyre can damage the tyres during the journey and even cause it to burst.



If tyres that are not approved for the vehicle are used, then the type approval for the vehicle and subsequently the insurance coverage can lapse. The authorised dealer or service centre will be happy to advise you.

The tyre sizes approved for the vehicle are given in the vehicle documents or can be obtained from the authorised dealers or service centres. Each tyre must fit the vehicle on which it will be driven. This applies to the external dimensions (diameter, width), which are indicated with the standardised size designations. In addition, the tyres must meet the requirements of the vehicle with regard to weight and speed.

The weight is based on the technically permissible maximum laden mass on the axle, which is distributed between two tyres. The maximum load-carrying capacity of a tyre is indicated by its load index (= LI, load index code).

The maximum permissible speed for a tyre (with full load-carrying capacity) is indicated by the speed index (= SI). Together, load index and speed index form the operating code of a tyre. This is an official component of the complete, standardised dimensions description which appears on every tyre. The information on the tyres must correspond to the specifications which appear in the vehicle papers.

13.3 Tyre specifications

215/70 R 15C 109/107 Q (example)

Description	Explanation	
215	Tyre width in mm	
70	Height-to-width proportion in percent	
R	Tyre design (R = radial)	
15	Rim diameter in inches	
С	Commercial (transporter)	
109	Load index code for single tyres	
107	Load index code for twin tyres	
Q	Speed index (Q = 160 km/h)	



13.4 Handling of tyres

- Drive over kerbs at an obtuse angle. Otherwise the flanks of the tyres may get pinched. Driving over a kerb at a sharp angle can damage the tyre and result in it getting ruptured.
- Drive over high manhole covers at a slow speed. Otherwise the tyres may get pinched. Driving over a high manhole cover at high speed can damage the tyre and result in it getting ruptured.
- Check the shock absorbers regularly. Driving with poor shock absorbers significantly increases wear.
- In the event of an uneven thread wear, contact customer service.
- Do not clean the tyres with a high-pressure cleaner. The tyres can suffer serious damage within just a few seconds and rupture as a result.

Wing nut Pad

13.5 Spare wheel

The spare wheel is stowed away in the rear storage space.




Fig. 239 Spare wheel in the rear storage space

Removing the spare wheel:

- Loosen the wing nut (Fig. 239,1) by hand and unscrew it.
- Remove the pad (Fig. 239,2).
- Remove the spare wheel.

13.6 Repair kit



▶ Observe the safety instructions in the manufacturer's instruction manual.

Depending on the equipment, the vehicle will be equipped with the TyreKit breakdown kit.

Take further information from the manufacturer's instruction manual.



13.7 Changing wheels

13.7.1 General instructions



- ▶ The vehicle must be on level, firm ground, secure from slipping.
- ▶ Go into first gear. Shift the automatic transmission to position "P".
- Before jacking up the vehicle firmly apply the handbrake.
- Prevent the vehicle from rolling away by blocking the opposite wheel with the wheel chocks.
- ▶ Under no circumstances jack the vehicle with the fitted supports.
- ▶ If a trailer is connected: Detach the trailer before lifting the vehicle.
- ▶ Position the vehicle jack at the designated mounting points.
- ▶ Never overload the vehicle jack. The maximum permissible load is specified on the vehicle jack's identification plate.
- Use the vehicle jack only for lifting the vehicle briefly while changing the tyre.
- ▶ Do not start the motor while the vehicle is jacked up.
- ► Whilst the vehicle is in a jacked up position, persons must not lie down under it



- Do not damage the thread of the thread bolt or wheel bolt when changing the wheel.
- Tighten the wheel nuts or wheel bolts cross-wise.
- ▷ If you are converting to other rims (e.g. aluminium rims or wheels with winter tyres), use the appropriate wheel bolts with the correct length and spherical shape. Otherwise the wheels may not be securely fixed or the braking system may not work correctly.
- All 4 wheels must be of the same model and size and be approved for the vehicle.
- Wheel rims or tyres that are not approved for the vehicle can jeopardize road safety and they must be separately inspected and approved by an accredited test centre.
- Do not replace wheels cross-wise.



- ▶ Protect the vehicle according to the national regulations, e.g. with a hazard warning triangle.
- ▷ Before changing the wheel, check the wheel rim and tyre size, the max. tyre load and the speed index on the tyres. Only use the wheel rim and tyre sizes stated in the vehicle documents.
- The on-board tool set is adapted to the mounted wheel nuts or wheel bolts. When alloy wheel rims are mounted, carry an appropriate tool for the spare wheel (steel wheel rim) in the vehicle.
- > Further information can be found in the instruction manual of the base vehicle.

The on-board tool set is stored in the footwell of the front passenger under the floor plate.



13.7.2 **Tightening torque**

Wheel rim	Tightening torque
Steel wheel rim	250 Nm ± 20 Nm
Alloy wheel rim	190 Nm ± 20 Nm

13.7.3 Changing a wheel



- The footplate of the vehicle jack must be levelly positioned on the ground.
- Only drive to the nearest workshop with the spare wheel.
- Vehicles with 3 axles (tandem axle at the rear) cannot be lifted with a commercially available vehicle jack. Changing wheels must be carried out in a specialist workshop.




- Use a commercially available vehicle jack.
- If the vehicle is equipped with a spare wheel (special equipment), an adapter for mounting the vehicle jack on the rear axle is included in the scope of delivery.
- The adapter is intended for use with a commercially available vehicle
- The wheel you have replaced should be repaired immediately.
- Take note of the general instructions in this chapter.
- Park the vehicle on as even and stable a surface as possible.
- Go into first gear. In the case of automatic transmission, change gear to "P" position.
- Apply the handbrake.
- Place chocks or other appropriate objects beneath the vehicle to secure it.
- Remove the spare wheel from the spare wheel support.
- If the ground is soft, place a stable support such as a wooden board beneath the vehicle jack.



Fig. 240 Front axle mount

If a wheel on the front axle is to be changed: apply the vehicle jack on the jacking point provided for this purpose (Fig. 240).





1 Pin 2 Adapter

Fig. 241 Adapter for rear axle mount

■ If a wheel on the rear axle is to be changed: attach the adapter (Fig. 241,2) to the vehicle jack.




Fig. 242 Rear axle mount

- Insert the pin (Fig. 241,1) into the mount of the rear axle (Fig. 242).
- Using the wheel brace, turn the wheel bolts several times to loosen them, but do not remove them.
- Lift the vehicle until the wheel has been lifted 2 to 3 cm above the ground.
- Remove the wheel bolts and take off the wheel.
- Place the spare wheel on the wheel hub and adjust.
- Screw in the wheel bolts and slightly tighten them cross-wise.
- Crank down the vehicle jack and remove it.
- Using the wheel brace, tighten the wheel bolts evenly (see section 13.7.2 for tightening torque).

13.7.4 Changing a wheel with alloy wheel rims



▶ Alloy wheel rims and steel wheel rims require different wheel bolts. When alloy wheel rims are mounted, the spare wheel (steel wheel rim) is accompanied by suitable wheel bolts.

Wheels with alloy rims are changed in the same way as wheels with steel rims (see section 13.7.3).



13.8 Tyre pressure



- ► Tyres overheat if the tyre pressure is too low. This can cause serious tyre damage.
- ► Check tyre pressure before a journey or every 2 weeks. Wrong tyre pressure causes excessive wear and can lead to damage or even to tyre burst. You can lose control of the vehicle.
- Use only valves that are approved for the specified tyre pressure.
- ▶ If the tyre pressure exceeds 4.5 bar, the use of a metal or hybrid valve is recommended.



○ Check the tyre pressure on cold tyres. Do not reduce the higher tyre pressure when the tyres are warm.

The payload and the durability of tyres is directly dependent on the tyre pressure. Air is a volatile medium. It is unavoidable that it will escape from tyres.

As a rule of thumb it can be assumed that a filled tyre loses pressure at a rate of 0.1 bar every two months. To prevent the tyres becoming damaged or burst, check the tyre pressure regularly.



- The information on pressure levels is valid for cold tyres and loaded vehicles.
- ▶ Pressure in hot tyres must be 0.3 bar higher than in cold tyres. Recheck the pressure when the tyres are cold.
- The tyre pressure tolerance is +/- 0.05 bar.
- Refer to the vehicle documents or the vehicle identification plate for the maximum permissible axle load.

Air pressure front axle

Tyre size	Tyre manufacturer	Permissible axle load	
		1850 kg	2100 kg
225/75 R16	All	3.5 bar	4.1 bar
235/60 R17	All	3.6 bar	4.2 bar

Air pressure rear axle

Tyre size	Tyre manufacturer	Permissible axle load		d	
		1800 kg*	2100 kg	2430 kg	2500 kg
225/75 R16	All	4.0 bar	4.8 bar	5.5 bar	5.5 bar
235/60 R17	All	4.0 bar	4.8 bar	5.3 bar	-

^{*} For 3-axle vehicle (tandem axle at the rear): rear axle load per rear axle



Permissible axle loads, see the vehicle identification plate.

Depending on the equipment, the vehicle will be equipped with a spare wheel. If different air pressure values are specified for front and rear axle: use the higher of both values for the spare wheel.





Chapter overview

This chapter contains instructions about possible faults in your vehicle.

The faults are listed with their possible causes and corresponding remedies.

The specified faults can be remedied with relative ease and without a great deal of specialised knowledge. In the event that the remedies detailed in this instruction manual should not be successful, an authorised specialist workshop must find and eliminate the cause of the fault.

14.1 **Braking system**



Have defects on the braking system immediately remedied by an authorised specialist workshop.

Air suspension



Have defects on the air suspension immediately remedied by an authorised specialist workshop.

14.3 **Skylight**

If the fan is not working, check the fuse and replace it if necessary. Only insert fuses of the same type (glass fuse 4 A/type "SLO BLO"). For information on position and replacement of the fuse see chapter 8.



If this measure does not rectify the fault, contact customer service.

14.4 **Electrical system**



When the living area battery is changed, only use batteries of the same type and the same capacity.



See chapter 8 for changing the fuses.



Fault	Cause	Remedy
Road light system does no longer work correctly	Bulb is defective	Replace bulb. Note volts and watts specifications
	Fuse is defective	Replace fuse
Interior lighting does not work	Illuminant, plug con- nector or cable faulty	Contact customer service
The electrically operated entrance step cannot be moved in or out	Fuse on the trans- former/rectifier is defec- tive	Replace fuse on the trans- former/rectifier
The entrance step does not extend or only partially (in the winter)	The mechanics are iced up The protection device (pinch protection) has triggered due to a overload current	Clean the entrance step, remove ice
No 230 V power supply in spite of connection	230 V automatic circuit breaker has triggered	Switch on 230 V automatic circuit breaker
Starter or living area bat- tery is not charged when operated in 230 V mode	Jumbo fuse on the starter or living area battery is defective	Replace jumbo fuse on the starter or living area battery
	No mains voltage	Switch on automatic circuit breaker in the vehicle
	Transformer/rectifier is overheated	Ambient temperature too high or transformer/rectifier ventilation hindered
	Too many appliances are switched on	Switch off appliances that are not required
	Charger module in the transformer/rectifier is defective	Contact customer service
Living area battery is not charged during vehicle operation	Fuse on terminal D+ of the alternator is defective	Replace fuse
	Charge booster is defective	Contact customer service
12 V indicator lamp is not lit	12 V power supply is switched off	Switch on the 12 V power supply
	Battery cut-off switch on the transformer/rectifier is switched off	Set battery cut-off switch to on
	Starter or living area battery is not charged	Charge the starter or living area battery
	Fuse on the living area battery is defective	Replace fuse on the living area battery
12 V power supply does not work	12 V power supply is switched off	Switch on the 12 V power supply
	Battery cut-off switch on the transformer/rectifier is switched off	Set battery cut-off switch to on
	Living area battery is discharged	Charge the living area bat- tery
	Jumbo fuse on the living area battery is defective	Replace jumbo fuse on the living area battery



Fault	Cause	Remedy
12 V power supply does not work in 230 V opera-	12 V power supply is switched off	Switch on the 12 V power supply
tion	Battery cut-off switch on the transformer/rectifier is switched off	Set battery cut-off switch to on
	230 V automatic circuit breaker has triggered	Contact customer service
	Charger module in the transformer/rectifier is defective	Contact customer service
	Jumbo fuse on the living area battery is defective	Replace jumbo fuse on the living area battery
230 V indicator lamp does not light up even though	The mains connection is de-energised	Check external mains connection
230 V mains supply is connected	230 V automatic circuit breaker upstream of transformer/rectifier has tripped or is switched off	Reset 230 V automatic circuit breaker
No voltage at a connected appliance	Self-resetting Polyswitch fuse has tripped	Check plug connectors and cables. Switch off 12 V power supply for approx. 2 minutes, then switch it back on
	Self-resetting Polyswitch fuse has tripped several times (3 times), system has deactivated corre- sponding output perma- nently	Remedy cause of Polyswitch tripping Cancel permanent switch-off (switch on 12 V power supply for living area, press rotary knob and keep it pressed for minimum 3 seconds)
No voltage is supplied by the living area battery	Living area battery is discharged	Charge living area battery immediately
	Living area battery has switched off to protect against deep discharge	If the vehicle is to be laid up for a long period, completely charge the living area bat- tery beforehand
		Discharging is caused by in- active appliances (see chap- ter 8)
Battery charge through solar module not working	Electrical connection to solar module interrupted	Check plug connectors and cables
	Fuse is defective	Replace fuse
	Solar charge regulator is defective	Contact customer service



14.5 AC converter

Fault	Cause	Remedy
Sockets without voltage (for special equipment AC converter)	The AC converter has switched itself off due to a fault	If the AC converter does not start again after some time, contact the customer service
	The circuit breaker in the additional fuse box has tripped	Switch the circuit breaker on

14.6 Gas system



- ▶ In case of a defect of the gas system (gas odour, high gas consumption) there is danger of explosion! Close regulator tap on the gas bottle immediately. Open doors and windows and ventilate well.
- ▶ If the gas system is defective: Do not smoke; do not ignite any open flames, and do not operate electric switches (light switches etc.). Check the tightness of gas-conducting parts and lines with leakage search spray. Do not check with an open flame.
- ► Have the defective gas system repaired by an authorised specialist workshop.

Fault	Cause	Remedy
No gas	Gas bottle is empty	Change gas bottle
	Gas isolator tap closed	Open the gas isolator tap
	Regulator tap on the gas bottle is closed	Open the regulator tap on the gas bottle
	External temperature is too low (-42 °C for pro- pane gas, 0 °C for butane gas)	Wait for higher external temperatures
	Built-in appliance is defective	Contact customer service



14.7 Cooker

Fault	Cause	Remedy
Ignition fuse does not op- erate (flame does not burn after the control knobs are	Heat-up time is too short	Keep control knob pressed for approx. 15 to 20 seconds after ignition
released)	Ignition fuse is defective	Contact customer service
Flame extinguishes when being reduced to its minimum setting	Thermocouple sensor is incorrectly set	Correctly reset thermo- couple sensor (do not bend). The sensor tip should protrude by 5 mm beyond the burner. The sensor neck should not be more than 3 mm away from the burner ring; if necessary, contact cus- tomer service

Heater/boiler 14.8

In the event of a defect contact the nearest customer service workshop of the relevant appliance manufacturer. The list of addresses is enclosed with the accompanying appliance documentation. Only authorised qualified personnel may repair the appliance.

Heater/boiler with CP plus digital operating unit 14.8.1

Fault	Cause	Remedy
Heater does not ignite	Temperature sensor on control unit or remote sensor defective	Pull out plug on control unit. The heater then works without thermostat. Contact the customer service as soon as possible
No display on the operating unit	Fuse on the trans- former/rectifier is defective	Replace fuse on the transformer/rectifier
	Fuse in the electronic control unit has been triggered	Contact customer service
	Living area battery defective	Charge or replace the living area battery (or have it charged or replaced)
Fault with error code is displayed	See table "Fault search instruction"	See table "Fault search instruction"
Boiler empties, safety/drainage valve has opened	Internal temperature below 8 °C	Heat inside
Safety/drainage valve cannot be closed	Temperature at safety/drainage valve below 8 °C	Heat inside
Fan wheel runs noisily or not steadily	Fan wheel is soiled	Contact Truma service department



Fault search instruction

Error code	Cause	Rectification
# 17	Summer operation with empty water container	Switch off the device and allow it to cool down. Fill the boiler with water
	Warm air louvres blo- cked	Check outlet openings
	Air circulation suction system blocked	Remove blocking of air circulation suction system
# 18	Gas pressure regulator iced up	Use regulator heater (defroster if available)
	Proportion of butane gas in gas bottle too high	Use propane gas (butane gas is unsuitable for heating especially for temperatures under 10 °C)
# 21	Room temperature sensor or cable defective	Contact customer service
# 24	Risk of undervoltage Battery voltage too low < 10.4 V	Charge the battery
# 29	Short circuit in heating element for frost control	Remove plug of heating element on electronic control unit. Replace heating element
# 41	Electronics blocked	Contact customer service
# 42	Safety switch has trig- gered	(Not used here)
# 43	Overvoltage > 16.4 V	Check battery voltage and voltage sources (e.g. charger)
# 44	Undervoltage Battery voltage too low < 10.0 V	Charge battery. Replace outdated battery if required
# 45	No 230 V power supply	Check external mains connection
	230 V automatic circuit breaker has triggered	Switch on 230 V automatic circuit breaker
	Overheating protection has triggered	Reset overheating protection. Allow heater to cool, remove connection cover and press reset button
#112, #202, #121, #211	Lack of gas	Open the regulator tap and the gas isolator tap
		Connect a full gas bottle
#122, #212	Combustion air inlet or exhaust gas outlet closed	Check openings for dirt (slush, ice, leaves etc.) and clean if necessary
#255	No connection be- tween heater and op- erating unit	Contact customer service
	Cable defective	Contact customer service

If these measures do not rectify the fault, contact customer service.



14.8.2 Alde heater/boiler



Fault	Cause	Remedy
Heater does not ignite with gas operation	Lack of gas	Open the regulator tap and the gas isolator tap
		Connect a full gas bottle
Heater does not ignite	Battery voltage too low	Charge battery. If the battery voltage rises above 11 V, the heater is switched on automatically
Heater does not ignite at 230 V electrical operation	No 230 V power supply	Switch on 230 V automatic circuit breaker
		Connect 230 V power supply
Heater switches off	Overheating	Allow the heater to cool. Disconnect and connect the 12 V power supply to the heater again to reset the indicator
Heater running, but no heat at the convectors	Circulating pump does not work	Switch on room thermostat
		Contact customer service
Heater and circulating pump running, but no heat at the convectors	Air in the heating system	Bleed hot-water heater

14.9 Air conditioning unit

Fault	Cause	Remedy
Air conditioning unit does not cool	No 230 V power supply	Connect 230 V power supply
	Fuse is defective	Check fuse and replace if necessary
	Temperature below 16 °C	-
	Temperature has been set incorrectly	Adjust the temperature
	Air filter contaminated	Replace air filter



14.10 Refrigerator

14.10.1 General

In the event of a defect contact the nearest customer service workshop of the relevant appliance manufacturer. The list of addresses is enclosed with the accompanying appliance documentation. Only authorised qualified personnel may repair the appliance.



> Further information can be obtained in the manufacturer's instruction manual.

Fault	Cause	Remedy
Refrigerator does not re- frigerate sufficiently	Insufficient ventilation of unit	Check if ventilation grills are covered; remove covers if necessary
		Remove ventilation grills and clean the space behind them (of leaves etc.)
	Thermostat adjusted too low	Adjust higher value on thermostat
	Cooling fins heavily iced- over	Check if refrigerator door closes correctly
	Too many warm foods stored in a short period of time	Let warm foods cool down before storage
	Appliance has not been running long enough	Check again after 4 or 5 hours if the refrigerator cools
	Ambient temperature is too high	Remove the ventilation grills periodically
	The vehicle is not in a horizontal position	Set the vehicle up in a horizontal position
Refrigerator does not refri-	Lack of gas	Connect a full gas bottle
gerate in gas operation		Open the regulator tap and the gas isolator tap
	Air in the gas pipe	Switch appliance off and start it up again (if neces- sary, repeat procedure 3 to 4 times)
Refrigerator does not re-	Fuse is defective	Replace fuse
frigerate in 12 V operation	Battery is discharged	Check and charge battery
	Ignition switched off	Switch on ignition
	Heating element is defective	Contact customer service
Refrigerator does not re- frigerate in 230 V opera-	Fuse is defective	Change fuse; switch fuse on again at fuse box
tion	No 230 V power supply	Connect 230 V power supply
	Heating element is defective	Contact customer service



Fault	Cause	Remedy
Refrigerator changes into gas mode in spite of mains connection	Line voltage too low	Check line voltage (refrigerator will automatically change into 230 V operation in case of correct line voltage)

14.11 Water supply

Fault	Cause	Remedy
Leakage water inside the vehicle	A leak has occurred	Identify leak, re-connect water pipes
No water	Water tank is empty	Replenish drinking water
	Drain cock not closed	Close drain cock
	12 V power supply is switched off	Switch 12 V power supply on
	Switch for water pump is off	Switch water pump on
	Fuse of the water pump is defective	Replace fuse on the transformer/rectifier
	Water pump defective	Exchange water pump (have it exchanged)
	Water pipe snapped off	Straighten water pipe or replace
	Transformer/rectifier de- fective	Contact customer service
Toilet has no flush water	Water tank is empty	Replenish drinking water
Display for water and waste water indicates a wrong value	Measuring probe in the waste water or water tank is soiled	Clean water/waste water tank
	Measuring probe is defective	Replace measuring probe
Waste water tank cannot be emptied	Drain cock is clogged	Open the cleaning cap on the waste water tank and drain the waste water. Rinse the waste water tank well
Drain on the single lever mixer tap is clogged	Perlator calcified	Unclip the perlator, de-calcify in vinegar water (only for products made from metal)
Water jets on the shower nozzle clogged	Water jets calcified	De-calcify shower nozzle in vinegar water (only for products made from metal) or rub off soft noz- zle burling
Water drains from the shower tray slowly or does not drain at all	The vehicle is not in a horizontal position	Position the vehicle horizontally



Fault	Cause	Remedy
Milkiness of the water	Tank filled with dirty water	Clean water tank mechan- ically and chemically; then disinfect and rinse copi- ously with drinking water
	Residues in the water tank or water system	Clean water system me- chanically and chemically; then disinfect and rinse copiously with drinking water
Any change in the taste or odour of the water	Tank filled with dirty water	Clean water system me- chanically and chemically; then disinfect and rinse copiously with drinking water
	Fuel filled into the water tank by mistake	Clean water system me- chanically and chemically; then disinfect and rinse copiously with drinking water. If not successful: Contact a specialist work- shop
	Microbiological deposits in the water system	Clean water system me- chanically and chemically; then disinfect and rinse copiously with drinking water
Deposits in the water tank and/or water-carrying components	Water excessively long in the water tank and in wa- ter-carrying components	Clean water system me- chanically and chemically; then disinfect and rinse copiously with drinking water



14.12 Body

Fault	Cause	Remedy
Flap hinges/door hinges are difficult to operate	Flap/door hinges are not (sufficiently) lubricated	Lubricate flap hinges/door hinges with acid-free and resin-free grease
Hinges/joints in the bath- room unit/toilet compart- ment are difficult to oper- ate/make a grating noise	Hinges/joints are not (sufficiently) lubricated	Lubricate hinges/joints with solvent-free and acid- free grease Spray cans of- ten contain sol- vents
Storage compartment hinges are difficult to operate/make a grating noise	Storage compartment hinges are not (sufficiently) lubricated	Lubricate storage com- partment hinges with acid- free and resin-free grease
Front bonnet swivel system is difficult to operate	Front bonnet swivel system is not (sufficiently) lubricated	Lubricate front bonnet swivel system with acid- free and resin-free grease
Wind-up skylight is difficult to operate	Threaded spindle not lubricated	Lubricate threaded spindle
	Threaded spindle defective	Have threaded spindle replaced
Electric pull-down bed	Fuse is defective	Replace fuse
does not move	Living area battery is empty or the trans- former/rectifier has switched off due to insuffi- cient voltage	Charge the living area battery
	Drive is defective	In an emergency, the pull- down bed can be moved manually; afterwards, con- tact customer service



The authorised dealers and service centres are available for any spare parts requirement.

14 Troubleshooting





15.1 Weight details for optional equipment



- The use of accessories, parts and fittings not supplied by **HYMER GmbH & Co. KG** may cause damage to the vehicle and jeopardize road safety. Even if an expert's report, a general type approval or a design certification exists, there is no guarantee for the proper quality of the product.
- Every alteration of the original condition of the vehicle can alter road behaviour and jeopardize road safety.
- No liability can be assumed for damage caused by products which have not been released by HYMER GmbH & Co. KG. This also applies to impermissible alterations to the vehicle.

Depending on the model series, different optional equipments are offered. You can find out which optional equipments are available for your vehicle in the accessories list, which is available separately. There you will also find information on the weights of the individual optional equipments.



276



16.1 Technical data



- Only the details provided in the actual vehicle documentation shall be binding with regard to the technical data.
- The measurements as well as the net weight of the vehicle may change when mounting accessories or optional equipment. Differences due to manufacturing tolerances (+/- 5 %) are possible and admissable.

16.2 Dimensions and permissible number of persons

вмс	Wheel- base in cm	Length in cm	Width in cm	Height in cm	Permissible number of persons Regular/additional
550	390	699	229	296	4 + 1
580	390	699	229	296	4
600	400	719	229	296	4 + 1
680	420	739	229	296	4 + 1
690	420	739	229	296	4 + 1

Refer to the vehicle documents or the instruction manual of the base vehicle for further information on technical data. The authorised dealers and service centres will also provide information if necessary.





Lubricating the rear axle



- The rear axle must be re-lubricated by an authorised specialist company / service partner.
- Carry out the lubrication while the rear axle is not loaded.
- Only use following lubricating grease for lubricating: Stabutherm GH 461 by Klüber

(Or a lubricant authorised by the manufacturer of the chassis)





The weight specifications and tests for motorhomes are uniformly regulated throughout the EU in EU Implementing Regulation No. 2021/535 (until June 2022: EU Implementing Regulation No. 1230/2012). We have summarised and explained the key terms and legal requirements from this regulation for you below. Our dealers and the HYMER configurator on our website offer you additional assistance in configuring your vehicle.

1. Technically permissible maximum laden mass

The technically permissible maximum laden mass of the vehicle (e.g. 3,500 kg) is a mass specification set by the manufacturer which the vehicle must not exceed. Information on the technically permissible maximum laden mass of the model you have chosen can be found in the technical data. If the vehicle exceeds the technically permissible maximum laden mass in everyday driving, this constitutes an administrative offence which may result in a fine.

2. Mass in running order

In simple terms, the mass in running order is the basic vehicle with standard equipment plus a legally fixed standard weight of 75 kg for the driver. This essentially includes the following items:

- the unladen weight of the vehicle together with the bodywork, including operating fluids such as greases, oils and coolants;
- the standard equipment, i.e. all equipment items that are included as standard in the factory-fitted scope of delivery;
- the fresh water tank filled to 100 % in driving mode (driving fill according to manufacturer's specifications; 20 litres) and an aluminium gas cylinder filled to 100 % with a weight of 16 kg;
- the fuel tank, which is 90 % full, including fuel;
- the driver, whose weight regardless of the actual weight is generally specified as 75 kg in accordance with EU law.

Information on the mass in running order can be found for each model in our sales documents. It is important to note that the value for mass in running order given in the sales documents is a default value determined in the type-approval procedure and verified by the authorities. It is legally permissible and possible for the mass in running order of the vehicle delivered to you to deviate from the nominal value stated in the sales documents. The legally permissible tolerance is $\pm\,5$ %. In this way, the EU legislator accounts for the fact that certain fluctuations in the mass in running order occur due to variations in the weight of supplied parts as well as due to processes and weather conditions.

These weight deviations can be illustrated by means of an example calculation:

- Mass in running order acc. to sales documents: 2,850 kg
- Legally permissible tolerance of ± 5 %: 142.50 kg
- Legally permissible range of mass in running order: 2,707.50 kg to 2,992.50 kg

The specific range of permissible weight deviations can be found for each model in the technical data. HYMER makes great efforts to reduce weight variations to the minimum that is unavoidable for production reasons. Deviations at the upper and lower end of the range are therefore very rare; however, they cannot be completely ruled out technically, even with all optimisations. The real weight of the vehicle and compliance with the permissible tolerance is therefore checked by HYMER by weighing each vehicle at the end of the line.



3. Mass of the passengers

The mass of the passengers is set a standard value of 75 kg for each seat provided by the manufacturer, regardless of the actual weight of the passengers. The mass of the driver is already included in the mass in running order (see no. 2 above) and is therefore not included again. In the case of a motorhome with four permitted seats, the mass of the passengers is therefore $3 \times 75 \text{ kg} = 225 \text{ kg}$.

4. Optional equipment and actual mass of the vehicle

Optional equipment (also: additional equipment) includes, according to the legal definition, all optional equipment parts not included in the standard equipment which are fitted to the vehicle under the responsibility of the manufacturer – i.e. ex works – and can be ordered by the customer (e.g. awning, bicycle or motorbike carrier, satellite system, solar system, oven, etc.). Information on the individual or package weights of the optional equipment that can be ordered can be found in our sales documents. Optional equipment in this sense does not include other accessories that are retrofitted by the dealer or you personally after the vehicle has been delivered ex works.

The mass of the vehicle in running order (see no. 2 above) and the mass of the optional equipment fitted to a specific vehicle at the factory are together referred to as the actual mass. You will find the corresponding information for your vehicle after handover under item 13.2 of the Certificate of Conformity (CoC). Please note that this specification also represents a standardised value. Since the mass in running order – as an element of the actual mass – is subject to a legally permissible tolerance of \pm 5 % (see no. 2), the actual mass may also deviate accordingly from the stated nominal value.

5. Pay-mass and minimum pay-mass

The installation of optional equipment is also subject to technical and legal limits: Only so much optional equipment can be ordered and fitted at the factory that sufficient free weight remains for baggage and other accessories ("pay-mass") without exceeding the technically permissible maximum laden mass. The pay-mass is calculated by subtracting the mass in running order (nominal value according to sales documents, see no. 2 above), mass of the optional equipment and the mass of the passengers (see no. 3 above) from the technically permissible maximum laden mass (see no. 1 above).

The EU regulations stipulate a fixed minimum pay-mass for motorhomes, which must remain as a minimum for baggage or other non-factory-fitted accessories. This minimum pay-mass is calculated as follows:

Minimum pay-mass in kg \geq 10 x (n + L)

Where: "n" is the maximum number of passengers plus the driver and "L" is the overall length of the vehicle in metres.

For a motorhome with a length of 6 m and 4 approved seats, the minimum pay-mass is therefore e.g. $10 \text{ kg} \times (4 + 6) = 100 \text{ kg}$.



To ensure that the minimum pay-mass is maintained, there is a maximum combination of optional equipment that can be ordered for each vehicle model. In the above example with a minimum pay-mass of 100 kg, the total mass of optional equipment for a vehicle with four permitted seats and a mass in running order of 2,850 kg should not exceed 325 kg:

3,500 kg technically permissible maximum laden mass

- 2,850 kg mass in running order
- 3 x 75 kg mass of the passengers
- 100 kg minimum pay-mass
- = 325 kg maximum permissible mass of optional equipment

It is important to note that this calculation is based on the default value for mass in running order as defined in the type-approval procedure, without taking into account the permissible weight deviations for mass in running order (see no. 2 above). If the maximum permissible value for the optional equipment of (in the example) 325 kg is almost or completely exhausted, an upward weight deviation can therefore result in the minimum pay-mass of 100 kg being met mathematically using the default value for the mass in running order, although in fact there is no corresponding load capacity. Here, too, an example calculation for a vehicle with four seats, whose real weighed mass in running order is 2 % above the nominal value:

3,500 kg technically permissible maximum laden mass

- 2,907 kg real weighed mass in running order (+ 2 % compared to the stated value of 2,850 kg)
- 3 x 75 kg mass of the passengers
- 325 kg optional equipment (maximum permissible value)
- = 43 kg actual load capacity (< minimum pay-mass of 100 kg)

In order to avoid such a situation, HYMER further reduces the maximum permissible weight of the total optional equipment that can be ordered on a model-specific basis. The limitation of optional equipment is intended to ensure that the minimum pay-mass, i.e. the legally prescribed free mass for baggage and retrofitted accessories, is actually available for the vehicle load capacity of the vehicles delivered by HYMER.

Since the weight of a specific vehicle can only be determined when it is weighed at the end of the line, in very rare cases a situation may arise in which the minimum pay-mass at the end of the line is not guaranteed, despite this limitation of optional equipment. In order to guarantee the minimum pay-mass even in these cases, HYMER will check together with your trade partner and you before delivery of the vehicle whether, for example, the vehicle is loaded up, seats are reduced or optional equipment is removed.



6. Effects of tolerances of the mass in running order on the pay-mass

Regardless of the minimum pay-mass, you should note that unavoidable production-related fluctuations in the mass in running order – both upwards and downwards – have a mirror-image effect on the remaining load capacity: If you order our example vehicle (see no. 3. above), for example, with optional equipment with a total weight of 150 kg, the calculated pay-mass based on the default value for the mass in running order is 275 kg. The load capacity actually available may deviate from this value due to tolerances and may be higher or lower. If the mass in running order of your vehicle is, for example, permissibly 2 % higher than stated in the sales documents, the load capacity is reduced from 275 kg to 218 kg:

3,500 kg technically permissible maximum laden mass

- 2,907 kg real weighed mass in running order (+ 2 % compared to the stated value of 2,850 kg)
- 3 x 75 kg mass of the passengers
- 150 kg optional equipment ordered for the specific vehicle
- = 218 kg actual load capacity

As a precaution to ensure that the calculated pay-mass is actually given, you should therefore take the possible and permissible tolerances for the mass in running order into account when configuring your vehicle.

We also recommend that you weigh the laden motorhome on a non-automatic scale before each journey and, taking the individual weight of the passengers into account, determine whether the technically permissible maximum laden mass and the technically permissible maximum mass on the axle are observed.



12 V fuses		App HYMER Connect	151
For the AC converter		Appliances	165
For Thetford toilet		Manuals	
Starter battery		Armrest, adjustment	57
Ventilation system		Automatic power selection (AES)	
12 V indicator lamp		Auxiliary fans of hot-water heater	
12 V main switch		Awning	
12 V power supply		Awning light	
Switching off		Awriiing light	200
Switching on			
Troubleshooting		В	
230 V connection		Basic equipment	23
Troubleshooting		Bathroom	
230 V fuse		Ventilation	
230 V fuse box		Battery alarm	
230 V indicator lamp	150	Battery see starter battery or	
230 V power supply	157	living area battery	138
230 V power supply see also		Battery voltage, displaying	
230 V connection	157	Battery, charging with solar energy	
Α		Beds Protective panel / fall out protection	
		Queen size bed, mechanically	117
AC converter	,	height-adjustable	115
Position		Rear bed, extending width	
Troubleshooting		Rear single bed, extending lying surfa	
Access ladder, pull-down bed		Before the journey	
Accessories, fitting		Bike rack	
Actual vehicle mass	•	Load	36
Ad-Blue	67	Travelling with a loaded bike rack	
Additional seat	59, 61	Blind, cleaning	
Add-on parts see special equipment	14	Bluetooth	
Air conditioning unit (Truma)	188	Connecting mobile device (pairing)	
Air circulation	191	Switching on/off	
Air distribution		Boiler	
Automatic mode	189	Boiler (Alde)	
Cooling		Emptying	183
Heater		Water temperature, setting	
Lighting		Water, filling with	
Operating modes		Boiler (Truma)	
Remote controlSoft-start		Emptying	
Switching off		Hot water production, switching off	
Switching on		Hot water production, switching on	.170, 176
Timer		Operating modes	.172, 178
Air conditioning unit, troubleshooting		Safety/drainage valve	
Air outlet nozzles, adjusting		Troubleshooting	
		Water, filling with	
Air suspension Troubleshooting		Bonnet	
Vehicle, lowering		Closing	
Vehicle, raising		Opening	
Alarm system		Brakes	
Alloy wheel rims		Check	
Alloy Wilder Hills	200	Braking system, troubleshooting	263



Breakdown service	48	Checklist	
Bulbs, see illuminants	245	Before the journey	43
Butane gas		For commissioning after a lay-up	
		Road safety	
•		Checks see checklist	
С		Child restraint systems	52
Cable reel	157	Children's beds1	10, 113
Camping gas bottles, use	18, 125	Circulation fan1	68, 174
Capacity of the battery	136	Cleaning see care	
Caravan coupling	37	Closed circuit current	
With detachable ball neck		Closed-circuit current consumption	
Care	219	-	
Blind		Condensation	85, 80
Carpet		Condensation on the double	
Engine compartment		acrylic glass pane	86
Entrance step		Condensation on the screwed	
External care		connections in the floor	
Furniture surfaces	224	Connecting cable see 230 V connection	157
GRP add-on parts	221	Control unit, heater	174
High-pressure cleaner, washing with.	219	Control unit, hot-air heater	168
Hot-water heater	242	Conventional load	
In the winter	231	Cooker1	
Insect screen		Switching off	
Interior care		Switching on	
Kitchen installation		_	
Lamps		Cooker see gas cooker or gas oven	
Lay-up		Curtain shade, driver's window	
Leather covers		Curtain shade, front passenger's window	64
PVC-floor covering		Curtain shade, windscreen	64
Roman shade			
Seat belt		D	
Stainless steel surfaces		D	
Synthetic parts, interior		Danger of suffocation	
Underbody		Dimensions see technical data	277
Upholstery		Direction indicator	250
Wall covering, inside Washing		Displays	
Waste water tank		Battery voltage	148
Water pipes		Waste water tank level	
Water system		Water tank level	149
Water tank		Disposal	
When taking out of operation	220	Household waste	10
temporarily	232	Sewage	
Windows		Waste water	
Windscreen washer system		Divan, sleeping conversion	121
Windscreen wipers		Door lock	
Carpet, cleaning		Doors	, 01
Central locking system		Living area door	70
Remote control		Lock	
		Troubleshooting	
Changing wheels		Drain cocks, position	
Tightening torque		•	∠11
riginorning torquo	200	Drinking water filler neck	207
		Closing	
		Opening	
		Driver's cabin lighting	109



Driver's door, inside	Fire risks, avoidance	13
Locking81	Flap lock	
Opening81	Closing	84
Driver's door, outside	Opening	
Locking81	Flashing indicator see direction indicator	
Opening81	Flat screen40	
Driver's seat56	Floor storage compartment	
Adjusting in lengthways direction56		
Armrest, adjustment57	Fog light	
Backrest, adjustment57	Folding worktop	
Seat height, adjusting56	Forced ventilation	14, 85
Seat inclination, setting56	Front passenger's seat	
Turning into the driving position56	Adjusting in lengthways direction	
Driving47	Armrest, adjustment	
Driving speed49	Backrest, adjustment	
	Seat height, adjusting	
_	Seat inclination, setting	
E	Turning into the driving position	56
Electrical system	Front passenger's window	
230 V connection, troubleshooting 264	Closing	
Explanation of terms135	Opening	
Lighting, troubleshooting264	Fuel filler neck	
Safety instructions19	Closing	
Troubleshooting263	Opening	
Electrically adjustable external mirrors63	Furniture flaps, troubleshooting	273
Energy balance, living area battery143	Furniture surfaces, cleaning	224
Engine compartment, care221	Fuses	
Entrance step	12 V fuses	160
Care	230 V fuse	157, 164
Extending38	For skylight	163
Retracting38	For starter battery	162
Warning tone38	For the AC converter	
Environmental tips10	For the hot-water heater	
Exterior lighting	For the pull-down bed	
Bulbs, changing245	For the satellite unit	
Check43	For Thetford toilet	
Troubleshooting264	For ventilation system	
External care	Installation positions	160
External connection see 230 V connection76		
External flaps84	G	
Flap lock	Garage door	82
	Emergency release	
External gas connection	Gas bottle compartment17	
External mirrors, electrically adjustable,	Extractable	
adjusting63		
	Gas bottle compartment pull-out	
F	Gas bottles	
Fault current protection switch157	Changing (with gos bottle	131, 133
Check164	Changing (with gas bottle	407
Filling the tank	compartment pull-out)	
_	Safety instructions	
Fire Extinguishing 12	Gas burner	
Extinguishing	Switching off	
Response to	Switching on	
Fire prevention13	Gas connection, external	126



Gas cooker	High-pressure cleaner, washing with	219
Cleaning225	Hinged roof window	
Switching off194	Closing	89
Switching on193	Continuous ventilation	
Troubleshooting267	Opening	
Gas cooker, see also cooker 194	Hinged skylight	
Gas filter132	Closing	
Changing241	Insect screen	
Gas grill	Locking in the ventilation position	
Switching off	Opening	
Switching on	Roman shade	
Gas isolator tap125	Hinged window	
Symbols	Closing	87
Gas odour 17, 123, 266	Continuous ventilation	
	Insect screen	
Gas oven	Opening	
Switching off	Roman shade	
Switching on	Hot air distribution	167
Gas pressure regulator, screw connections 125	Hot-air heater16	
Gas regulator42	Circulation fan16	
Gas system	Control unit16	
Defect17, 123, 266	Operating modes17	-
DuoControl129	Troubleshooting	
Gas bottles, changing129	Hot-water heater	
General instructions16	230 V electrical operation, selecting	183
No gas266	Auxiliary fans	
Operation 129	Care	
Switching automatics	Control unit	
Troubleshooting266	Fluid level, check	
Grill	Gas and 230 V electrical operation,	
Switching off196	selecting	182
Switching on196	Gas operation, selecting	
GRP add-on parts, care221	Heat exchangers	
	Heater, switching off	
ш	Heater, switching on	
Н	Heating fluid, topping up	243
Handbrake69	Maintenance work	242
Applying14	Operating modes	182
Handling of tyres257	Settings menu	
Headrests58	Start screen	
Adjustment58	Tool menus	182
Removing58	Hydraulic steady legs	72
Heater 166	HYMER Connect App	151
Air outlet nozzles, adjusting167		
Circulation fan 168, 174		
Hot air distribution167	l	
Initial start-up166	Illuminant, replacing	245
Troubleshooting267	Exterior lighting	245
Venting243	Front lights	
Heater, external mirrors63	Licence plate light	250
Heating fluid, changing242	Living area	
Heating fluid, topping up243	Rear lights	249
	Side lights	
Hibernation mode, vehicle, activate	Third brake light	
High rate of gas consumption 17, 123, 266	Types of external bulbs	251



Indicator lamp, 12 V	148	Rear	249
Indicator lamp, 230 V power supply	150	Rear area	70
Indicator lamp, toilet		Side	250
Information stickers		Troubleshooting	
Initial start-up		Types of external bulbs	251
•		Living area battery	
Inner door, troubleshooting		Balance of energy	
Insect screen, cleaning	224	Battery alarm	
Insect screen, hinged skylight	0.5	Position	
Closing		Troubleshooting	
Opening		Voltage, displaying	
Insect screen, skylight with crank handle		Living area door	
Closing		Insect screen	83
Opening	93	Living area door, inside	0.0
Insect screen, window	04	Locking	
Closing		Opening	80
Opening	91	Living area door, outside	00
Insect screen, wind-up skylight	00	Locking	
Closing		Opening	
Opening		Load	
Inspection time limits		Bike rack	
Inspections		Rear garage	
Inspections, official	239	Rear storage spaceRoof rack	
Interior care	224	Load rack for roof loads	
Interior lighting	251		
Interior lighting, troubleshooting	264	Load see also payload	27
Isofix fastening system for child seat		Lock	0.4
<i>3</i> ,		Driver's door	
		External flap	
L		Living area door	
Ladder, rear	32	L-seating group, sleeping conversion	120
Lamps	251		
Cleaning		M	
Operating levels	110	Maintenance work	240
Lay-up		Air suspension	
General		Cooker	
Temporary		Hot-water heater	
Temporary (toilet)		Refrigerator	244
Leakage water inside the vehicle	271	Marker light	250
Leather covers, cleaning	227	Mass in running order	
Lift-off table	102	Mechanical steady legs	
Conversion to bed foundation	102	Extending	71
Table height, adjusting	102	Length, adjustment	
Table top, shifting	102	Retracting	
Light metal wheel rims see alloy		Multifunctional sideboard	
wheel rims	260	Multimedia system	
Lighting		Manuficula System	40
Bulbs, changing			
Driver's cabin		N	
Front		Nose weight	37
Lamps, cleaning		 	
Living area			
Operating levels	110		



0		Pull-down bed, electrically operated	
OEM service	43	Access ladder	
Official inspections		Emergency operation	
Off-load voltage		Lowering	
_		Retaining belts, tightening	
Oil level, checking	66	PVC-floor covering, cleaning	224
Operating modes, air conditioning unit (Truma)	189		
Operating modes, boiler (Alde)		Q	
		Queen size bed	115
Operating modes, boiler (Truma)			
Operating modes, hot-air heater		_	
Operating modes, hot-water heater		R	
Operating modes, refrigerator (Thetford)	199	Ramps	69
Optional equipment		Reading lamp, switching on/off	109
Certification		Rear area lighting	70
Description		Rear axle load	
Weights		Rear axle, lubricating2	
Overloading	27	Rear bed	
Р		Rear garage	
-	4.47	Rear garage heating	
Panel (LT 94)		Rear ladder	
Panel, 7 inch		Folding downwards	
Position		Folding upwards	
Panel, see also displays		Rear storage space	
Permissible gross weight see technically		Refrigerator	
permissible maximum laden mass	22	Change-over between energy sources.	
Personal equipment	25	Door lock	
Position		Operating modes	
230 V fuse box	_	Switching on	
7 inch panel		Troubleshooting Ventilation grill, removing	
AC converter		Winter cover	
Ad-Blue tank		Refrigerator door	130
Call for breakdown assistance		Locking in the ventilation position	202
Control unit, heater 168,		Opening	
Fuses Heat exchanger spherical valve		Refrigerator ventilation grill, removing	
Living area battery			
Safety/drainage valve boiler		Remote control, central locking system	
Satellite unit control unit		Repair kit	
SCU		Replacement keys	
Solar installation display panel	159	Reversing camera	64
Starter battery		Risk of frost damage2	.03, 208
Transformer/rectifier	146	Road safety	43
Waste water tank operating lever	210	Checklist	43
Water filter	209	Notes for	15
Propane gas	17, 124	Roman shade, cleaning	224
Pull-down bed		Roman shade, driver's window	
Access ladder	112	Closing	
Closing	111	Opening	91
Opening		Securing	63
Safety net	111		



Roman shade, front passenger's window	63	Shade, skylight with crank handle	
Closing	91	Closing	93
Opening	91	Opening	93
Securing		Shower	
Roman shade, hinged skylight		Side marker light	
Closing	95	_	
Opening		Sideboard, multifunctional	
Roman shade, window		Sink cover	
Closing	90	Skylight with crank handle	
Opening		Closing	
Roman shade, wind-up skylight		Insect screen, closing	
Closing	96	Insect screen, opening	
Opening		Opening	
. •		Shade, closing	
Roof load		Shade, opening	
Roof rack, load		Skylights	
Roof rail	32	Fuse	
		Skylight with crank handle	
S		Troubleshooting	
		Wind-up skylight	
Safety instructions		With Fan	96
Changing wheels		Sleeping conversion	
Cooker		Divan and individual seat	121
Electrical system		L-seating group and individual seat	120
Fire prevention		L-seating group into additional bed	120
Road safety		Smart Battery system	139
Towing		Snow chains	
Water system		Solar cells	
Safety instructions symbols	9	Solar installation	
Safety knob, hinged window	86		
Safety net, pull-down bed11	1, 114	Spare parts	
Safety/drainage valve boiler17	1. 177	Spare wheel	257
Position 171, 177		Special equipment	
Sanitary fittings	•	Safety instructions	14
Satellite unit		Stainless steel surface, cleaning	226
With automatic antenna alignment		Starter battery	
		Battery alarm	150
SCU		Loading	138
Position		Position	139
Seat belt cover52		Troubleshooting	264
Attaching		Voltage, displaying	148
Seat belts		Start-up	
Cleaning		After lay-up over winter	236
Correct fastening	51	After temporary lay-up	
Seat heater	57	Steady legs	
Seating arrangement	62	Emergency operation	
Seats, adjusting		Extending	
Seats, rotating		Length, adjustment	
•		Retracting	
Serial number		Step, driver's door	
Service and sales partners		Storage spaces	
Set of keys	21		
Sewage container		Supports see steady legs	10
Emptying			
Removal	215		



Suspension table	Troubleshooting	
Converting to bed foundation105	12 V power supply	265
Extending104	230 V connection	264
Reducing size104	AC converter	266
With separable support leg104	Air conditioning unit	269
Symbols for gas isolator taps125, 165	Air suspension	263
Synthetic parts in the toilet and living areas,	Battery	264
cleaning224	Body	273
System Control Unit	Boiler	
Cyclem Control Chite	Braking system	
	Electrical system	
Т	Furniture flaps	
Table102	Gas cooker	
Extending103	Gas system	
Reducing size103	Heater	
Shifting103	Hot-air heater	
Turning103	Inner door	
Table with pillar table leg	Lighting	
Table top, rotating104	Living area battery	
Table top, shifting104	Refrigerator	
Tables102, 104	Skylight	
Tank lid see fuel filler neck	Starter battery	
	Toilet Water supply	
Technical data277		
Technically permissible maximum laden	TV unit	
mass22, 26	Twilight, switching on/off	
Television40	Tyre change see wheels, changing	258
Thetford toilet	Tyre specifications	256
Flushing214	Tyres	
Level indicator214	Certification	256
Sliding trap, closing214	Excessive wear15, 43	
Sliding trap, opening214	General instructions	255
Tightening torque, wheels259	Handling	257
Toilet	Load-carrying capacity	258
Flushing 213	Tyre pressure	
Fuse162	Tyre selection	256
Indicator lamp213		
Temporary lay-up217	U	
Troubleshooting271	_	
Ventilation system216	Underbody, maintenance	
Winter operation216	Upholstery, cleaning	227
Toilet level indicator214	USB socket	138
Total discharge 135		
Towing16, 68	V	
General instructions37	-	
Safety instructions16	Vehicle identification plate	253
Towing eye, installing68	Vehicle lighting see lighting	245
Transformer/rectifier144	Vehicle load capacity	21
Functions	Calculation	
Lay-up146	Composition	23
Position	Example calculation	23
Travel cots suitable for children 110, 113	Vehicle load capacity see also load	21
Traver cots suitable for dillidicit	Vehicle, washing	
	Ventilation	
	Bathroom	
	Datin 00111	



Ventilation system (toilet)216, 252	Water tank	
Volume of waste water, displaying149	Cleaning	229
Volume of water, displaying149	Draining water	
volume of water, displaying149	Filling	
	Filling level, displaying	149
W	Tank alarm	
Wall covering, inside, care225	Water quantity, reducing	
Warning stickers254	Water, filling with	206
Warning tone, entrance step38	Weight details for optional equipment	275
·	Wheel chock	69
Washing with a high-pressure cleaner219	Wheel rim size	258
Waste water hose	Wheel rim type	255
Waste water tank	Window winder	
Cleaning 230	Windows	
Cleaning230 Drain cock210	Insect screen	
Drain cock operating switch210	Roman shade	
Emptying211	Windows, cleaning	
Filling level, displaying149	Windscreen blade, changing	
Operating lever drain cock210	Windscreen heater	
Tank alarm150	Switching off	
Troubleshooting271	Switching on	
Water filter209	Windscreen washer fluid, filling in	
Water pipes, cleaning229	Windscreen washer system, care	
Water pump	•	
Water supply	Windscreen wipers, care	
General203	Wind-up skylight	
Troubleshooting271	Closing Insect screen	
Water system	Opening	
Care229	Roman shade	
Cleaning229	Troubleshooting	
Disinfect230	Winter care	
Emptying208	Timer our our our our our our our our our ou	201
Filling205		
Safety instructions19		

